



AHLERS AEROSPACE INSTRUMENT & ACCESSORY SHOP REPAIR CAPABILITY LIST
3621 RAIDER DRIVE, HURST, TEXAS 76053

***NOTE:** Please contact our sales department at **817-553-2155** if unable to locate the item you require*

MFG P/N	DESCRIPTION	MFG.
23007827	SOLENOID VALVE	VALCOR ENGINEERING
01-0770028-05	POWER SUPPLY	WHELEN
01-0770062-03	POWER SUPPLY	WHELEN
01-0770062-04	POWER SUPPLY	WHELEN
01-0770062-05	POWER SUPPLY	WHELEN
01-077062-03	POWER SUPPLY	WHELEN
01-077062-04	POWER SUPPLY	WHELEN
01-077062-05	POWER SUPPLY	WHELEN
01-0790044-01	ANTICOLLISION LIGHT	WHELEN
01-0790044-01 thru -58	ANTI-COLLISION LIGHT	WHELEN
014-901-010	TRANSMITTER, FUEL QTY.	GULL AIRBORNE
014-901-012	TRANSMITTER, FUEL QTY.	GULL AIRBORNE
014-901-013	TRANSMITTER, FUEL QTY.	GULL AIRBORNE
014-901-015	TRANSMITTER, FUEL QTY.	GULL AIRBORNE
020-904-001	TRANSMITTER, FUEL QTY.	GULL AIRBORNE
020-904-002	TRANSMITTER, FUEL QTY.	GULL AIRBORNE
027-003-001	TRANSMITTER, FUEL QTY.	GULL AIRBORNE
027-003-005	TRANSMITTER, FUEL QTY.	GULL AIRBORNE
035A-6009-1	INDICATOR, DUAL FUEL PRESSURE	INSCO
035A-876418-5	INDICATOR, TACHOMETER	INSCO
035A-98641	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
035A-986411	INDICATOR, EXPANDED SCALE	INSCO
035A-986414-3	INDICATOR, OUTSIDE AIR TEMPERATURE	INSCO
035A-986415	INDICATOR, OUTSIDE AIR TEMPERATURE	INSCO
035A-986418	INDICATOR, TACHOMETER	INSCO
035A-986418-3	INDICATOR, TACHOMETER	INSCO
035A-986418-401	INDICATOR, TACHOMETER	INSCO
035A-PS1819A	INDICATOR, VOLTMETER/AMMETER	INSCO
035A-PS1820	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
035A-PS-1822	INDICATOR, OIL TEMPERATURE	INSCO
035A-PS-1824	INDICATOR, HYDRAULIC PRESSURE	INSCO
035A-PS-1824A	INDICATOR, HYDRAULIC PRESSURE	INSCO
100-380006-11	TRANSMITTER, FUEL QTY.	GULL AIRBORNE
100-380006-13	TRANSMITTER, FUEL QTY.	GULL AIRBORNE
100-380006-15	TRANSMITTER, FUEL QTY.	GULL AIRBORNE
100-380006-17	TRANSMITTER, FUEL QTY.	GULL AIRBORNE
100-380006-37	TRANSMITTER, FUEL QTY.	GULL AIRBORNE
100-380006-41	TRANSMITTER, FUEL QTY.	GULL AIRBORNE
100-380006-43	TRANSMITTER, FUEL QTY.	GULL AIRBORNE
100-380006-47	FUEL QTY GAGING SYS.	GULL AIRBORNE
100-380006-49	TRANSMITTER, FUEL QTY.	GULL AIRBORNE
100-380006-53	BULKHEAD ASSY	GULL AIRBORNE
100-380006-7	TRANSMITTER, FUEL QTY.	GULL AIRBORNE
100-384058-3	INDICATOR, OIL TEMP/PRESS	INSCO
100-384058-5	INDICATOR, OIL TEMP/PRESS	INSCO
100-384073-1	INDICATOR, FUEL FLOW	INSCO
100-384093-3	INDICATOR, FLAP POSITION	INSCO
100-384116-5	INDICATOR, TORQUE	INSCO
100-384117-1	INDICATOR, OIL TEMP/PRESS	INSCO
10042-0000-0101	INDICATOR, POWER TURBINE SHAFT TORQUE	AERITALIA
101-384009	INDICATOR, FUEL FLOW	INSCO
101-384016-1	INDICATOR, OIL TEMP/PRESS	INSCO
101-384016-3	INDICATOR, OIL TEMP/PRESS	INSCO
101-384093-1	INDICATOR, FUEL QTY	INSCO

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
101-384122-1	INDICATOR, OIL TEMP/PRESS	INSCO
101-384157-5	INDICATOR, TACHOMETER	INSCO
101-384159-7	INDICATOR, TACHOMETER	INSCO
101-384241-5	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
1020-1002	PANEL, DOOR AJAR	INSCO
102-380003-1	INDICATOR, FUEL FLOW	INSCO
102-380004-1	INDICATOR, DUAL FUEL FLOW	INSCO
102-380011-11	INDICATOR, TACHOMETER	INSCO
102-40001	TRANSDUCER	AHLERS AEROSPACE
102-40002	TRANSDUCER	AHLERS AEROSPACE
102-40004	TRANSDUCER	AHLERS AEROSPACE
102-40009	TRANSDUCER	AHLERS AEROSPACE
102-40010	TRANSDUCER	AHLERS AEROSPACE
102-40011	TRANSDUCER	AHLERS AEROSPACE
102-40012	TRANSDUCER	AHLERS AEROSPACE
103-40001	TRANSDUCER	AHLERS AEROSPACE
103-40002	TRANSDUCER	AHLERS AEROSPACE
103-40003	TRANSDUCER	AHLERS AEROSPACE
103-40004	TRANSDUCER	AHLERS AEROSPACE
103-40008	TRANSDUCER	AHLERS AEROSPACE
103-40009	TRANSDUCER	AHLERS AEROSPACE
103-40010	TRANSDUCER	AHLERS AEROSPACE
103-40011	TRANSDUCER	AHLERS AEROSPACE
103-40012	TRANSDUCER	AHLERS AEROSPACE
103-40013	TRANSDUCER	AHLERS AEROSPACE
103-40014	TRANSDUCER	AHLERS AEROSPACE
10355N01T00	INDICATOR, TEMPERATURE	AMETEK
10355N02T00	INDICATOR, TURBINE OUTLET TEMP	AMETEK
10355N05T0	INDICATOR, TURBINE OUTLET TEMP	AMETEK
10355N07T00	INDICATOR, TURBINE OUTLET TEMP	AMETEK
10355N08T00	INDICATOR, TEMPERATURE	AMETEK
104-384008-1	INDICATOR, FLAP POSITION	INSCO
104-384010-3	INDICATOR, TACHOMETER	INSCO
104-384011-3	INDICATOR, TACHOMETER	INSCO
104-384012	INDICATOR	INSCO
104-384013-1	INDICATOR, FUEL FLOW	INSCO
104-384014-1	INDICATOR, OIL TEMP/PRESS	INSCO
104-384014-3	INDICATOR, OIL TEMP/PRESS	INSCO
104-384014-5	INDICATOR, OIL TEMP/PRESS	INSCO
104-384020-1	INDICATOR, VOLTMETER/AMMETER	INSCO
104-384059-1	INDICATOR, OIL TEMP/PRESS	INSCO
104-384059-3	INDICATOR, OIL TEMP/PRESS	INSCO
10446N02	INDICATOR, TURBINE OUTLET TEMP	AMETEK
10447	INDICATOR, TEMPERATURE	AMETEK
105-90845	INDICATOR, TACHOMETER	INSCO
105-90863	INDICATOR, TRIPLE TACHOMETER	INSCO
105-90882	INDICATOR, OIL TEMPERATURE	INSCO
105-90941	INDICATOR, DUAL TORQUE	INSCO
105-90947	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
105-90951	INDICATOR, DUAL TORQUE	INSCO
105-94564	SYSTEM, MAST MOMENT	MBB
105-94575	SYSTEM, MAST MOMENT	MBB
105-956851	INDICATOR, N1 TACHOMETER	INSCO
105-956871	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
105-956891	INDICATOR, DUAL TORQUE	INSCO
105-956911	INDICATOR, OIL TEMPERATURE	INSCO
105-957051	INDICATOR, N1 TACHOMETER	INSCO
105-957151	INDICATOR, OIL TEMPERATURE	INSCO
105-957201	INDICATOR, TRIPLE TACHOMETER	INSCO
105-957251	INDICATOR, DUAL OIL TEMPERATURE	INSCO
10-60757-22	INDICATOR, AC VOLTMETER	INSCO
10-60757-23	INDICATOR, DC VOLTMETER	INSCO
10-60757-24	INDICATOR, DC AMMETER	INSCO
10-60757-25	INDICATOR, AC HERTZ	INSCO
10-60757-27	INDICATOR, AC AMMETER	INSCO
106-40001	TRANSDUCER	AHLERS AEROSPACE
106-40002	TRANSDUCER	AHLERS AEROSPACE
107-40001	MONOPOLE TACH GENERATOR	AHLERS AEROSPACE

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
108-40001	MONOPOLE TACH GENERATOR	AHLERS AEROSPACE
108-40003	MONOPOLE TACH GENERATOR	AHLERS AEROSPACE
108-40004	MONOPOLE TACH GENERATOR	AHLERS AEROSPACE
108-40005	MONOPOLE TACH GENERATOR	AHLERS AEROSPACE
108-40006	MONOPOLE TACH GENERATOR	AHLERS AEROSPACE
108-40007	MONOPOLE TACH GENERATOR	AHLERS AEROSPACE
108-40008	MONOPOLE TACH GENERATOR	AHLERS AEROSPACE
108-40009	MONOPOLE TACH GENERATOR	AHLERS AEROSPACE
109-0729-30-3	INDICATOR, DUAL TORQUE	AGUSTA/FAREM
109-40001	PICKUP, MAGNETIC	AHLERS AEROSPACE
109-40002	PICKUP, MAGNETIC	AHLERS AEROSPACE
109-40003	PICKUP, MAGNETIC	AHLERS AEROSPACE
110-40001	TRANSMITTER, FLAP POSITION	AHLERS AEROSPACE
110-40002	TRANSMITTER, FLAP POSITION	AHLERS AEROSPACE
1-1118ZF	TRANSMITTER, HIGH PRESSURE	JAEGER
1-1118ZG	TRANSMITTER, HIGH PRESSURE	JAEGER
111302-5	INDICATOR, HORIZONTAL SITUATION	ASTRONAUTICS
111-40001	SENSOR, RESISTIVE	AHLERS AEROSPACE
112-40001	SENSOR, RESISTIVE	AHLERS AEROSPACE
113-30001	SWITCH ASSEMBLY	AHLERS AEROSPACE
113-30002	SWITCH ASSEMBLY	AHLERS AEROSPACE
114-380006-5	INDICATOR, PROP TACHOMETER	INSCO
114-380007-5	INDICATOR, TACHOMETER	INSCO
114-40001	TRANSMITTER, FUEL QTY	AHLERS AEROSPACE
114-40002	TRANSMITTER, FUEL QTY	AHLERS AEROSPACE
114-40003	TRANSMITTER, FUEL QTY	AHLERS AEROSPACE
114-40004	TRANSMITTER, FUEL QTY	AHLERS AEROSPACE
114-40005	TRANSMITTER, FUEL QTY	AHLERS AEROSPACE
114-40006	TRANSMITTER, FUEL QTY	AHLERS AEROSPACE
114-40007	TRANSMITTER, FUEL QTY	AHLERS AEROSPACE
114-40008	TRANSMITTER, FUEL QTY	AHLERS AEROSPACE
114-40009	TRANSMITTER, FUEL QTY	AHLERS AEROSPACE
114-40010	TRANSMITTER, FUEL QTY	AHLERS AEROSPACE
114-40011	TRANSMITTER, FUEL QTY	AHLERS AEROSPACE
114-40012	TRANSMITTER, FUEL QTY	AHLERS AEROSPACE
114-40013	TRANSMITTER, FUEL QTY	AHLERS AEROSPACE
114-40014	TRANSMITTER, FUEL QTY	AHLERS AEROSPACE
114-40015	TRANSMITTER, FUEL QTY	AHLERS AEROSPACE
114ES270	INDICATOR, DUAL TORQUE	INSCO
114ES288-1	INDICATOR, TRIPLE TACHOMETER	INSCO
115-384012	INDICATOR, OIL TEMPERATURE	INSCO
115-384012-1	INDICATOR, OIL TEMPERATURE	INSCO
115-384012-3	INDICATOR, OIL TEMPERATURE	INSCO
115-40001	TRANSMITTER, FUEL QTY	AHLERS AEROSPACE
115-40002	TRANSMITTER, FUEL QTY	AHLERS AEROSPACE
115-40003	TRANSMITTER, FUEL QTY	AHLERS AEROSPACE
1159SCF216	INDICATOR, DUAL POSITION	INSCO
116-40001	TRANSDUCER	AHLERS AEROSPACE
117-69005-03	INDICATOR, DUAL TORQUE	INSCO
117-902011	INDICATOR, TRIPLE TACHOMETER	INSCO
117-9020111	INDICATOR, TRIPLE TACHOMETER	INSCO
117-902011-1	INDICATOR, TRIPLE TACHOMETER	INSCO
117-94031-01	INDICATOR, TRIPLE TACHOMETER	INSCO
117-94032-01	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
117-94033	INDICATOR, MEASURED GAS TEMPERATURE	INSCO
117-94034-01	INDICATOR, DUAL OIL TEMP/PRESS	INSCO
117-94035-01	INDICATOR, OIL TEMPERATURE	INSCO
117-94035-05	INDICATOR, OIL TEMPERATURE	INSCO
117-94036-01	INDICATOR, DUAL XMSN OIL PRESSURE	INSCO
117-94036-05	INDICATOR, DUAL OIL PRESSURE	INSCO
117-94037	INDICATOR, DUAL FUEL PRESSURE	INSCO
117-94040-01	INDICATOR, DUAL AMMETER	INSCO
117-94041-01	INDICATOR, DUAL DC VOLTMETER	INSCO
117-94042-03	INDICATOR, AIRSPEED	INSCO
117-94051-05	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
117-94051-07	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
117-94053-01	INDICATOR, TRIPLE TACHOMETER	INSCO
117-94053-03	INDICATOR, TRIPLE TACHOMETER	INSCO

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
117-940541	INDICATOR, TRIPLE TACHOMETER	INSCO
117-940541-01	INDICATOR, TRIPLE TACHOMETER	INSCO
117-94055-01	INDICATOR, DUAL DC VOLTMETER	INSCO
117-94056-01	INDICATOR, GAS GENERATOR TACHOMETER	INSCO
117-94056-03	INDICATOR, GAS GENERATOR TACHOMETER	INSCO
117-94058-01	INDICATOR, ENGINE OIL TEMP/PRESS	INSCO
117-94058-03	INDICATOR, ENGINE OIL TEMP/PRESS	INSCO
117-94058-05	INDICATOR, ENGINE OIL TEMP/PRESS	INSCO
117-94059-07	INDICATOR, DUAL AC AMMETER	INSCO
117-94062-01	INDICATOR, HYDRAULIC PRESSURE	INSCO
117-94271	INDICATOR, DUAL XMSN OIL PRESSURE	INSCO
117-94564/945641	SYSTEM, MAST MOMENT	MBB
118-40001	ELEMENT, RESISTIVE	AHLERS AEROSPACE
118-40002	PROBE, THERMOCOUPLE, TYPE K	AHLERS AEROSPACE
119-32-07-001	INDICATOR, TORQUE	INSCO
119-32-07-003	INDICATOR, TACHOMETER	INSCO
119-32-07-004	INDICATOR, TACHOMETER	INSCO
119-32-07-005	INDICATOR, OIL TEMP/PRESS	INSCO
119-32-07-006	INDICATOR, DUAL FUEL QTY	INSCO
119-32-07-007	INDICATOR, VOLTMETER/AMMETER	INSCO
119-32-07-294	INDICATOR, TORQUE	INSCO
119-40001	ACTUATOR, CONTROL SURFACE	AHLERS AEROSPACE
120-IN-0056-5.1	INDICATOR, DUAL HYDRAULIC FLUID QTY	INSCO
120-IN-0056-5.2	INDICATOR, DUAL HYDRAULIC PRESSURE	INSCO
120-IN-0056-5.3	INDICATOR, VOLT/AMMETER	INSCO
120-IN-0056-5.4	INDICATOR, COCKPIT/CABIN TEMPERATURE	INSCO
120-IN-0056-5.5	INDICATOR, EXHAUST GAS TEMPERATURE	INSCO
120-IN-0056-5.6	INDICATOR, TACHOMETER	INSCO
120-IN-0056-5.7	INDICATOR, BATTERY TEMPERATURE	INSCO
1214-06-559	UNIT, MASTER WARNING	AIRSHIP IND.
121-IN-0031	INDICATOR, DUAL OIL PRESSURE	INSCO
121-IN-0033	INDICATOR, TORQUE	INSCO
122Y025	INDICATOR, DUAL TEMP/PRESS	KRATOS
122Y026	INDICATOR, TEMP/PRESS	KRATOS
124.013	INDICATOR, TEMP/PRESS	KRATOS
124.013-4	INDICATOR, TEMP/PRESS	KRATOS
124.014	INDICATOR, TEMP/PRESS	KRATOS
124.014-11	INDICATOR, TEMP/PRESS	KRATOS
124.014-111	INDICATOR, TEMP/PRESS	KRATOS
124.014-121	INDICATOR, TEMP/PRESS	KRATOS
124.014-13	INDICATOR, TEMP/PRESS	KRATOS
124.014-15	INDICATOR, TEMP/PRESS	KRATOS
124.014-17	INDICATOR, TEMP/PRESS	KRATOS
124.014-19	INDICATOR, TEMP/PRESS	KRATOS
124.014-21	INDICATOR, TEMP/PRESS	KRATOS
124.014-23	INDICATOR, TEMP/PRESS	KRATOS
124.014-25	INDICATOR, TEMP/PRESS	KRATOS
124.039	INDICATOR, DUAL AMMETER	KRATOS
124.039-4	INDICATOR, DUAL AMMETER	KRATOS
124.040	INDICATOR, VOLT/AMMETER	KRATOS
124.040-1	INDICATOR, VOLTAGE, AC/DC	KRATOS
124.041-1	INDICATOR, TEMP/PRESS	KRATOS
124.041-3	INDICATOR, TEMP/PRESS	KRATOS
124.043	INDICATOR, TEMP/PRESS	KRATOS
124.044	INDICATOR, FUEL PRESS	KRATOS
124.044-2	INDICATOR, FUEL PRESS	KRATOS
124.044-3	INDICATOR, FUEL PRESS	KRATOS
124.045	INDICATOR, TEMP/PRESS	KRATOS
124.045	INDICATOR, TEMP/PRESS	KRATOS
124.067-SERIES	INDICATOR, ITT	KRATOS
124.1012	INDICATOR, XMSN OIL TEMP/PRESS	KRATOS
124.1012-1	INDICATOR, TEMP/PRESS	KRATOS
124.1012-3	INDICATOR, TEMP/PRESS	KRATOS
124.1012-5	INDICATOR, TEMP/PRESS	KRATOS
124.1012-7	INDICATOR, TEMP/PRESS	KRATOS
124.1013	INDICATOR, ENG OIL TEMP/PRESS	KRATOS
124.1013	INDICATOR, TEMP/PRESS	KRATOS
124.1013-1	INDICATOR, TEMP/PRESS	KRATOS

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
124.1013-2	INDICATOR, TEMP/PRESS	KRATOS
124.1014	INDICATOR, FUEL PRESSURE/LOADMETER	KRATOS
124.1014-1	INDICATOR, FUEL PRESSURE/LOADMETER	KRATOS
124.1014-2	INDICATOR, FUEL PRESSURE/LOADMETER	KRATOS
124.1014-3	INDICATOR, FUEL PRESSURE/LOADMETER	KRATOS
124.1014-4	INDICATOR, FUEL PRESSURE/LOADMETER	KRATOS
124.102	INDICATOR, TORQUE PRESSURE	KRATOS
124.1130	INDICATOR, VOLTMETER	KRATOS
124.1130-2	INDICATOR, VOLTMETER	KRATOS
124.115	INDICATOR, DUAL TEMP/PRESS	KRATOS
124.115-5	INDICATOR, TEMP/PRESS	KRATOS
124.244-1	INDICATOR, VOLT/AMMETER	KRATOS
124.244-11	INDICATOR, VOLT/AMMETER	KRATOS
124.244-2	INDICATOR, VOLT/AMMETER	KRATOS
124.412	INDICATOR, TEMPERATURE	KRATOS
124.439-SERIES	INDICATOR, TEMPERATURE	KRATOS
124.440	INDICATOR, FUEL QUANTITY	KRATOS
124.443-SERIES	INDICATOR, TEMPERATURE	KRATOS
124.480-1	INDICATOR, INTERTURBINE TEMP	KRATOS
124.480-3	INDICATOR, INTERTURBINE TEMP	KRATOS
124.498	INDICATOR, ENG OIL TEMP/PRESS	KRATOS
124.499-SERIES	INDICATOR, TEMPERATURE	KRATOS
124.503-SERIES	INDICATOR, XMSN OIL PRESS	KRATOS
124.511	INDICATOR, TORQUE PRESSURE	KRATOS
124.514	INDICATOR, TEMP/PRESS	KRATOS
124.546	INDICATOR, TEMP/PRESS	KRATOS
124.550-SERIES	INDICATOR, ENG OIL TEMP/PRESS	KRATOS
124.838	INDICATOR, OIL TEMPERATURE	KRATOS
124.845	INDICATOR, OIL TEMPERATURE	KRATOS
124.878	INDICATOR, FUEL QUANTITY	KRATOS
124.924	INDICATOR, TEMP/PRESS	KRATOS
124.9304A	INDICATOR, VOLT/AMMETER	KRATOS
124.933A	INDICATOR, DUAL AMMETER	KRATOS
124.941	INDICATOR, TEMP/PRESS	KRATOS
124.972A	INDICATOR, TEMP/PRESS	KRATOS
124-1007	INDICATOR, TEMP/PRESS	KRATOS
124-1153	INDICATOR, HYDRAULIC PRESSURE	INSCO
124L039-5	INDICATOR, DUAL AMMETER	KRATOS
124L039-6	INDICATOR, DUAL AMMETER	KRATOS
124Q1348	INDICATOR, FUEL QTY	KRATOS
124Q1349	INDICATOR, FUEL QTY	KRATOS
126.306-5	INDICATOR, DUAL TOTALIZING FUEL QTY	KRATOS
126.306-7	INDICATOR, DUAL TOTALIZING FUEL QTY	KRATOS
126.307-5	INDICATOR, DUAL TOTALIZING FUEL QTY	KRATOS
1372-1-101	DETECTOR, RPM LIMIT	AVTECH
1372-1-5	DETECTOR, RPM LIMIT	AVTECH
13DC02A(TYPE776)	INDICATOR, DUAL TORQUE	AGUSTA/FAREM
141-10004-001	PANEL, MASTER CAUTION	AMERICAN LABS
141-10004-004	PANEL, MASTER CAUTION	MASTER SPECIALTIES
141-10004-005	PANEL, MASTER CAUTION	MASTER SPECIALTIES
141-10012-000	PANEL, MASTER CAUTION	AMERICAN LABS
141-10076	PANEL, MASTER CAUTION	AMERICAN LABS
141-10091-000	PANEL, MASTER CAUTION	AMERICAN LABS
1426-5A-A1	INDICATOR, AIR SPEED	EDO-AIRE
1426-5A-B1	INDICATOR, AIR SPEED	EDO-AIRE
145E5004-1	INDICATOR, LIQUID LEVEL	INSCO
145E5004-2	INDICATOR, LIQUID LEVEL	INSCO
145E5008	INDICATOR, ROTOR TACHOMETER	INSCO
145E5015-1	INDICATOR, HYDRAULIC OIL PRESSURE	INSCO
150SG-111Q	STARTER-GENERATOR	APC/UNISON
150SG-114Q	STARTER-GENERATOR	APC/UNISON
150SG-115Q	STARTER-GENERATOR	APC/UNISON
150SG-116Q	STARTER-GENERATOR	APC/UNISON
150SG-117Q	STARTER-GENERATOR	APC/UNISON
150SG-118Q	STARTER-GENERATOR	APC/UNISON
150SG-119Q	STARTER-GENERATOR	APC/UNISON
150SG-120Q	STARTER-GENERATOR	APC/UNISON
150SG-121Q	STARTER-GENERATOR	APC/UNISON

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
150SG-122Q	STARTER-GENERATOR	APC/UNISON
150SG-123Q	STARTER-GENERATOR	APC/UNISON
150SG-124Q	STARTER-GENERATOR	APC/UNISON
150SG-125Q	STARTER-GENERATOR	APC/UNISON
150SG-125Q-2	STARTER-GENERATOR	APC/UNISON
150SG-144Q	STARTER-GENERATOR	APC/UNISON
1523-20683-2	INDICATOR, ENGINE GAS TEMP	PHAOSTRON
152B2	INDICATOR, ENGINE EXHAUST	LEWIS
152B2A	INDICATOR, ENGINE EXHAUST	LEWIS
152B4	INDICATOR, ENGINE EXHAUST	LEWIS
152B8	INDICATOR, ENGINE EXHAUST	LEWIS
152C2C	INDICATOR, TEMPERATURE	LEWIS
152C2D	INDICATOR, TEMPERATURE	LEWIS
152C2E	INDICATOR, TEMPERATURE	LEWIS
152HL2	INDICATOR, TEMPERATURE	LEWIS
152HL2W	INDICATOR, TEMPERATURE	LEWIS
152HL2W3	INDICATOR, TEMPERATURE	LEWIS
160SG-136Q	STARTER-GENERATOR	APC/UNISON
160SG-137Q	STARTER-GENERATOR	APC/UNISON
160SG-137Q-2	STARTER-GENERATOR	APC/UNISON
160SG-139Q	STARTER-GENERATOR	APC/UNISON
160SG-139Q-2	STARTER-GENERATOR	APC/UNISON
160SG-140Q	STARTER-GENERATOR	APC/UNISON
160SG-141Q	STARTER-GENERATOR	APC/UNISON
160SG-142Q	STARTER-GENERATOR	APC/UNISON
162B2	INDICATOR, ELECTRICAL RESISTANCE THERMOMETER	LEWIS
162B3A	INDICATOR, ELECTRICAL RESISTANCE THERMOMETER	LEWIS
162CF705	INDICATOR, TACHOMETER	LEWIS
164A168-1	PUMP, FUEL	TRW/GLOBE
16VF024-1	INDICATOR, FUEL FLOW	GULL AIRBORNE
1702-1001-1	DETECTOR, RPM LIMIT	SATURN
1704-1001-2	DETECTOR, RPM LIMIT	SATURN
1864-1-2	INDICATOR, BATTERY TEMP	AVTECH
20040-0113	INDICATOR, AIRSPEED	AEROSONIC
20040-0145	INDICATOR, AIRSPEED	AEROSONIC
20040-0186	INDICATOR, AIRSPEED	AEROSONIC
200-914-001	INDICATOR, FUEL QTY	GULL AIRBORNE
200-914-002	INDICATOR, FUEL QTY	GULL AIRBORNE
200SGL-111Q	STARTER-GENERATOR	APC/UNISON
200SGL-111Q-2	STARTER-GENERATOR	APC/UNISON
200SGL-111Q-3	STARTER-GENERATOR	APC/UNISON
200SGL-112Q	STARTER-GENERATOR	APC/UNISON
200SGL-114Q	STARTER-GENERATOR	APC/UNISON
200SGL-115Q	STARTER-GENERATOR	APC/UNISON
200SGL-115Q-2	STARTER-GENERATOR	APC/UNISON
200SGL-117Q	STARTER-GENERATOR	APC/UNISON
200SGL-118Q	STARTER-GENERATOR	APC/UNISON
200SGL-119Q	STARTER-GENERATOR	APC/UNISON
200SGL-119Q-2	STARTER-GENERATOR	APC/UNISON
200SGL-120Q	STARTER-GENERATOR	APC/UNISON
200SGL-121Q	STARTER-GENERATOR	APC/UNISON
200SGL-124Q	STARTER-GENERATOR	APC/UNISON
200SGL-129Q	STARTER-GENERATOR	APC/UNISON
200SGL-129Q(1)	STARTER-GENERATOR	APC/UNISON
200SGL-129Q(4)	STARTER-GENERATOR	APC/UNISON
200SGL-129Q(5)	STARTER-GENERATOR	APC/UNISON
200SGL-129Q(8)	STARTER-GENERATOR	APC/UNISON
200SGL-130Q	STARTER-GENERATOR	APC/UNISON
200SGL-132Q	STARTER-GENERATOR	APC/UNISON
200SGL-142Q	STARTER-GENERATOR	APC/UNISON
200SGL-144Q	STARTER-GENERATOR	APC/UNISON
200SGL-145Q	STARTER-GENERATOR	APC/UNISON
200SGL-147Q	STARTER-GENERATOR	APC/UNISON
204-075-705-2 thru -73	MASTER CAUTION PANEL	MSC PRODUCTS/EATON
204-075-705-39	PANEL, MASTER CAUTION	GRIMES
204-075-705-41	PANEL, MASTER CAUTION	GRIMES
204-075-705-43	PANEL, MASTER CAUTION	GRIMES
204-075-705-45	PANEL, MASTER CAUTION	GRIMES

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
204-075-705-47	PANEL, MASTER CAUTION	GRIMES
204-075-705-49	PANEL, MASTER CAUTION	GRIMES
204-075-705-5	PANEL, MASTER CAUTION	GRIMES
204-075-705-51	PANEL, MASTER CAUTION	GRIMES
204-075-705-53	PANEL, MASTER CAUTION	GRIMES
204-075-705-55	PANEL, MASTER CAUTION	GRIMES
204-075-705-57	PANEL, MASTER CAUTION	GRIMES
204-075-705-59	PANEL, MASTER CAUTION	GRIMES
204-075-705-61	PANEL, MASTER CAUTION	GRIMES
204-075-705-63	PANEL, MASTER CAUTION	GRIMES
204-075-705-65	PANEL, MASTER CAUTION	GRIMES
204-075-705-69	PANEL, MASTER CAUTION	MASTER SPECIALTIES
204-075-705-7	PANEL, MASTER CAUTION	AMERICAN LABS
204-075-705-71	PANEL, MASTER CAUTION	MASTER SPECIALTIES
204-075-705-73	PANEL, MASTER CAUTION	GRIMES
204-075-705-75	PANEL, MASTER CAUTION	GRIMES
204-075-705-77	PANEL, MASTER CAUTION	GRIMES
204-075-705-79	PANEL, MASTER CAUTION	GRIMES
204-075-705-81	PANEL, MASTER CAUTION	GRIMES
204-075-705-83	PANEL, MASTER CAUTION	GRIMES
204-075-705-9	PANEL, MASTER CAUTION	GRIMES
204-1A	INDICATOR, EXHAUST GAS TEMP	ALCOR
204-234-021	INDICATOR, DUAL HYDRAULIC PRESSURE	INSCO
204-304-018	INDICATOR, ENGINE OIL TEMP/PRESS	INSCO
204-905-002	INDICATOR, FAN SPEED	GULL AIRBORNE
204-906-002	INDICATOR, INTERTURBINE TEMP	GULL AIRBORNE
205-060-606-003	PUMP, FUEL	TRW/GLOBE
205-070-243-1	INDICATOR, TACHOMETER	INSCO
205-070-283-3	INDICATOR, TACHOMETER	INSCO
205-075-170-001	INDICATOR, TORQUE PRESSURE	EDISON
205-075-388-1	INDICATOR, RPM LIMIT WARNING	SATURN
205-1A	INDICATOR, EXHAUST GAS TEMP	ALCOR
205-375-002-101	INDICATOR, ENGINE GAS TEMP	TRANSICOIL
205-375-002-103	INDICATOR, ENGINE GAS TEMP	PHAOSTRON
205-375-003-101	INDICATOR, TORQUE PRESSURE	TRANSICOIL
205-375-003-103	INDICATOR, TORQUE PRESSURE	PHAOSTRON
205-375-004-101	INDICATOR, TEMP/PRESS	INSCO
205-375-004-103	INDICATOR, TEMP/PRESS	PHAOSTRON
205-375-005-101	INDICATOR, TEMP/PRESS	INSCO
206-063-633-003	INDICATOR, FUEL QUANTITY	INSCO
206-063-633-1	INDICATOR, FUEL QTY	GULL AIRBORNE
206-063-633-101	INDICATOR, FUEL QTY	GULL AIRBORNE
206-063-633-103	INDICATOR, FUEL QTY	Ragen Data
206-063-633-3	INDICATOR, FUEL QTY	INSCO
206-063-656-1	TRANSMITTER, FUEL QTY	GULL AIRBORNE
206-063-656-3	TRANSMITTER, FUEL QTY	INSCO
206-063-656-5	TRANSMITTER, FUEL QTY	INSCO
206-064-635-101	TRANSMITTER, FUEL QTY	GULL AIRBORNE
206-064-635-103	TRANSMITTER, FUEL QTY	RAGEN DATA
206-070-153-1	INDICATOR, TURBINE TEMP	LEWIS
206-070-241-1	INDICATOR, DUAL TACHOMETER % RPM	INSCO
206-070-242-3	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
206-070-243-001	INDICATOR, TACHOMETER, GAS PRODUCER	INSCO
206-070-243-003	INDICATOR, TACHOMETER, GAS PRODUCER	INSCO
206-070-264-5	INDICATOR, AIRSPEED	INSCO
206-070-265-001	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	INSCO
206-070-265-003	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	INSCO
206-070-265-005	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	INSCO
206-070-265-007	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	GENERAL ELECTRIC
206-070-265-009	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	INSCO
206-070-265-011	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	INSCO
206-070-265-101	INDICATOR, DUAL TACHOMETER	INSCO
206-070-265-7	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	INSCO
206-070-266-001	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
206-070-266-003	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
206-070-266-005	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
206-070-266-007	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
206-070-266-009	INDICATOR, GAS PRODUCER TACHOMETER	INSCO

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
206-070-266-011	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
206-070-266-013	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
206-070-266-1	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	INSCO
206-070-266-11	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	INSCO
206-070-266-13	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	INSCO
206-070-266-3	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	INSCO
206-070-266-5	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	INSCO
206-070-266-7	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	INSCO
206-070-266-9	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	INSCO
206-070-267-001	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
206-070-267-003	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
206-070-267-005	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
206-070-267-007	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
206-070-267-009	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
206-070-267-011	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
206-070-267-013	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
206-070-267-1	INDICATOR, TEMPERATURE	SMS INSTRUMENTS
206-070-267-11	INDICATOR, TEMPERATURE	LEWIS
206-070-267-13	INDICATOR, TEMPERATURE	INSCO
206-070-267-15	INDICATOR, TEMPERATURE	LEWIS
206-070-267-3	INDICATOR, TEMPERATURE	LEWIS
206-070-267-5	INDICATOR, TEMPERATURE	LEWIS
206-070-267-7	INDICATOR, TEMPERATURE	LEWIS
206-070-267-9	INDICATOR, TEMPERATURE	LEWIS
206-070-268-001	INDICATOR, TORQUE	INSCO
206-070-268-005	INDICATOR, TORQUE	INSCO
206-070-268-007	INDICATOR, TORQUE	INSCO
206-070-268-009	INDICATOR, TORQUE	INSCO
206-070-268-011	INDICATOR, TORQUE	INSCO
206-070-268-013	INDICATOR, TORQUE	INSCO
206-070-268-11	INDICATOR, PRESSURE, DIRECT READING	INSCO
206-070-268-5	INDICATOR, PRESSURE, DIRECT READING	INSCO
206-070-269-1	CLUSTER, INSTRUMENT	INSCO
206-070-269-11	INDICATOR, TRANSMISSION OIL PRESSURE	INSCO
206-070-269-13	INDICATOR, LOADMETER	INSCO
206-070-269-15	INDICATOR, FUEL QTY	INSCO
206-070-269-17	CLUSTER, INSTRUMENT	INSCO
206-070-269-19	CLUSTER, INSTRUMENT	INSCO
206-070-269-21	CLUSTER, INSTRUMENT	INSCO
206-070-269-23	CLUSTER, INSTRUMENT	INSCO
206-070-269-25	INDICATOR, FUEL PRESS	INSCO
206-070-269-27	INDICATOR, ENGINE OIL PRESSURE	INSCO
206-070-269-3	INDICATOR, ENGINE OIL PRESSURE	INSCO
206-070-269-5	INDICATOR, ENGINE OIL PRESSURE	INSCO
206-070-269-9	INDICATOR, TRANSMISSION OIL TEMPERATURE	INSCO
206-070-275-SERIES	CLOCK	INSCO
206-070-278-001	INDICATOR, DUAL TACHOMETER	INSCO
206-070-278-005	INDICATOR, IVSI	INSCO
206-070-282-003	INDICATOR, AMMETER	INSCO
206-070-289-003	INDICATOR, OIL TEMP/PRESS	INSCO
206-070-299-001	INDICATOR, TORQUE	INSCO
206-070-307-003	INDICATOR, OIL TEMP/PRESS	INSCO
206-070-307-2A	INDICATOR, ENGINE OIL PRESSURE	INST. TECH
206-070-307-4A	INDICATOR, FUEL QTY	INST. TECH
206-070-307-A	INDICATOR, ENGINE OIL TEMPERATURE	INST. TECH
206-070-351-001	INDICATOR, OIL TEMP/PRESS	INSCO
206-070-399-001	INDICATOR, TORQUE	INSCO
206-070-399-003	INDICATOR, TORQUE	INSCO
206-070-473-001	CLUSTER, INSTRUMENT	INSCO
206-070-473-003	CLUSTER, INSTRUMENT	INSCO
206-070-473-005	CLUSTER, INSTRUMENT	INSCO
206-070-473-007	CLUSTER, INSTRUMENT	INSCO
206-070-473-1	CLUSTER, INSTRUMENT	INSCO
206-070-556-001	INDICATOR, OIL TEMP/PRESS	INSCO
206-070-675-SERIES	INDICATOR, TORQUE	INSCO
206-070-989-001	INDICATOR, % TORQUE	INSCO
206-070-996-001	INDICATOR, VOLTMETER	INSCO
206-070-997-003	INDICATOR, VOLTMETER	INSCO

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
206-075-185-001	INDICATOR, TORQUE	INSCO
206-075-185-003	INDICATOR, TORQUE	INSCO
206-075-185-005	INDICATOR, TORQUE	INSCO
206-075-185-007	INDICATOR, TORQUE	INSCO
206-075-185-1	INDICATOR, PRESSURE, DIRECT READING	INSCO
206-075-185-101	INDICATOR, TORQUE	INSCO
206-075-185-103	INDICATOR, TORQUE	INSCO
206-075-185-105	INDICATOR, TORQUE	INSCO
206-075-185-3	INDICATOR, PRESSURE, DIRECT READING	INSCO
206-075-185-5	INDICATOR, PRESSURE, DIRECT READING	INSCO
206-075-185-7	INDICATOR, PRESSURE, DIRECT READING	INSCO
206-075-186-001	INDICATOR, LOADMETER/FUEL PRESS	INSCO
206-075-186-003	INDICATOR, LOADMETER/FUEL PRESS	INSCO
206-075-186-005	INDICATOR, FUEL PRESSURE/LOADMETER	INSCO
206-075-186-119	INDICATOR, FUEL PRESSURE/LOADMETER	INSCO
206-075-186-3	INDICATOR, DUAL LOAD/FUEL PRESS	INSCO
206-075-186-5	INDICATOR, DUAL LOAD/FUEL PRESS	INSCO
206-075-187-001	INDICATOR, ENGINE OIL TEMP/PRESS	INSCO
206-075-187-003	INDICATOR, ENGINE OIL TEMP/PRESS	INSCO
206-075-187-1	INDICATOR, TEMP/PRESS	INSCO
206-075-187-3	INDICATOR, TEMP/PRESS	INSCO
206-075-188-001	INDICATOR, XMSN OIL TEMP/PRESS	INSCO
206-075-188-003	INDICATOR, XMSN OIL TEMP/PRESS	INSCO
206-075-188-005	INDICATOR, XMSN OIL TEMP/PRESS	INSCO
206-075-188-1	INDICATOR, TEMP/PRESS	INSCO
206-075-188-3	INDICATOR, TEMP/PRESS	INSCO
206-075-188-5	INDICATOR, TEMP/PRESS	INSCO
206-075-189-001	INDICATOR, FUEL QTY	INSCO
206-075-189-003	INDICATOR, FUEL QTY	INSCO
206-075-189-101	INDICATOR, FUEL QTY	INSCO
206-075-190-001	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
206-075-190-003	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
206-075-190-005	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
206-075-190-007	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
206-075-190-1	INDICATOR, TEMPERATURE	INSCO
206-075-190-7	INDICATOR, TEMPERATURE	INSCO
206-075-545-1	SENSOR, RPM	APPLIED ELEC. TECH
206-075-545-3	SENSOR, RPM	APPLIED ELEC. TECH
206-075-545-5	SENSOR, RPM	APPLIED ELEC. TECH
206-075-545-7	SENSOR, RPM	APPLIED ELEC. TECH
206-075-545-9	SENSOR, RPM	APPLIED ELEC. TECH
206-075-545-9	SENSOR, RPM	APPLIED ELEC. TECH
206-075-676-001	INDICATOR, LOADMETER/FUEL PRESS	INSCO
206-075-676-003	INDICATOR, LOADMETER/FUEL PRESS	INSCO
206-075-676-1	INDICATOR, FUEL PRESSURE/LOADMETER	INSCO
206-075-676-101	INDICATOR, LOADMETER/FUEL PRESS	INSCO
206-075-676-103	INDICATOR, FUEL PRESSURE/LOADMETER	KRATOS
206-075-676-105	INDICATOR, FUEL PRESSURE/LOADMETER	KRATOS
206-075-676-107	INDICATOR, FUEL PRESSURE/LOADMETER	KRATOS
206-075-676-109	INDICATOR, FUEL PRESSURE/LOADMETER	KRATOS
206-075-676-111	INDICATOR, FUEL PRESSURE/LOADMETER	KRATOS
206-075-676-113	INDICATOR, LOADMETER/FUEL PRESS	INSCO
206-075-676-115	INDICATOR, FUEL PRESSURE/LOADMETER	INSCO
206-075-676-115	INDICATOR, LOADMETER/FUEL PRESS	INSCO
206-075-676-117	INDICATOR, FUEL PRESSURE/LOADMETER	INSCO
206-075-676-119	INDICATOR, FUEL PRESSURE/LOADMETER	INSCO
206-075-676-3	INDICATOR, FUEL PRESSURE/LOADMETER	INSCO
206-075-677-101	INDICATOR, TEMP/PRESS	KRATOS
206-075-677-103	INDICATOR, TEMP/PRESS	KRATOS
206-075-677-105	INDICATOR, TEMP/PRESS	KRATOS
206-075-678-101	INDICATOR, TEMP/PRESS	KRATOS
206-075-678-103	INDICATOR, TEMP/PRESS	KRATOS
206-075-678-105	INDICATOR, TEMP/PRESS	KRATOS
206-075-678-107	INDICATOR, TEMP/PRESS	KRATOS
206-075-679-001	INDICATOR, FUEL QTY	INSCO
206-075-679-003	INDICATOR, FUEL QTY	INSCO
206-075-680-001	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
206-075-680-003	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
206-075-680-005	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
206-075-680-101	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	AMETEK
206-075-680-103	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
206-075-680-105	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
206-075-680-107	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
206-075-681-1	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	GENERAL ELECTRIC
206-075-681-101	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	GENERAL ELECTRIC
206-075-681-103	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	INSCO
206-075-681-105	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	
206-075-681-107	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	BENDIX
206-075-681-109	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	BENDIX
206-075-681-113	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	BENDIX
206-075-681-115	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	VDO
206-075-681-117	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	VDO
206-075-681-119	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	VDO
206-075-681-121	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	VDO
206-075-681-123	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	VDO
206-075-681-3	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	GENERAL ELECTRIC
206-075-682-001	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
206-075-682-1	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	GENERAL ELECTRIC
206-075-682-101	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	BENDIX
206-075-682-103	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	GENERAL ELECTRIC
206-075-682-103	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
206-075-682-105	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	VDO
206-075-682-107	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
206-075-682-109	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
206-075-683-001	INDICATOR, FUEL QTY	INSCO
206-075-705-001	INDICATOR, ENGINE OIL TEMP/PRESS	INSCO
206-075-706-003	INDICATOR, XMSN OIL PRESSURE	INSCO
206-075-706-3	INDICATOR, PRESSURE	INSCO
206-075-707-001	INDICATOR, FUEL QTY	INSCO
206-075-707-1	INDICATOR, FUEL QTY	INSCO
206-075-710-003	INDICATOR, DC AMMETER	INSCO
206-075-711-001	INDICATOR, FUEL QTY	INSCO
206-075-711-003	INDICATOR, FUEL QTY	INSCO
206-075-713-001	INDICATOR, DUEL TACHOMETER	INSCO
206-075-713-101	INDICATOR, DUEL TACHOMETER	INSCO
206-075-715-003	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
206-075-739-101	INDICATOR, TORQUE	INSCO
206-075-739-103	INDICATOR, TORQUE	INSCO
206-075-739-105	INDICATOR, TORQUE	INSCO
206-075-739-107	INDICATOR, TORQUE	INSCO
206-075-739-109	INDICATOR, TORQUE	INSCO
206-075-739-111	INDICATOR, TORQUE	INSCO
206-075-739-113	INDICATOR, TURBINE OUTLET TEMP	AMETEK
206-075-739-115	INDICATOR, PRESSURE, DIRECT READING	AMETEK
206-075-739-117	INDICATOR, PRESSURE, DIRECT READING	
206-075-739-119	INDICATOR, PRESSURE, DIRECT READING	
206-075-739-121	INDICATOR, PRESSURE, DIRECT READING	
206-075-739-123	INDICATOR, PRESSURE, DIRECT READING	
206-075-739-125	INDICATOR, PRESSURE, DIRECT READING	
206-075-739-125W	INDICATOR, PRESSURE, DIRECT READING	
206-075-739-127	INDICATOR, PRESSURE, DIRECT READING	
206-075-739-129	INDICATOR, PRESSURE, DIRECT READING	
206-075-739-131	INDICATOR, PRESSURE, DIRECT READING	
206-075-739-133	INDICATOR, PRESSURE, DIRECT READING	
206-075-739-135	INDICATOR, PRESSURE, DIRECT READING	
206-075-739-137	INDICATOR, PRESSURE, DIRECT READING	
206-075-740-001	INDICATOR, FUEL QTY	INSCO
206-075-740-101	INDICATOR, FUEL QTY	INSCO
206-075-740-103	INDICATOR, FUEL QTY	INSCO
206-075-740-105	INDICATOR, FUEL QTY	INSCO
206-075-740-107	INDICATOR, FUEL QTY	INSCO
206-075-740-109	INDICATOR, FUEL QTY	INSCO
206-075-740-111	INDICATOR, FUEL QTY	INSCO
206-075-740-113	INDICATOR, FUEL QTY	KRATOS
206-075-740-115	INDICATOR, FUEL QTY	KRATOS
2060A01	PUMP, FUEL, ELECTRIC	INTERTECHNIQUE

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
2060A12	PUMP, FUEL, ELECTRIC	INTERTECHNIQUE
2060B	PUMP, FUEL, ELECTRIC	INTERTECHNIQUE
2060B06	PUMP, FUEL, ELECTRIC	INTERTECHNIQUE
206114	INDICATOR, TEMPERATURE	SMS INSTRUMENTS
206-1A	INDICATOR, EXHAUST GAS TEMP	ALCOR
206-351-00001	7 MODULE CLUSTER	INSCO
206-351-00001-1	7 MODULE CLUSTER	INSCO
206-351-00003	INDICATOR, XMSN OIL TEMPERATURE	INSCO
206-351-0001	CLUSTER, INSTRUMENT	INSCO
206-351-0001-1	CLUSTER, INSTRUMENT	INSCO
206-351-0002	INDICATOR, LOADMETER	INSCO
206-351-0003	INDICATOR, XMSN OIL TEMPERATURE	INSCO
206-351-0004	INDICATOR, ENGINE OIL TEMPERATURE	INSCO
206-351-0005	INDICATOR, XMSN OIL PRESSURE	INSCO
206-351-0006	INDICATOR, ENGINE OIL PRESSURE	INSCO
206-351-0006-1	INDICATOR, ENGINE OIL PRESSURE	INSCO
206-351-0007	INDICATOR, FUEL QTY	INSCO
206-351-0008	INDICATOR, FUEL PRESSURE	INSCO
206-351-0008-1	MODULE, FUEL PRESSURE	INSCO
206-375-005-101	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
206-375-005-103	INDICATOR, TEMPERATURE	AMETEK
206-375-006-101	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
206-375-007-101	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
206-375-007-103	INDICATOR, TEMPERATURE	AMETEK
206-375-009-101	INDICATOR, TEMPERATURE	AMETEK
206-375-010-101	INDICATOR, DUAL TACHOMETER	INSCO
2070C01	PUMP, FUEL BOOST	INTERTECHNIQUE
2070C01	PUMP, FUEL BOOST	INTERTECHNIQUE
2070C11	PUMP, FUEL BOOST	INTERTECHNIQUE
2070C11	PUMP, FUEL BOOST	INTERTECHNIQUE
209-070-262-001	INDICATOR, ENGINE OIL TEMP/PRESS	INSCO
209-070-262-003	INDICATOR, ENGINE OIL TEMP/PRESS	INSCO
209-070-262-007	INDICATOR, ENGINE OIL TEMP/PRESS	INSCO
209-070-262-009	INDICATOR, ENGINE OIL TEMP/PRESS	INSCO
209-070-262-1	INDICATOR, TEMP/PRESS	INSCO
209-070-262-101	INDICATOR, ENGINE OIL TEMP/PRESS	INSCO
209-070-262-103	INDICATOR, ENGINE OIL TEMP/PRESS	INSCO
209-070-262-105	INDICATOR, ENGINE OIL TEMP/PRESS	INSCO
209-070-262-107	INDICATOR, ENGINE OIL TEMP/PRESS	INSCO
209-070-262-109	INDICATOR, TEMP/PRESS	KRATOS
209-070-262-111	INDICATOR, TEMP/PRESS	PHAOSTRON
209-070-262-113	INDICATOR, TEMP/PRESS	INSCO
209-070-262-115	INDICATOR, ENGINE OIL TEMP/PRESS	INSCO
209-070-262-3	INDICATOR, TEMP/PRESS	KRATOS
209-070-262-9	INDICATOR, TEMP/PRESS	KRATOS
209-070-263-009	INDICATOR, AC/DC VOLTMETER	INSCO
209-070-263-1	INDICATOR, VOLT/AMMETER	KRATOS
209-070-263-101	INDICATOR, AC/DC VOLTMETER	INSCO
209-070-263-103	INDICATOR, AC/DC VOLTMETER	INSCO
209-070-263-11	INDICATOR, VOLT/AMMETER	KRATOS
209-070-263-3	INDICATOR, VOLT/AMMETER	KRATOS
209-070-263-7	INDICATOR, VOLT/AMMETER	KRATOS
209-070-263-9	INDICATOR, VOLT/AMMETER	KRATOS
209-070-264-1	INDICATOR, DUAL AMMETER	KRATOS
209-070-264-101	INDICATOR, DUAL AMMETER	KRATOS
209-070-264-103	INDICATOR, DUAL AMMETER	KRATOS
209-070-264-105	INDICATOR, DUAL AMMETER	KRATOS
209-070-264-109	INDICATOR, DUAL AMMETER	INSCO
209-070-264-3	INDICATOR, DUAL AMMETER	KRATOS
209-070-264-3	INDICATOR, DUAL AMMETER	INSCO
209-070-275-001	INDICATOR, FUEL PRESSURE	INSCO
209-075-326-1M	DETECTOR, RPM LIMIT	LELAND
209-075-651-101	INDICATOR, TORQUE	BENDIX
209-075-652-001	INDICATOR, GAS PRODUCER	INSCO
209-075-652-003	INDICATOR, GAS PRODUCER	INSCO
209-075-652-005	INDICATOR, GAS PRODUCER	INSCO
209-075-653-001	INDICATOR, TORQUE	INSCO
209-075-653-007	INDICATOR, TORQUE	BENDIX

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
209-075-654-001	INDICATOR, TORQUE	INSCO
209-075-654-005	INDICATOR, TORQUE	INSCO
209-075-655-001	INDICATOR, DUAL TACHOMETER	INSCO
209-075-656-001	INDICATOR, ENGINE OIL TEMP/PRESS	INSCO
209-075-658-001	INDICATOR, XMSN OIL TEMP/PRESS	INSCO
209-075-658-1	INDICATOR, TEMP/PRESS	INSCO
209-075-659-001	INDICATOR, DC VOLTMETER/AMMETER	INSCO
209-075-659-101	INDICATOR, VOLTMETER/AMMETER	INSCO
209-075-722-003	INDICATOR, TRIPLE TACHOMETER	INSCO
209-075-722-101	INDICATOR, TRIPLE TACHOMETER	INSCO
209-075-728-001	INDICATOR, DUAL HYDRAULIC PRESSURE	INSCO
2100-1003	TRANSMITTER, FLAP POSITION	INSCO
210-1A	INDICATOR, EXHAUST GAS TEMP	ALCOR
212-067-119	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
212-070-108-005	INDICATOR, TRIPLE TACHOMETER	INSCO
212-070-108-007	INDICATOR, TRIPLE TACHOMETER	INSCO
212-070-108-1	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	GENERAL ELECTRIC
212-070-108-101	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	HONEYWELL
212-070-108-101	INDICATOR, TRIPLE TACHOMETER	INSCO
212-070-108-103	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	INSCO
212-070-108-11	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	GENERAL ELECTRIC
212-070-108-3	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	GENERAL ELECTRIC
212-070-108-5	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	GENERAL ELECTRIC
212-070-108-7	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	GENERAL ELECTRIC
212-070-108-9	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	GENERAL ELECTRIC
212-070-116-003	INDICATOR, TEMP/PRESS	INSCO
212-070-116-009	INDICATOR, TEMP/PRESS	INSCO
212-070-116-023	INDICATOR, TEMP/PRESS	INSCO
212-070-116-025	INDICATOR, TEMP/PRESS	INSCO
212-070-116-1	INDICATOR, TEMP/PRESS	KRATOS
212-070-116-105	INDICATOR, TEMP/PRESS	INSCO
212-070-116-11	INDICATOR, TEMP/PRESS	KRATOS
212-070-116-13	INDICATOR, TEMP/PRESS	KRATOS
212-070-116-15	INDICATOR, TEMP/PRESS	KRATOS
212-070-116-17	INDICATOR, TEMP/PRESS	KRATOS
212-070-116-19	INDICATOR, TEMP/PRESS	KRATOS
212-070-116-21	INDICATOR, TEMP/PRESS	KRATOS
212-070-116-3	INDICATOR, TEMP/PRESS	KRATOS
212-070-116-5	INDICATOR, TEMP/PRESS	KRATOS
212-070-116-7	INDICATOR, TEMP/PRESS	KRATOS
212-070-116-9	INDICATOR, TEMP/PRESS	KRATOS
212-070-241	INDICATOR, HYDRAULIC OIL TEMP	INSCO
212-070-242-003	INDICATOR, HYDRAULIC OIL PRESSURE	INSCO
212-070-504-001	INDICATOR, HYDRAULIC OIL PRESSURE	INSCO
212-070-504-003	INDICATOR, HYDRAULIC OIL PRESSURE	INSCO
212-075-036-101	INDICATOR, TEMP/PRESS	KRATOS
212-075-036-103	INDICATOR, TEMP/PRESS	KRATOS
212-075-036-105	INDICATOR, TEMP/PRESS	INSCO
212-075-036-105	INDICATOR, DUAL TEMPERATURE/PRESSURE	INSCO
212-075-036-107	INDICATOR, TEMP/PRESS	KRATOS
212-075-036-109	INDICATOR, TEMP/PRESS	KRATOS
212-075-037-101	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	BENDIX
212-075-037-103	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	BENDIX
212-075-037-105	INDICATOR, TACHOMETER % RPM	INSCO
212-075-037-107	INDICATOR, TACHOMETER % RPM	INSCO
212-075-037-109	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	VDO
212-075-037-111	INDICATOR, TACHOMETER % RPM	INSCO
212-075-037-113	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	VDO
212-075-037-115	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	VDO
212-075-037-117	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	VDO
212-075-037-119	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	VDO
212-075-067-101	INDICATOR, TEMPERATURE	BENDIX
212-075-067-105	INDICATOR, TEMPERATURE	BENDIX
212-075-067-107	INDICATOR, TEMPERATURE	BENDIX
212-075-067-109	INDICATOR, TEMPERATURE	AMETEK
212-075-067-113	INDICATOR, TEMPERATURE	AMETEK
212-075-067-115	INDICATOR, TURBINE OUTLET TEMP	AMETEK
212-075-067-117	INDICATOR, TURBINE OUTLET TEMP	AMETEK

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
212-075-067-117	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
212-075-067-119	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
212-075-067-123	INDICATOR, TURBINE OUTLET TEMP	AMETEK
212-075-067-125	INDICATOR, TEMPERATURE	AMETEK
212-075-067-127	INDICATOR, TEMPERATURE	AMETEK
214-00121	INDICATOR, OIL PRESSURE	EDISON
214-070-160-021	INDICATOR, TORQUE	INSCO
214-075-239-001	INDICATOR, TORQUE	INSCO
214-075-239-003	INDICATOR, TORQUE	INSCO
214-075-239-005	INDICATOR, TORQUE	INSCO
214-075-239-007	INDICATOR, TORQUE	INSCO
214-075-239-009	INDICATOR, TORQUE	INSCO
214-075-239-011	INDICATOR, TORQUE	INSCO
214-075-239-1	INDICATOR, TORQUE PRESSURE	INSCO
214-075-239-11	INDICATOR, TORQUE PRESSURE	INSCO
214-075-239-3	INDICATOR, TORQUE PRESSURE	INSCO
214-075-239-5	INDICATOR, TORQUE PRESSURE	INSCO
214-075-239-7	INDICATOR, TORQUE PRESSURE	INSCO
214-075-239-9	INDICATOR, TORQUE PRESSURE	INSCO
214-075-253-001	INDICATOR, FUEL PRESSURE	KRATOS
214-075-302-11	INDICATOR, TEMP/PRESS	INSCO
214-10001	INDICATOR, FUEL FLOW	AHLERS AEROSPACE
214-175-257-105	INDICATOR, DUAL TOTALIZING FUEL QTY	KRATOS
214-175-257-107	INDICATOR, FUEL QTY	VDO
214-175-257-109	INDICATOR, FUEL QTY	VDO
214-175-258-101	INDICATOR, VOLT	INSCO
214-175-258-103	INDICATOR, VOLT	INSCO
214-175-258-105	INDICATOR, VOLT	KRATOS
214-175-258-107	INDICATOR, VOLT	KRATOS
2146-5	INDICATOR, ENGINE POWER OUT	AUTRONICS
217-00111	INDICATOR, OIL PRESSURE	EDISON
217-00131	INDICATOR, OIL PRESSURE	EDISON
217-00141	INDICATOR, OIL PRESSURE	EDISON
217-00151	INDICATOR, OIL PRESSURE	EDISON
217-00161	INDICATOR, OIL PRESSURE	EDISON
217-00171	INDICATOR, OIL PRESSURE	EDISON
217-00181	INDICATOR, OIL PRESSURE	EDISON
217-00211	INDICATOR, OIL PRESSURE	EDISON
217-00221	INDICATOR, OIL PRESSURE	EDISON
217-00231	INDICATOR, OIL PRESSURE	EDISON
217-00241	INDICATOR, OIL PRESSURE	EDISON
217-00261	INDICATOR, OIL PRESSURE	EDISON
217-00271	INDICATOR, OIL PRESSURE	EDISON
217-00281	INDICATOR, OIL PRESSURE	EDISON
217-02161	INDICATOR, TORQUE	INSCO
217-03111	INDICATOR, DE-ICE PRESSURE	INSCO
217-04111	INDICATOR, FUEL PRESSURE	INSCO
217-07151	INDICATOR, OIL PRESSURE	INSCO
217-11261	INDICATOR, TORQUE PRESSURE	EDISON
217A100A	INDICATOR, OIL PRESSURE	EDISON
2200-10	INDICATOR, ENGINE POWER OUT	AUTRONICS
2200-3	INDICATOR, ENGINE POWER OUT	AUTRONICS
2200-7	INDICATOR, ENGINE POWER OUT	AUTRONICS
2203-1002	UNIT, RPM WARNING	INSCO
2203-1003	UNIT, RPM WARNING	INSCO
221-901-001	INDICATOR, FUEL QTY	INSCO
222-375-016-101	INDICATOR, TEMP/PRESS	KRATOS
222-375-016-101	INDICATOR, DUAL HYDRAULIC OIL PRESSURE	INSCO
222-375-017-101	INDICATOR, XMSN OIL TEMP/PRESS	INSCO
222-375-022-101	INDICATOR, TACHOMETER	BENDIX
222-375-022-103	INDICATOR, TACHOMETER	BENDIX
222-375-022-105	INDICATOR, TACHOMETER	BENDIX
222-375-022-105	INDICATOR, TACHOMETER	INSCO
222-375-022-111	INDICATOR, TACHOMETER	BENDIX
222-375-023-107	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
222-375-064-101	INDICATOR, TOTALIZING FUEL QTY	BENDIX
222-375-064-103	INDICATOR, TOTALIZING FUEL QTY	BENDIX
222-375-064-105	INDICATOR, TOTALIZING FUEL QTY	KRATOS

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
222-375-064-107	INDICATOR, TOTALIZING FUEL QTY	KRATOS
22-304-04	INDICATOR, TURBINE OUTLET TEMP	EDO-AIRE
2245-1	CONTROL, DIMMER	AUTRONICS
2245-5	CONTROL, DIMMER	AUTRONICS
224-902-006	INDICATOR, N1	GULL AIRBORNE
224-902-007	INDICATOR, N2	GULL AIRBORNE
224-911-006	INDICATOR, INTERTURBINE TEMPERATURE	GULL AIRBORNE
2290-3	INDICATOR, ENGINE OUT WARNING	MDHC
23032-010	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23032-011	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23032-018	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23032-020	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23032-022	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23032-025	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23032-026	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23032-027	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23032-028	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23032-042	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23032-043	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23032-044	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23032-045	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23032-046	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23032-047	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23032-048	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23032-049	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23032-051	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23032-054	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23032-062	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23046-001	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23046-007	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23046-007M	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23046-009	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23046-017	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23046-019	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23046-020	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23046-028	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23065-013	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23065-013-1	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23065-015	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23065-015-1	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23065-015-2	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23065-015-3	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23065-018	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23065-018-1	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23065-018-2	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23065-020	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23069-013	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23069-013-1	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23069-015	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23069-015-1	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23069-016	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23069-016-1	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23069-020	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23069-020-1	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23069-021	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23076-001	STARTER-GENERATOR	GOODRICH AEROSPACE
23076-001-1	STARTER-GENERATOR	GOODRICH AEROSPACE
23076-004	STARTER-GENERATOR	GOODRICH AEROSPACE
23076-004-1	STARTER-GENERATOR	GOODRICH AEROSPACE
23076-005	STARTER-GENERATOR	GOODRICH AEROSPACE
23079-000	STARTER-GENERATOR	GOODRICH AEROSPACE
23079-000-1	STARTER-GENERATOR	GOODRICH AEROSPACE
23079-000-2	STARTER-GENERATOR	GOODRICH AEROSPACE
23079-002	STARTER-GENERATOR	GOODRICH AEROSPACE
23079-002-1	STARTER-GENERATOR	GOODRICH AEROSPACE
23079-003	STARTER-GENERATOR	GOODRICH AEROSPACE
23079-004	STARTER-GENERATOR	GOODRICH AEROSPACE
23079-005	STARTER-GENERATOR	GOODRICH AEROSPACE

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
23079-006	STARTER-GENERATOR	GOODRICH AEROSPACE
23079-007	STARTER-GENERATOR	GOODRICH AEROSPACE
23079-009	STARTER-GENERATOR	GOODRICH AEROSPACE
23079-010	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-001-1	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-002	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-003	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-003-1	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-004	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-005	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-005-1	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-006	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-011	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-012	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-013	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-013A	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-013B	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-014	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-014A	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-015	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-019	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-023	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-023A	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-023B	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-025	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-025-1	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-031	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-032	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-050	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-056	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-058	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-059	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-064	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-066	STARTER-GENERATOR	GOODRICH AEROSPACE
23080-067	STARTER-GENERATOR	GOODRICH AEROSPACE
23081-001	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-002	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-003	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-004	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-007	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-008	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-011	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-011-1	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-012	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-012-1	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-017	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-018	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-022	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-022A	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-023	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-023A	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-024	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-042	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-043	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-056	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-057	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-059	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-063	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-069	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-070	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-072	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23081-073	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23085-001	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23085-002	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23085-003	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23085-004	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23085-004-1	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23085-006	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
23085-009	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23085-013	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23085-014	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23085-015	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23085-024	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
23085-025	STARTER-GENERATOR	LSI/LUCAS/TRW/GOODRICH
234ES205-1	INDICATOR, SIDE SLIP	INSCO
238-10001	INDICATOR, FUEL FLOW	AHLERS AEROSPACE
2401-3010	SWITCH, GENERATOR/BATTERY	INSCO
2401-3011	SWITCH, INVERTER/BATTERY	INSCO
2501-1001	TRANSMITTER, FUEL QTY	INSCO
2502-1007	TRANSMITTER, FUEL QTY	INSCO
2502-1008	TRANSMITTER, FUEL QTY	INSCO
2502-1009	TRANSMITTER, FUEL QTY	INSCO
2502-1011	TRANSMITTER, FUEL QTY	INSCO
2502-1012	TRANSMITTER, FUEL QTY	INSCO
2502-1013	TRANSMITTER, FUEL QTY	INSCO
2502-1013	TRANSMITTER, FUEL QTY	INSCO
2502-1014	TRANSMITTER, FUEL QTY	INSCO
2502-1014	TRANSMITTER, FUEL QTY	INSCO
2502-1015	TRANSMITTER, FUEL QTY	INSCO
2502-1015	TRANSMITTER, FUEL QTY	INSCO
2502-1024	TRANSMITTER, FUEL QTY	INSCO
2502-1027	TRANSMITTER, FUEL QTY	INSCO
2502-1027	TRANSMITTER, FUEL QTY	INSCO
2502-6001	TRANSMITTER, FUEL QTY	INSCO
2502-7001	TRANSMITTER, FUEL QTY	INSCO
2502-7001	TRANSMITTER, FUEL QTY	INSCO
2502-7002	TRANSMITTER, FUEL QTY	INSCO
2502-7002	TRANSMITTER, FUEL QTY	INSCO
2502-7003	TRANSMITTER, FUEL QTY	INSCO
2502-7003	TRANSMITTER, FUEL QTY	INSCO
2502-7004	TRANSMITTER, FUEL QTY	INSCO
2502-7004	TRANSMITTER, FUEL QTY	INSCO
2502-7020	TRANSMITTER, FUEL QTY	INSCO
2502-7020	TRANSMITTER, FUEL QTY	INSCO
2502-7021	TRANSMITTER, FUEL QTY	INSCO
2502-7021	TRANSMITTER, FUEL QTY	INSCO
2502-7022	TRANSMITTER, FUEL QTY	INSCO
2502-7022	TRANSMITTER, FUEL QTY	INSCO
25122-A10B-1-A1	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-A15A-1-A2	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-A15H-2-A2	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-A17F-2-A3	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-A1A-1-A2	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-A23E-2-A2	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-A23F-2-A2	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-A27C-1-A1	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-A27E-2-A3	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-A28C-1-A2	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-A29B-2-A2	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-A2C-1-A1	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-A2J-1-A2	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-A30D-1-A2	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-A30E-1-A1	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-A37A-1-A1	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-A37B-1-A1	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-A37M-2-A2	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-A37R-2-A2	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-A40A-1-A3	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-A56A-1-A2	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-A73A-2-A1	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-B16A-1-A1	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-B16E-1-A2	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-B22C-1-A1	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-B25A-2-A2	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-B25B-2-A2	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-B3B-2-A2	INDICATOR, SINGLE SYNCHRO	BENDIX

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
25122-B3C-4-A2	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-B4A-1-A1	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-B54A-2-A2	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-B57A-1-A2	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-B5D-2-A2	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-B7A-1-A1	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-C11A-1-A2	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-C72A-17-A3	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-C73A-18-A3	INDICATOR, SINGLE SYNCHRO	BENDIX
25122-C76A-2-A3	INDICATOR, SINGLE SYNCHRO	BENDIX
25140/164A168-1	PUMP, FUEL	TRW/GLOBE
25140/164A168-1	PUMP, FUEL	TRW/GLOBE
252-10001	INDICATOR, FUEL QTY	AHLERS AEROSPACE
257-10001	INDICATOR, FUEL QTY	AHLERS AEROSPACE
2600-2001	INDICATOR, ENGINE OIL TEMPERATURE	INST. TECH
260-10001	INDICATOR, FUEL QTY	AHLERS AEROSPACE
260-10002	INDICATOR, FUEL QTY	AHLERS AEROSPACE
260-10003	INDICATOR, FUEL QTY	AHLERS AEROSPACE
260-10004	INDICATOR, FUEL QTY	AHLERS AEROSPACE
260-10005	INDICATOR, FUEL QTY	AHLERS AEROSPACE
260-10006	INDICATOR, FUEL QTY	AHLERS AEROSPACE
260-10007	INDICATOR, FUEL QTY	AHLERS AEROSPACE
260-10009	INDICATOR, FUEL QTY	AHLERS AEROSPACE
260-10010	INDICATOR, FUEL QTY	AHLERS AEROSPACE
260-2350-1	INDICATOR, TRIPLE TACHOMETER	INSCO
260-2351-1	INDICATOR, PRESSURE	INSCO
260-2352-1	INDICATOR, % TACHOMETER	INSCO
260-2353-1	INDICATOR, DUAL TORQUE	INSCO
260-2353-3	INDICATOR, DUAL TORQUE	INSCO
260-2353-5	INDICATOR, TRIPLE TORQUE	INSCO
260-2354-1	INDICATOR, ENGINE OIL TEMP/PRESS	INSCO
260-2355-1	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
260-2357-1	INDICATOR, DUAL TORQUE	INSCO
260-2357-3	INDICATOR, DUAL TORQUE	INSCO
260-2357-5	INDICATOR, TRIPLE TORQUE	INSCO
260-2358-1	INDICATOR, C BOX OIL TEMP/PRESS	INSCO
260-30001	INDICATOR, FUEL QTY	AHLERS AEROSPACE
260-30002	INDICATOR, FUEL QTY	AHLERS AEROSPACE
260-30003	INDICATOR, FUEL QTY	AHLERS AEROSPACE
260-40011	INDICATOR, FUEL QTY	AHLERS AEROSPACE
2606011-2	INDICATOR, PRESSURE	INSCO
2606011-3	INDICATOR, TORQUE	INSCO
2606012	INDICATOR, INTER TURBINE TEMPATURE	INSCO
2606012-1	INDICATOR, INTER TURBINE TEMPATURE	INSCO
2606013-1	INDICATOR, TACHOMETER	INSCO
2606014-1	INDICATOR, TACHOMETER	INSCO
261-10001	INDICATOR, FUEL QTY	AHLERS AEROSPACE
261-10002	INDICATOR, FUEL QTY	AHLERS AEROSPACE
261-10003	INDICATOR, FUEL QTY	AHLERS AEROSPACE
261-10004	INDICATOR, FUEL QTY	AHLERS AEROSPACE
261-10005	INDICATOR, FUEL QTY	AHLERS AEROSPACE
261-10006	INDICATOR, FUEL QTY	AHLERS AEROSPACE
261-10007	INDICATOR, FUEL QTY	AHLERS AEROSPACE
261-10008	INDICATOR, WATER BALLAST	AHLERS AEROSPACE
261-10009	INDICATOR, FUEL QTY	AHLERS AEROSPACE
261-10011	INDICATOR, FUEL QTY	AHLERS AEROSPACE
261-10014	INDICATOR, FUEL QTY	AHLERS AEROSPACE
261-10015	INDICATOR, FUEL QTY	AHLERS AEROSPACE
261-10017	INDICATOR, FUEL QTY	AHLERS AEROSPACE
261-10021	INDICATOR, FUEL PRESSURE	AHLERS AEROSPACE
261-10022	INDICATOR, FUEL QTY	AHLERS AEROSPACE
261-10023	INDICATOR, FUEL QTY	AHLERS AEROSPACE
261-10025	INDICATOR, FUEL QTY	AHLERS AEROSPACE
262-10001	INDICATOR, FUEL QTY	AHLERS AEROSPACE
263-10001	INDICATOR, FUEL QTY	AHLERS AEROSPACE
263-10002	INDICATOR, WATER QTY	AHLERS AEROSPACE
263-10003	INDICATOR, FUEL QTY	AHLERS AEROSPACE
263-10004	INDICATOR, FUEL QTY	AHLERS AEROSPACE

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
263-10005	INDICATOR, FUEL QTY	AHLERS AEROSPACE
263-10006	INDICATOR, FUEL QTY	AHLERS AEROSPACE
263-30006	INDICATOR, FUEL QTY	AHLERS AEROSPACE
266-025-001	INDICATOR, FUEL FLOW	GULL AIRBORNE
267-901-003	SYSTEM, FUEL QTY GAUGING	GULL AIRBORNE
269A4550	INDICATOR, ALTIMETER	INSCO
269D6068-1	INDICATOR, OIL TEMP/PRESS	INSCO
2702-2101	INDICATOR, EXHAUST GAS TEMPERATURE	UNDERWOOD INST.
27-19119-3	INDICATOR, FLAP POSITION	INSCO
27-19121-1	INDICATOR, HYDRAULIC PRESSURE	INSCO
27-19121-3	INDICATOR, HYDRAULIC PRESSURE	INSCO
27-19121-5	INDICATOR, HYDRAULIC PRESSURE	INSCO
27-19122-001	INDICATOR, SUCTION	INSCO
27-19126-3	INDICATOR, OUTSIDE AIR TEMPERATURE	INSCO
27-19132-001	INDICATOR, CABIN ALTIMETER/DIFFERENTIAL PRESS	INSCO
27-19134-001	INDICATOR, TURN & BANK	INSCO
27-19135-001	CLOCK	INSCO
27-19136-001	INDICATOR, CABIN CLIMB	INSCO
27-19137-031	INDICATOR, AIRSPEED	INSCO
27-19138-001	INDICATOR, ALTIMETER	INSCO
27-19139-001	INDICATOR, IVSI	INSCO
27-19149-1	INDICATOR, ARINC EGT/SUB DIAL	INSCO
27-19149-3	INDICATOR, ARINC EGT/SUB DIAL	INSCO
27-19149-5	INDICATOR, ARINC EGT/SUB DIAL	INSCO
27-19157-7	INDICATOR, % RPM TACHOMETER	INSCO
27-19158-1	INDICATOR, TORQUE/SUB DIAL	INSCO
27-19158-3	INDICATOR, % TORQUE/SUB DIAL	INSCO
27-19158-5	INDICATOR, % TORQUE/SUB DIAL	INSCO
27-19158-7	INDICATOR, % TORQUE/SUB DIAL	INSCO
2719158-9	INDICATOR, % TORQUE	INSCO
27-19171-1	INDICATOR, SAS	INSCO
27-19174-11	INDICATOR, TORQUE	INSCO
27-19175-003	INDICATOR, PROP TACHOMETER	INSCO
27-19176-003	INDICATOR, TACHOMETER	INSCO
27-19178-3	INDICATOR, OIL TEMP/PRESS	INSCO
27-19193-009	INDICATOR, AIRSPEED	INSCO
27-19193-011	INDICATOR, AIRSPEED	INSCO
2747	INDICATOR, FLAP POSITION	INSCO
2748	INDICATOR, ANGLE OF ATTACK	INSCO
2749	INDICATOR, ELEVATOR TRIM	INSCO
27-66004-19	INDICATOR, INTER TURBINE TEMPERATURE	INSCO
278-10001	INDICATOR, FUEL QTY	AHLERS AEROSPACE
278-40002	INDICATOR, FUEL QTY	AHLERS AEROSPACE
2790534-101	VALVE, FUEL LEVEL CONTROL	PARKER-HANNIFIN
2790534-101	VALVE, FUEL LEVEL CONTROL	PARKER-HANNIFIN
2803-2101	INDICATOR, PERCENT ROTOR SPEED	UNDERWOOD INST.
2904-2101	INDICATOR, TURBINE GAS TEMPERATURE	UNDERWOOD INST.
30-00010	MODULE	INSCO
30-0504-1	LIGHT, STROBE	GRIMES
30-0504-17	LIGHT, STROBE	GRIMES
30-0504-21	LIGHT, STROBE	GRIMES
30-0504-23	LIGHT, STROBE	GRIMES
30-0504-25	LIGHT, STROBE	GRIMES
30-0504-27	LIGHT, STROBE	GRIMES
30-0504-29	LIGHT, STROBE	GRIMES
30-0504-31	LIGHT, STROBE	GRIMES
30-0504-35	LIGHT, STROBE	GRIMES
30-0504-39	LIGHT, STROBE	GRIMES
30-0504-41	LIGHT, STROBE	GRIMES
30-0504-7	LIGHT, STROBE	GRIMES
30-0504-9	LIGHT, STROBE	GRIMES
30-0538-7	LIGHT, NAVIGATION	GRIMES
30-0538-8	LIGHT, NAVIGATION	GRIMES
300SGL111Q-1	STARTER-GENERATOR	APC/UNISON
300SGL111Q-2	STARTER-GENERATOR	APC/UNISON
300SGL114Q	STARTER-GENERATOR	APC/UNISON
300SGL115Q	STARTER-GENERATOR	APC/UNISON
300SGL116Q	STARTER-GENERATOR	APC/UNISON

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
300SGL116Q-2	STARTER-GENERATOR	APC/UNISON
300SGL118Q	STARTER-GENERATOR	APC/UNISON
300SGL126Q	STARTER-GENERATOR	APC/UNISON
300SGL127Q-1	STARTER-GENERATOR	APC/UNISON
300SGL127Q-2	STARTER-GENERATOR	APC/UNISON
300SGL127Q-3	STARTER-GENERATOR	APC/UNISON
300SGL127Q-4	STARTER-GENERATOR	APC/UNISON
300SGL129Q	STARTER-GENERATOR	APC/UNISON
300SGL129Q-2	STARTER-GENERATOR	APC/UNISON
300SGL129Q-3	STARTER-GENERATOR	APC/UNISON
300SGL138Q-2	STARTER-GENERATOR	APC/UNISON
300SGL138Q-4	STARTER-GENERATOR	APC/UNISON
300SGL138Q-5	STARTER-GENERATOR	APC/UNISON
300SGL139Q	STARTER-GENERATOR	APC/UNISON
300SGL145Q	STARTER-GENERATOR	APC/UNISON
300SGL146Q	STARTER-GENERATOR	APC/UNISON
300SGL146Q-2	STARTER-GENERATOR	APC/UNISON
300SGL146Q-3	STARTER-GENERATOR	APC/UNISON
300SGL150Q	STARTER-GENERATOR	APC/UNISON
300SGL152Q	STARTER-GENERATOR	APC/UNISON
300SGL153Q	STARTER-GENERATOR	APC/UNISON
300SGL157Q	STARTER-GENERATOR	APC/UNISON
3057-3-131	INDICATOR, TORQUE	LABEM
306-10002	INDICATOR, DC VOLTMETER	AHLERS AEROSPACE
306-30002	INDICATOR, DC VOLTMETER	AHLERS AEROSPACE
30B37-23B	STARTER-GENERATOR	BENDIX
30B37-49B	STARTER-GENERATOR	BENDIX
30B37-49BT	STARTER-GENERATOR	BENDIX
30B37-49C	STARTER-GENERATOR	BENDIX
30B37-49D	STARTER-GENERATOR	BENDIX
30B37-7B	STARTER-GENERATOR	BENDIX
30E20-111	STARTER-GENERATOR	BENDIX
30E20-11B	STARTER-GENERATOR	BENDIX
30E20-11C	STARTER-GENERATOR	BENDIX
30E20-39A	STARTER-GENERATOR	BENDIX
30E20-41A	STARTER-GENERATOR	BENDIX
30E20-41B	STARTER-GENERATOR	BENDIX
30E20-49B	STARTER-GENERATOR	BENDIX
30E20-97A	STARTER-GENERATOR	BENDIX
3100-2001	INDICATOR, ENGINE OIL PRESSURE	INST. TECH
311-30002	INDICATOR, DC VOLTMETER	AHLERS AEROSPACE
311-40001	INDICATOR, AMMETER	AHLERS AEROSPACE
312-10001	INDICATOR, VOLTMETER	AHLERS AEROSPACE
31230-1120	INDICATOR, VERTICAL SPEED	AEROSONIC
31230-1127	INDICATOR, VERTICAL SPEED	AEROSONIC
312-IN-0001	INDICATOR, INLET AIR TEMPERATURE	INSCO
312-IN-0002	INDICATOR, INTER TURBINE TEMPERATURE	INSCO
312-IN-0003	INDICATOR, OIL TEMPERATURE	INSCO
312-IN-0004	INDICATOR, OIL PRESSURE	INSCO
312-IN-0005	INDICATOR, TORQUE	INSCO
312-IN-0007	INDICATOR, PROP TACHOMETER	INSCO
312-IN-0009	INDICATOR, FUEL PRESSURE	INSCO
31342-001	GENERATOR, AC	SAFRAN
31342-003	GENERATOR, AC	SAFRAN
31342-006	GENERATOR, AC	SAFRAN
31-3172-1 thru 37	FLASHTUBE ASSY.	GRIMES
3200-2001	INDICATOR, FUEL QTY	INST. TECH
3252010-0101	INDICATOR, COUNTER DRUM POINTER ALTIMETER	BENDIX
3252010-1101	INDICATOR, COUNTER DRUM POINTER ALTIMETER	BENDIX
3252010-1101/0101	INDICATOR, ALTIMETER	BENDIX/KING
3380001-501	INDICATOR, CHT/OAT	INSCO
3490233-9003	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	BENDIX
350-82-1267-01	INDICATOR, TURBINE OUTLET TEMPERATURE T-4	INSCO
350A-82-1283-02	INDICATOR, TORQUE	INSCO
350A-82-1289-01	INDICATOR, TORQUE	INSCO
353-10001	INDICATOR, LOADMETER	AHLERS AEROSPACE
356-10001	INDICATOR, DEICE AMPS	AHLERS AEROSPACE
356-10003	INDICATOR, AMPS, LH	AHLERS AEROSPACE

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
356-10004	INDICATOR, AMPS, RH	AHLERS AEROSPACE
356-10005	INDICATOR, DEICE AMPS	AHLERS AEROSPACE
356-10006	INDICATOR, AMPS, LH	AHLERS AEROSPACE
356-10007	INDICATOR, AMPS, RH	AHLERS AEROSPACE
356-30001	INDICATOR, DEICE AMPS	AHLERS AEROSPACE
356-30003	INDICATOR, AMPS, LH	AHLERS AEROSPACE
356-30004	INDICATOR, AMPS, RH	AHLERS AEROSPACE
3571211-9001	INDICATOR, SINGLE SYNCHRO	BENDIX
3571211-9009	INDICATOR, SINGLE SYNCHRO	BENDIX
3571211-9010	INDICATOR, SINGLE SYNCHRO	BENDIX
3571211-9011	INDICATOR, SINGLE SYNCHRO	BENDIX
3571211-9012	INDICATOR, SINGLE SYNCHRO	BENDIX
3571211-9014	INDICATOR, SINGLE SYNCHRO	BENDIX
3571211-9015	INDICATOR, SINGLE SYNCHRO	BENDIX
3571211-9016	INDICATOR, SINGLE SYNCHRO	BENDIX
3571211-9020	INDICATOR, SINGLE SYNCHRO	BENDIX
3571211-9021	INDICATOR, SINGLE SYNCHRO	BENDIX
3571211-9028	INDICATOR, SINGLE SYNCHRO	BENDIX
3571211-9032	INDICATOR, SINGLE SYNCHRO	BENDIX
3571211-9035	INDICATOR, SINGLE SYNCHRO	BENDIX
3571211-9039	INDICATOR, SINGLE SYNCHRO	BENDIX
3571211-9040	INDICATOR, SINGLE SYNCHRO	BENDIX
3571211-9041	INDICATOR, SINGLE SYNCHRO	BENDIX
3571211-9043	INDICATOR, SINGLE SYNCHRO	BENDIX
3571211-9054	INDICATOR, SINGLE SYNCHRO	BENDIX
3571212-0006	INDICATOR, SINGLE SYNCHRO	BENDIX
3571212-0052	INDICATOR, SINGLE SYNCHRO	BENDIX
3571212-0055	INDICATOR, SINGLE SYNCHRO	BENDIX
3571251-9110	INDICATOR, TACHOMETER	BENDIX
3571251-9115	INDICATOR, TEMPERATURE	BENDIX
3571251-9120	INDICATOR, TACHOMETER	BENDIX
3571251-9123	INDICATOR, MEASURED GAS TEMP	BENDIX/KING
3571251-9127	INDICATOR, MEASURED GAS TEMP	BENDIX/KING
3571251-9129	INDICATOR, MEASURED GAS TEMP	BENDIX/KING
3571251-9131	INDICATOR, TEMPERATURE	BENDIX
3571251-9202	INDICATOR, FUEL PRESSURE	BENDIX
3571251-9207	INDICATOR, FUEL PRESSURE	BENDIX
3571251-9209	INDICATOR, FUEL PRESSURE	BENDIX
3571251-9210	INDICATOR, FUEL PRESSURE	BENDIX
3571251-9212	INDICATOR, FUEL PRESSURE	BENDIX
3571251-9212M	INDICATOR, FUEL PRESSURE	BENDIX
3571251-9215	INDICATOR, FUEL PRESSURE	BENDIX
3571251-9216	INDICATOR, FUEL PRESSURE	BENDIX
3571262-2301	INDICATOR, TACHOMETER	BENDIX
3571262-2302	INDICATOR, TACHOMETER	BENDIX
3571262-2303	INDICATOR, TACHOMETER	BENDIX
3571262-2306	INDICATOR, TACHOMETER	BENDIX
3571262-2307	INDICATOR, TACHOMETER	BENDIX
3571262-2308	INDICATOR, TACHOMETER	BENDIX
3571262-5101	INDICATOR, ELECTRICAL TACH	BENDIX/KING
3571262-5108	INDICATOR, ELECTRICAL TACH	BENDIX/KING
3571262-5109	INDICATOR, ELECTRICAL TACH	BENDIX/KING
3571371-9004	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	BENDIX
357-40001	INDICATOR, DC LOADMETER	AHLERS AEROSPACE
361070120	INDICATOR, TORQUE	INSCO
361140040	INDICATOR, PRESSURE	INSCO
362-10001	INDICATOR, LOADMETER	AHLERS AEROSPACE
36-380020-1	CLUSTER, INSTRUMENT	INSCO
36-380021-1	CLUSTER, INSTRUMENT	INSCO
36-380044-1	CLUSTER, INSTRUMENT	INSCO
366-905-003	ASSEMBLY, BULKHEAD	GULL AIRBORNE
369A4512	INDICATOR, TORQUE	INSCO
369A4512B	INDICATOR, TORQUE	INSCO
369A4514-3	UNIT, EPO WARNING	INSCO
369A4514-5	UNIT, EPO WARNING	INSCO
369A4515	INDICATOR, DUAL TACHOMETER	INSCO
369A4515	INDICATOR, DUAL TACHOMETER	INSCO
369A4516-1	INDICATOR, N1 TACHOMETER	INSCO

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
369A4516-3	INDICATOR, N1 TACHOMETER	INSCO
369A4516-5	INDICATOR, N1 TACHOMETER	INSCO
369A4516-7	INDICATOR, N1 TACHOMETER	INSCO
369A4517	GENERATOR, TACH	INSCO
369A4519-3	INDICATOR, FUEL QTY	INSCO
369A4521	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
369A4521-11	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
369A4521-13	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
369A4521-15	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
369A4521-3	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
369A4521-5	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
369A4521-9	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
369A4522	INDICATOR, TORQUE	INSCO
369A4524-3	UNIT, EPO WARNING	INSCO
369A4540	UNIT, EPO WARNING	INSCO
369A45614	UNIT, EPO WARNING	INSCO
369A4672	PANEL, CAUTION	INSCO
369A4831	CLUSTER, INSTRUMENT	INSCO
369A514-3	INDICATOR, ENGINE POWER OUT	AUTRONICS
369D24137	INDICATOR, FUEL QTY	ROCHESTER
369D241474	INDICATOR, ALTIMETER	INSCO
369D24158	INDICATOR, TORQUE	INSCO
369D24158-11	INDICATOR, TORQUE	INSCO
369D24158-13	INDICATOR, TORQUE	INSCO
369D24158-15	INDICATOR, TORQUE	INSCO
369D24158-3	INDICATOR, TORQUE	INSCO
369D24158-5	INDICATOR, TORQUE	INSCO
369D24158-7	INDICATOR, TORQUE	INSCO
369D24158-9	INDICATOR, TORQUE	INSCO
369D24518	INDICATOR, DUAL TACHOMETER	INSCO
369D24518-3	INDICATOR, DUAL TACHOMETER	INSCO
369D24518-5	INDICATOR, DUAL TACHOMETER	INSCO
369D296303-3	SENDING UNIT, FUEL QTY	INSCO
369H4518	INDICATOR, DUAL TACHOMETER	INSCO
369H4518-3	INDICATOR, DUAL TACHOMETER	INSCO
369H4518-5	INDICATOR, DUAL TACHOMETER	INSCO
369H4518-7	INDICATOR, DUAL TACHOMETER	INSCO
369H4518-9	INDICATOR, DUAL TACHOMETER	INSCO
369H4526	INDICATOR, TORQUE	INSCO
369H4526-11	INDICATOR, TORQUE	INSCO
369H4526-13	INDICATOR, TORQUE	INSCO
369H4526-15	INDICATOR, TORQUE	INSCO
369H4526-17	INDICATOR, TORQUE	INSCO
369H4526-19	INDICATOR, TORQUE	INSCO
369H4526-21	INDICATOR, TORQUE	INSCO
369H4526-23	INDICATOR, TORQUE	INSCO
369H4526-3	INDICATOR, TORQUE	INSCO
369H4526-5	INDICATOR, TORQUE	INSCO
369H4526-7	INDICATOR, TORQUE	INSCO
369H4526-9	INDICATOR, TORQUE	INSCO
369H6415	CLUSTER, INSTRUMENT	INSCO
369H6418	INDICATOR, OIL PRESSURE	INSCO
369H6425NC,-5	CONTROL, DIMMER	AUTRONICS
38050196	INDICATOR, DUAL INLET AIR TEMPERATURE	INSCO
3809312-6	INDICATOR, TORQUE	BENDIX
3809357-2	TURBINE OUTLET TEMP	BENDIX/KING
3809431-1	INDICATOR, TORQUE	BENDIX
3880002-501	INDICATOR, OIL TEMPERATURE	INSCO
3880003-501	INDICATOR, OIL PRESSURE	INSCO
3880004-501	INDICATOR, MANIFOLD PRESSURE	INSCO
3880005-501	INDICATOR, TACHOMETER	INSCO
3880006-501	INDICATOR, VOLTMETER/AMMETER	INSCO
3880007-501	INDICATOR, TURBINE INLET TEMPERATURE	INSCO
3880008-501	INDICATOR, FUEL PRESSURE	INSCO
3880009-501	INDICATOR, FUEL QTY	INSCO
3880009-503	INDICATOR, FUEL QTY	INSCO
3911212-9001	INDICATOR, TEMPERATURE	BENDIX
393004-01699	INDICATOR, FUEL QTY	SIMMONDS

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
393004-01794	INDICATOR, FUEL QTY	SIMMONDS
393004-01970	INDICATOR, FUEL QTY	SIMMONDS
393011-07	INDICATOR, DUAL FUEL QTY	INSCO
3932241-9002	INDICATOR, FUEL QTY, TOTALIZING	BENDIX
3932241-9003	INDICATOR, FUEL QTY, DUAL TOTALIZING	BENDIX
3932241-9008	INDICATOR, FUEL QTY, TOTALIZING	BENDIX
3941213-9003	INDICATOR, TACHOMETER	BENDIX
3941213-9009	INDICATOR, GAS PRODUCER TACHOMETER	BENDIX/KING
3941213-9014	INDICATOR, TACHOMETER	BENDIX
3943331-9002	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	HONEYWELL
3943332-9001	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	BENDIX
3943333-9001	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	BENDIX
3943333-9002	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	BENDIX
3S3060DC168D1	GENERATOR CONTROL UNIT	GENERAL ELECTRIC
3S3060DC168D1	GENERATOR CONTROL UNIT	GENERAL ELECTRIC
4005-1011	INDICATOR, SEGMENTAL VOLTMETER	INSCO
4005-1012	INDICATOR, DC VOLTMETER	INSCO
4005-3010	INDICATOR, DC VOLTMETER	INSCO
4009-3005	INDICATOR, AC VOLTMETER	INSCO
4009-3006	INDICATOR, AC VOLTMETER	INSCO
4010-3005	INDICATOR, DC VOLTMETER	INSCO
4011-1009	INDICATOR, DC VOLTMETER	INSCO
4011-3008	INDICATOR, DC VOLTMETER	INSCO
4013-2001	INDICATOR, VOLT	INSCO
4013-3001	INDICATOR VOLT	INSCO
4014-3002	INDICATOR, AC HERTZ METER	INSCO
402-0003	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
402-0004	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
402-0005	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
402-0006	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
402-0008	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
402-0009	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
402-0013	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
402-0014	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
402-0015	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
402-40001	INDICATOR, OXYGEN PRESSURE	AHLERS AEROSPACE
403-0001	INDICATOR, OIL PRESSURE	AHLERS AEROSPACE
403-0002	INDICATOR, OIL PRESSURE	AHLERS AEROSPACE
4038-3022	INDICATOR, PRESSURE, DIRECT READING	INSCO
407-10001	INDICATOR, OIL PRESSURE	AHLERS AEROSPACE
407-10002	INDICATOR, FUEL PRESSURE	AHLERS AEROSPACE
407-10004	INDICATOR, FUEL PRESSURE	AHLERS AEROSPACE
407-30003	INDICATOR, FUEL PRESSURE	AHLERS AEROSPACE
407-375-008-101	INDICATOR, DUAL TACHOMETER	VDO
407-375-008-103	INDICATOR, DUAL TACHOMETER	VDO
407-375-008-105	INDICATOR, DUAL TACHOMETER	VDO
4101-3002	INDICATOR, LOADMETER	INSCO
4104-3008	INDICATOR, DC AMMETER	INSCO
4106-1013	INDICATOR, DC AMMETER	INSCO
4106-1021	INDICATOR, DC AMMETER	INSCO
4106-3024	INDICATOR, DC AMMETER	INSCO
4107-3002	INDICATOR, AC AMMETER	INSCO
4109-2001	INDICATOR, DC AMMETER	INSCO
4109-3004	INDICATOR, DC AMMETER	INSCO
411-10001	INDICATOR, MANIFOLD PRESSURE	AHLERS AEROSPACE
411-10002	INDICATOR, FUEL PRESSURE	AHLERS AEROSPACE
411-10004	INDICATOR, TORQUE	AHLERS AEROSPACE
411-10005	INDICATOR, FUEL PRESSURE	AHLERS AEROSPACE
411-10006	INDICATOR, TORQUE	AHLERS AEROSPACE
411-10007	INDICATOR, TORQUE	AHLERS AEROSPACE
411-10010	INDICATOR, TORQUE	AHLERS AEROSPACE
411-10011	INDICATOR, FUEL PRESSURE	AHLERS AEROSPACE
411-10016	INDICATOR, OIL PRESSURE	AHLERS AEROSPACE
411-10017A	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
411-10020	INDICATOR, HYDRAULIC PRESSURE	AHLERS AEROSPACE
411-10025	INDICATOR, TORQUE	AHLERS AEROSPACE
411-10026	INDICATOR, TORQUE	AHLERS AEROSPACE
411-10031	INDICATOR, TORQUE	AHLERS AEROSPACE

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
411-10032	INDICATOR, TORQUE	AHLERS AEROSPACE
411-10033	INDICATOR, TORQUE	AHLERS AEROSPACE
411-10034	INDICATOR, TORQUE	AHLERS AEROSPACE
411-10035	INDICATOR, TORQUE	AHLERS AEROSPACE
411-10036	INDICATOR, FUEL PRESSURE	AHLERS AEROSPACE
411-20015	INDICATOR, XMSN OIL PRESSURE	AHLERS AEROSPACE
411-30002	INDICATOR, FUEL PRESSURE	AHLERS AEROSPACE
411-30017	INDICATOR, TORQUE	AHLERS AEROSPACE
411-30034	INDICATOR, TORQUE	AHLERS AEROSPACE
411-40008	INDICATOR, TORQUE	AHLERS AEROSPACE
411-40009	INDICATOR, TORQUE	AHLERS AEROSPACE
411-40010	INDICATOR, TORQUE	AHLERS AEROSPACE
411-40011	INDICATOR, FUEL PRESSURE	AHLERS AEROSPACE
411-40012	INDICATOR, TORQUE	AHLERS AEROSPACE
411-40014	INDICATOR, FUEL PRESSURE	AHLERS AEROSPACE
411-40018	INDICATOR, TORQUE	AHLERS AEROSPACE
411-40023	INDICATOR, FUEL PRESSURE	AHLERS AEROSPACE
411-40024	INDICATOR, TORQUE	AHLERS AEROSPACE
411-40027	INDICATOR, OIL PRESSURE	AHLERS AEROSPACE
411-40028	INDICATOR, FUEL PRESSURE	AHLERS AEROSPACE
411-40029	INDICATOR, TORQUE	AHLERS AEROSPACE
411-40030	INDICATOR, TORQUE	AHLERS AEROSPACE
411-40031	INDICATOR, FUEL PRESSURE	AHLERS AEROSPACE
411-40032	INDICATOR, TORQUE	AHLERS AEROSPACE
412-075-008-113	INDICATOR, DUAL TORQUE	VDO
412-075-010-101	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	BENDIX
412-075-010-105	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	BENDIX
412-075-010-107	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	BENDIX
412-075-010-109	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	BENDIX
412-075-010-111	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	VDO
412-075-010-113	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	VDO
412-075-010-115	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	INSCO
412-075-010-115	INDICATOR, TRIPLE TACHOMETER	INSCO
412-375-001-101	INDICATOR, FUEL QTY, DUAL TOTALIZING	BENDIX
412-375-001-105	INDICATOR, FUEL QTY, DUAL	VDO
412-375-001-105	INDICATOR, FUEL QTY, DUAL TOTALIZING	VDO
412-375-007-109	INDICATOR, FUEL PRESSURE	INSCO
412-375-035-101	INDICATOR, FUEL PRESSURE	INSCO
412-375-036-101	INDICATOR, HYDRAULIC OIL PRESS/TEMP	INSCO
413-10001	INDICATOR, DUAL FUEL PRESSURE	AHLERS AEROSPACE
413-10002	INDICATOR, DUAL HYDRAULIC PRESSURE	AHLERS AEROSPACE
414ES100-2	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
414ES209	INDICATOR, N1 TACHOMETER	INSCO
414ES209-1	INDICATOR, TACHOMETER	INSCO
414ES209-2	INDICATOR, TACHOMETER	INSCO
414ES209-5	INDICATOR, TACHOMETER	INSCO
414ES270-2	INDICATOR, DUAL TORQUE	INSCO
414ES270-4	INDICATOR, DUAL TORQUE	INSCO
414ES288	INDICATOR, TACHOMETER	INSCO
414ES288-1	INDICATOR, TACHOMETER	INSCO
414ES288-2	INDICATOR, TRIPLE TACHOMETER	INSCO
414ES288-3	INDICATOR, TACHOMETER	INSCO
414ES288-4	INDICATOR, TRIPLE TACHOMETER	INSCO
414ES288-6	INDICATOR, TRIPLE TACHOMETER, ENGINE/ROTOR	INSCO
41830	INDICATOR, ROTOR RPM	ABG-SEMCA SA
419.199/82	INDICATOR, NH TACHOMETER	INSCO
419.297/82	INDICATOR, INTER TURBINE TEMPERATURE	INSCO
419.298/82	INDICATOR, TORQUE	INSCO
419.302/82	INDICATOR, FUEL FLOW	INSCO
419.304/82	INDICATOR, OIL TEMP/PRESS	INSCO
419.524/82	INDICATOR, DUAL TACHOMETER	INSCO
42370	INDICATOR, ROTOR RPM	ABG-SEMCA SA
425-40001	INDICATOR, PRESSURE	AHLERS AEROSPACE
426-10001	INDICATOR, TORQUE	AHLERS AEROSPACE
426-10003	INDICATOR, TORQUE	AHLERS AEROSPACE
426-10004	INDICATOR, TORQUE	AHLERS AEROSPACE
426-10005	INDICATOR, TORQUE	AHLERS AEROSPACE
426-10006	INDICATOR, TORQUE	AHLERS AEROSPACE

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
426-10009	INDICATOR, TORQUE	AHLERS AEROSPACE
426-10010	INDICATOR, TORQUE	AHLERS AEROSPACE
426-20011	INDICATOR, TORQUE	AHLERS AEROSPACE
426-30003	INDICATOR, TORQUE	AHLERS AEROSPACE
427-10001	INDICATOR, DUAL DE-ICE PRESSURE	AHLERS AEROSPACE
427-10002	INDICATOR, DUAL DE-ICE PRESSURE	AHLERS AEROSPACE
42960	INDICATOR, ROTOR RPM	ABG-SEMCA SA
42965	INDICATOR, ROTOR RPM	ABG-SEMCA SA
4301-3003	INDICATOR, ENGINE OIL PRESSURE	INSCO
4301-3004	INDICATOR, TRANSMISSION OIL PRESSURE	INSCO
4308-1002	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1003	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1004	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1005	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1005	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1006	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1007	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1008	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1009	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1011	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1014	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1020	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1024	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1025	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1026	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1033	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1041	INDICATOR, TORQUE PRESSURE	INSCO
4308-1041	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1043	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1046	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1049	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1050	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1052	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1052	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1061	INDICATOR, TORQUE PRESSURE	INSCO
4308-1061	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1069	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1071	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1072	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1073	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1083	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1084	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1085	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1090	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1091	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1092	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1099	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1100	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1101	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1108	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1114	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1115	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1120	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1121	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1123	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1124	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1127	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1128	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1129	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1130	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-1134	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-2070	INDICATOR, FUEL PRESSURE	INSCO
4308-3001	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3013	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3018	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3018	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3021	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3021	INDICATOR, PRESSURE, DIRECT READING	INSCO

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
4308-3035	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3035	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3037	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3037	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3051	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3051	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3053	INDICATOR, DE-ICE PRESSURE	INSCO
4308-3054	INDICATOR, HYDRAULIC PRESSURE	INSCO
4308-3055	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3055	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3056	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3056	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3058	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3058	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3062	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3062	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3063	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3063	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3064	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3064	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3065	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3065	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3066	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3066	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3074	INDICATOR, HYDRAULIC PRESSURE	INSCO
4308-3074	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3075	INDICATOR, LANDING GEAR HYDRAULIC PRESSURE	INSCO
4308-3075	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3076	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3077	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3078	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3081	INDICATOR, TORQUE PRESSURE	INSCO
4308-3082	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3090	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3096	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3097	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3098	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3112	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3113	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3116	INDICATOR, PRESSURE, DIRECT READING	INSCO
4308-3117	INDICATOR, PRESSURE, DIRECT READING	INSCO
4309-3004	INDICATOR, TORQUE PRESSURE	INSCO
4310-2001	INDICATOR, TORQUE PRESSURE	INSCO
4310-2002	INDICATOR, TORQUE PRESSURE	INSCO
4310-2002	INDICATOR, TORQUE PRESSURE	INSCO
4310-2003	INDICATOR, TORQUE PRESSURE	INSCO
4310-2004	INDICATOR, TORQUE PRESSURE	INSCO
4310-2004	INDICATOR, TORQUE PRESSURE	INSCO
4310-2006	INDICATOR, TORQUE PRESSURE	INSCO
4310-3002	INDICATOR, TORQUE PRESSURE	INSCO
4310-3002	INDICATOR, TORQUE PRESSURE	INSCO
4310-3005	INDICATOR, TORQUE PRESSURE	INSCO
4310-3005	INDICATOR, TORQUE PRESSURE	INSCO
431-10001	INDICATOR, DUAL TORQUE W/TOTALIZER	AHLERS AEROSPACE
431-10002	INDICATOR, DUAL TORQUE W/TOTALIZER	AHLERS AEROSPACE
431-10003	INDICATOR, DUAL TORQUE W/TOTALIZER	AHLERS AEROSPACE
431-10008	INDICATOR, DUAL TORQUE	AHLERS AEROSPACE
431-10009	INDICATOR, DUAL TORQUE	AHLERS AEROSPACE
431-10010	INDICATOR, DUAL TORQUE	AHLERS AEROSPACE
431-10011	INDICATOR, DUAL TORQUE	AHLERS AEROSPACE
432-10013	INDICATOR, TRIPLE PRESSURE	AHLERS AEROSPACE
4328-1018	INDICATOR, TORQUE PRESSURE	INSCO
4328-3019	INDICATOR, TORQUE PRESSURE	INSCO
4328-3020	INDICATOR, TORQUE PRESSURE	INSCO
4328-3021	INDICATOR, TORQUE PRESSURE	INSCO
4328-3022	INDICATOR, TORQUE PRESSURE	INSCO
4328-3023	INDICATOR, TORQUE PRESSURE	INSCO
4328-3024	INDICATOR, TORQUE PRESSURE	INSCO

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
4328-3025	INDICATOR, TORQUE PRESSURE, FT/LB	INSCO
4328-3026	INDICATOR, TORQUE PERCENT	INSCO
4332-SERIES	INDICATOR, FUEL PRESS	INSCO
4337-1005	INDICATOR, DUAL OIL PRESSURE (SERVOED)	INSCO
4337-1014	INDICATOR, DUAL TORQUE PRESSURE	INSCO
4337-3006	INDICATOR, DUAL TORQUE PRESSURE	INSCO
4337-3007	INDICATOR, DUAL TORQUE PRESSURE	INSCO
4343-3001	INDICATOR, FUEL PRESSURE	INSCO
4344-1004	INDICATOR, OIL PRESSURE	INSCO
4344-1005	INDICATOR, TORQUE PRESSURE	INSCO
4344-1027	INDICATOR, FUEL PRESSURE	INSCO
4344-1028	INDICATOR, OIL PRESSURE	INSCO
4344-1029	INDICATOR, TORQUE PRESSURE	INSCO
4344-1037	INDICATOR, TORQUE PRESSURE	INSCO
4344-1038	INDICATOR, OIL PRESSURE	INSCO
4344-1039	INDICATOR, TORQUE PRESSURE	INSCO
4344-1040	INDICATOR, TORQUE PRESSURE	INSCO
4344-1041	INDICATOR, TORQUE PRESSURE	INSCO
4344-1042	INDICATOR, OIL PRESSURE	INSCO
4344-1043	INDICATOR, TORQUE PRESSURE	INSCO
4344-1044	INDICATOR, FUEL PRESSURE	INSCO
4344-1061	INDICATOR, FUEL PRESSURE, INLET	INSCO
4344-1062	INDICATOR, FUEL PRESSURE, INTERSTAGE	INSCO
4344-1076	INDICATOR, TORQUE PRESSURE	INSCO
4344-1084	INDICATOR, FUEL PRESSURE	INSCO
4344-1085	INDICATOR, TORQUE PRESSURE	INSCO
4344-2020	INDICATOR, XMSN OIL PRESSURE	INSCO
4344-3013	INDICATOR, TORQUE PRESSURE	INSCO
4344-3031	INDICATOR, HYDRAULIC PRESSURE	INSCO
4344-3049	INDICATOR, TORQUE PRESSURE	INSCO
4344-3064	INDICATOR, TORQUE PRESSURE	INSCO
4344-3067	INDICATOR, FUEL PRESSURE	INSCO
4344-3073	INDICATOR, TORQUE PRESSURE	INSCO
4344-3074	INDICATOR, TORQUE PRESSURE	INSCO
4344-3077	INDICATOR, ENGINE OIL PRESSURE	INSCO
4344-3078	INDICATOR, ENVELOPE PRESSURE	INSCO
4344-3079	INDICATOR, FUEL PRESSURE	INSCO
4344-3080	INDICATOR, TORQUE PRESSURE	INSCO
4344-3082	INDICATOR, FUEL PRESSURE	INSCO
4344-3083	INDICATOR, FUEL PRESSURE	INSCO
4344-3087	INDICATOR, FUEL PRESSURE	INSCO
4344-3090	INDICATOR, TORQUE PRESSURE	INSCO
4344-3091	INDICATOR, TORQUE PRESSURE	INSCO
4344-3092	INDICATOR, TORQUE PERCENT	INSCO
4350-1003	INDICATOR, TORQUE PRESSURE	INSCO
4351-1214	INDICATOR, TORQUE PRESSURE	INSCO
4351-1215	INDICATOR, TORQUE PRESSURE	INSCO
4351-1413	INDICATOR, TORQUE PRESSURE	INSCO
4353-2002	INDICATOR, TORQUE PRESSURE	INSCO
4353-2003	INDICATOR, TORQUE PRESSURE	INSCO
4354-1004	INDICATOR, TORQUE PRESSURE	INSCO
4354-3005	INDICATOR, TORQUE PRESSURE	INSCO
4355-3003	INDICATOR, DUAL TORQUE PRESSURE	INSCO
4355-3008	INDICATOR, DUAL TORQUE PRESSURE	INSCO
4358-3012	INDICATOR, FUEL PRESSURE	INSCO
4390-1004	INDICATOR, TORQUE PRESSURE %	INSCO
4390-1005	INDICATOR, TORQUE PRESSURE	INSCO
4390-1008	INDICATOR, TORQUE PERCENT A/D	INSCO
4390-3002	INDICATOR, TORQUE PRESSURE	INSCO
4390-3003	INDICATOR, TORQUE PRESSURE	INSCO
4390-3006	INDICATOR, TORQUE PRESSURE A/D	INSCO
4390-3007	INDICATOR, TORQUE PERCENT	INSCO
4393-1001	INDICATOR, TORQUE PRESSURE A/D	INSCO
4393-1002	INDICATOR, OIL PRESSURE A/D	INSCO
4393-1003	INDICATOR, FUEL PRESSURE (INLET) A/D	INSCO
4393-1004	INDICATOR, FUEL PRESSURE (INTERSTAGE) A/D	INSCO
4408-100-019 thru -073	ANNUNCIATOR PANEL	MSC PRODUCTS/EATON
4408-100-19	MASTER CAUTION PANEL	EATON/MSC

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
4408-100-21	MASTER CAUTION PANEL	EATON/MSC
4408-100-23	MASTER CAUTION PANEL	EATON/MSC
4408-100-25	MASTER CAUTION PANEL	EATON/MSC
4408-100-27	MASTER CAUTION PANEL	EATON/MSC
4408-100-29	MASTER CAUTION PANEL	EATON/MSC
4408-100-33	MASTER CAUTION PANEL	EATON/MSC
4408-100-35	MASTER CAUTION PANEL	EATON/MSC
4408-100-43	MASTER CAUTION PANEL	EATON/MSC
4408-100-45	MASTER CAUTION PANEL	EATON/MSC
4408-100-47	MASTER CAUTION PANEL	EATON/MSC
4408-100-51	MASTER CAUTION PANEL	EATON/MSC
4408-100-55	MASTER CAUTION PANEL	EATON/MSC
4408-100-57	MASTER CAUTION PANEL	EATON/MSC
4408-100-61	MASTER CAUTION PANEL	EATON/MSC
4408-100-63	MASTER CAUTION PANEL	EATON/MSC
4408-100-73	MASTER CAUTION PANEL	EATON/MSC
44410-()	ROTATING BEACON	GRIMES
44410-()	ROTATING BEACON	GRIMES
446-10001	INDICATOR, LANDING GEAR HYDRAULIC PRESSURE	AHLERS AEROSPACE
446-10002	INDICATOR, LANDING GEAR HYDRAULIC PRESSURE	AHLERS AEROSPACE
446-10003	INDICATOR, DEICER PRESSURE	AHLERS AEROSPACE
446-10004	INDICATOR, HYDRAULIC PRESSURE	AHLERS AEROSPACE
446-10006	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10007	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10008	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10009	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10010	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10011	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10012	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10013	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10014	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10019	INDICATOR, FUEL PRESSURE	AHLERS AEROSPACE
446-10020	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10021	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10022	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10023	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10024	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10025	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10026	INDICATOR, HYDRAULIC PRESSURE	AHLERS AEROSPACE
446-10027	INDICATOR, LANDING GEAR HYDRAULIC PRESSURE	AHLERS AEROSPACE
446-10028	INDICATOR, DEICER PRESSURE	AHLERS AEROSPACE
446-10030	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10031	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10042	INDICATOR, LANDING GEAR HYDRAULIC PRESSURE	AHLERS AEROSPACE
446-10044	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10045	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10046	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10047	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10048	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10049	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10052	INDICATOR, HYDRAULIC PRESSURE	AHLERS AEROSPACE
446-10055	INDICATOR, LANDING GEAR HYDRAULIC PRESSURE	AHLERS AEROSPACE
446-10058	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10127	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10129	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10131	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10133	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10135	INDICATOR, TORQUE	AHLERS AEROSPACE
446-10137	INDICATOR, TORQUE	AHLERS AEROSPACE
446-30002	INDICATOR, LANDING GEAR HYDRAULIC PRESSURE	AHLERS AEROSPACE
446-30003	INDICATOR, DEICER PRESSURE	AHLERS AEROSPACE
446-30004	INDICATOR, HYDRAULIC PRESSURE	AHLERS AEROSPACE
446-40005	INDICATOR, TORQUE	AHLERS AEROSPACE
446-40014	INDICATOR, TORQUE	AHLERS AEROSPACE
446-40015	INDICATOR, XMSN OIL PRESSURE	AHLERS AEROSPACE
446-40026	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
446-40029	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
446-40032	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
446-40033	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
446-40034	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
446-40035	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
446-40036	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
446-40037	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
446-40038	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
446-40039	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
446-40040	INDICATOR, ENGINE OIL PRESSURE	AHLERS AEROSPACE
446-40041	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
446-40049	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
446-40050	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
446-40051	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
446-40053	INDICATOR, FUEL PRESSURE	AHLERS AEROSPACE
446-40054	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
446-40056	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
449-20001	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
45-0128-1	SEARCHLIGHT	GRIMES
45-0128-3	SEARCHLIGHT	GRIMES
45-0128-5	SEARCHLIGHT	GRIMES
457-40001	INDICATOR, OIL PRESSURE	AHLERS AEROSPACE
45AS76754-1	CLUSTER, INSTRUMENT	INSCO
45AS86116-1	INDICATOR	INSCO
45AS86801	INDICATOR, FUEL FLOW	INSCO
45AS8682	INDICATOR, INTER TURBINE TEMPATURE	INSCO
45AS86823-7	INDICATOR, TACHOMETER	INSCO
45AS86825-7	INDICATOR, OIL TEMP/PRESS	INSCO
45AS86839-1	CLUSTER, INSTRUMENT	INSCO
45AS86839-3	CLUSTER, INSTRUMENT	INSCO
45AS86846-7	INDICATOR, HYDRAULIC PRESSURE	INSCO
45AS86848-1	INDICATOR, DUAL ROLL TRIM POSITION	INSCO
45AS86849-1	INDICATOR, TACHOMETER	INSCO
45AS86849-3	INDICATOR, TACHOMETER	INSCO
45AS86854-3	CLUSTER, VOLT/AMMETER	INSCO
45AS86854-5	CLUSTER, VOLT/AMMETER	INSCO
45AS86854-7	CLUSTER, VOLT/AMMETER	INSCO
45AS86854-9	CLUSTER, VOLT/AMMETER	INSCO
461-10004	INDICATOR, FUEL PRESSURE	AHLERS AEROSPACE
461-40002	INDICATOR, 2" VARIABLE RELUCTANCE	AHLERS AEROSPACE
461-40005	INDICATOR, OIL PRESSURE	AHLERS AEROSPACE
461-40006	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
468-10002	INDICATOR, FUEL PRESSURE	AHLERS AEROSPACE
468-10004	INDICATOR, TORQUE PRESSURE	AHLERS AEROSPACE
468-10006	INDICATOR, FUEL PRESSURE	AHLERS AEROSPACE
468-30006	INDICATOR, FUEL PRESSURE	AHLERS AEROSPACE
468-40001	INDICATOR, OIL PRESSURE, PUMP DISCHARGE	AHLERS AEROSPACE
468-40003	INDICATOR, FUEL PRESSURE	AHLERS AEROSPACE
468-40005	INDICATOR, FUEL PRESSURE	AHLERS AEROSPACE
469-40001	INDICATOR, OIL PRESSURE	AHLERS AEROSPACE
4A16	INDICATOR RATE OF CLIMB	THOMMEN
4A58	INDICATOR, RATE OF CLIMB	THOMMEN
5001-1012	INDICATOR, INLET AIR TEMPERATURE	INSCO
5002-3002	INDICATOR, ENGINE OIL TEMPERATURE	INSCO
5002-3003	INDICATOR, TRANSMISSION OIL TEMPERATURE	INSCO
5002-3025	INDICATOR, OIL TEMPERATURE	INSCO
5003-3017	INDICATOR, CABIN DUCT TEMPERATURE	INSCO
5006-1036	INDICATOR, TURBINE OUTLET TEMP	INSCO
5006-1037	INDICATOR, TURBINE OUTLET TEMP	INSCO
5006-1039	INDICATOR, TURBINE OUTLET TEMP	INSCO
5006-1041	INDICATOR, TURBINE OUTLET TEMP	INSCO
5006-1045	INDICATOR, TURBINE OUTLET TEMP	INSCO
5006-1047	INDICATOR, TURBINE OUTLET TEMP	INSCO
5006-1051	INDICATOR, TURBINE OUTLET TEMP	INSCO
5006-3012	INDICATOR, TEMPERATURE	INSCO
501-1228-01	PS-835 EMERGENCY POWER SUPPLY	BF GOODRICH
501-1228-01	EMERGENCY POWER SUPPLY	GOODRICH (L3)
501-1228-02	PS-835 EMERGENCY POWER SUPPLY	BF GOODRICH
501-1228-02	EMERGENCY POWER SUPPLY	GOODRICH (L3)
501-1228-03	PS-835 EMERGENCY POWER SUPPLY	BF GOODRICH

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
501-1228-03	EMERGENCY POWER SUPPLY	GOODRICH (L3)
501-1228-04	PS-835 EMERGENCY POWER SUPPLY	BF GOODRICH
501-1228-04	EMERGENCY POWER SUPPLY	GOODRICH (L3)
501-1228-05	PS-835 EMERGENCY POWER SUPPLY	BF GOODRICH
501-1228-05	EMERGENCY POWER SUPPLY	GOODRICH (L3)
501-1228-06	PS-835 EMERGENCY POWER SUPPLY	BF GOODRICH
501-1228-06	EMERGENCY POWER SUPPLY	GOODRICH (L3)
5017-1009	INDICATOR, OUTSIDE AIR TEMPERATURE	INSCO
5017-3008	INDICATOR, OUTSIDE AIR TEMPERATURE	INSCO
5017-3010	INDICATOR, ENGINE OIL TEMPERATURE	INSCO
5017-3011	INDICATOR, HELIUM TEMPERATURE	INSCO
5017-3012	INDICATOR, OUTSIDE AIR TEMPERATURE	INSCO
5017-3013	INDICATOR, SUPERHEAT (HELIUM/OAT)	INSCO
5021-1032	INDICATOR, INTERTURBINE TEMPERATURE	INSCO
5021-1036	INDICATOR, INTERTURBINE TEMPERATURE	INSCO
5021-1054	INDICATOR, INTERTURBINE TEMPERATURE	INSCO
5021-1055	INDICATOR, TURBINE OUTLET TEMP	INSCO
5021-3001	INDICATOR, TEMPERATURE	INSCO
5021-3030	INDICATOR, TEMPERATURE	INSCO
5021-3039	INDICATOR, INTERTURBINE TEMPERATURE	INSCO
5021-3051	INDICATOR, TURBINE OUTLET TEMP	INSCO
5022-1011	INDICATOR, OIL TEMP	INSCO
5029-1020	INDICATOR, INTERTURBINE TEMPERATURE	INSCO
5029-2008	INDICATOR, TURBINE OUTLET TEMP	INSCO
5029-2009	INDICATOR, TURBINE OUTLET TEMP	INSCO
5029-3015	INDICATOR, TEMPERATURE	INSCO
5032-1012	INDICATOR, TURBINE OUTLET TEMP	INSCO
5032-1017	INDICATOR, INTERTURBINE TEMPERATURE	INSCO
5032-1029	INDICATOR, MEASURED GAS TEMP	INSCO
5032-1048	INDICATOR, EXHAUST GAS TEMP	INSCO
5032-1051	INDICATOR, TURBINE INLET TEMP	INSCO
5032-1052	INDICATOR, TURBINE INLET TEMP	INSCO
5032-1053	INDICATOR, TURBINE INLET TEMP	INSCO
5032-1068	INDICATOR, INTERTURBINE TEMPERATURE	INSCO
5032-1084	INDICATOR, TURBINE OUTLET TEMP	INSCO
5032-1089	INDICATOR, INTERTURBINE TEMPERATURE	INSCO
5032-1094	INDICATOR, TURBINE OUTLET TEMP	INSCO
5032-1104	INDICATOR, TURBINE OUTLET TEMP	INSCO
5032-3009	INDICATOR, TURBINE OUTLET TEMP	INSCO
5032-3010	INDICATOR, TURBINE OUTLET TEMP	INSCO
5032-3016	INDICATOR, INTERTURBINE TEMPERATURE	INSCO
5032-3040	INDICATOR, TURBINE INLET TEMP	INSCO
5032-3056	INDICATOR, TURBINE OUTLET TEMP	INSCO
5032-3070	INDICATOR, TURBINE OUTLET TEMP	INSCO
5032-3071	INDICATOR, TURBINE OUTLET TEMP (SERVOED)	INSCO
5032-3088	INDICATOR, TURBINE OUTLET TEMP	INSCO
5032-3090	INDICATOR, TURBINE OUTLET TEMP	INSCO
5032-3092	INDICATOR, TEMPERATURE	INSCO
5032-3095	INDICATOR, TURBINE OUTLET TEMP	INSCO
5032-3098	INDICATOR, INTERTURBINE TEMPERATURE	INSCO
5032-3100	INDICATOR, INTERTURBINE TEMPERATURE	INSCO
5032-3101	INDICATOR, TEMPERATURE	INSCO
5032-3102	INDICATOR, INTERTURBINE TEMPERATURE	INSCO
5032-3105	INDICATOR, INTERTURBINE TEMPERATURE	INSCO
5032-3106	INDICATOR, INTERTURBINE TEMPERATURE	INSCO
5032-3109	INDICATOR, INTERTURBINE TEMPERATURE	INSCO
5032-3110	INDICATOR, INTERTURBINE TEMPERATURE	INSCO
5032-8101	INDICATOR, TEMPERATURE	INSCO
5033-3001	INDICATOR, SERVO TEMP	INSCO
5034-3005	INDICATOR, INLET AIR TEMPERATURE	INSCO
5034-3006	INDICATOR, INLET AIR TEMPERATURE	INSCO
5034-3007	INDICATOR, OUTLET AIR TEMPERATURE	INSCO
5034-3008	INDICATOR, INLET AIR TEMPERATURE	INSCO
5036-3004	INDICATOR, DUAL TURBINE OUTLET TEMP	INSCO
5036-3005	INDICATOR, DUAL TURBINE OUTLET TEMP	INSCO
50-380010-1	INDICATOR, DUAL TACHOMETER	INSCO
50-380010-11	INDICATOR, DUAL TACHOMETER	INSCO
50-380010-13	INDICATOR, DUAL TACHOMETER	INSCO

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
50-380010-15	INDICATOR, DUAL TACHOMETER	INSCO
50-380010-17	INDICATOR, DUAL TACHOMETER	INSCO
50-380010-19	INDICATOR, DUAL TACHOMETER	INSCO
50-380010-21	INDICATOR, DUAL TACHOMETER	INSCO
50-380010-23	INDICATOR, DUAL TACHOMETER	INSCO
50-380010-25	INDICATOR, DUAL TACHOMETER	INSCO
50-380010-27	INDICATOR, DUAL TACHOMETER	INSCO
50-380010-7	INDICATOR, DUAL TACHOMETER	INSCO
50-380010-9	INDICATOR, DUAL TACHOMETER	INSCO
50-380034-3	INDICATOR, % TACHOMETER	INSCO
50-380034-5	INDICATOR, % TACHOMETER	INSCO
50-380035-1	INDICATOR, PROP TACHOMETER	INSCO
50-380035-5	INDICATOR, PROP TACHOMETER	INSCO
50-380105-1	INDICATOR, PNEUMATIC PRESSURE	INSCO
50-384059-1	INDICATOR, DUAL TACHOMETER	INSCO
50-384059-3	INDICATOR, DUAL TACHOMETER	INSCO
50-384059-5	INDICATOR, DUAL TACHOMETER	INSCO
50-389080	INDICATOR, ENGINE	INSCO
50-389080-1	INDICATOR, ENGINE	INSCO
50-389102-1	INDICATOR, INTER TURBINE TEMPERTURE	INSCO
50-389102-11	INDICATOR, INTER TURBINE TEMPERTURE	INSCO
50-389102-13	INDICATOR, INTER TURBINE TEMPERTURE	INSCO
50-389102-15	INDICATOR, INTER TURBINE TEMPERTURE	INSCO
50-389102-9	INDICATOR, INTER TURBINE TEMPERTURE	INSCO
5052-1001	INDICATOR, OUTSIDE AIR TEMPERATURE A/D	INSCO
5052-1002	INDICATOR, OIL TEMPERATURE A/D	INSCO
5053-1001	INDICATOR, TURBINE OUTLET TEMPERATURE A/D	INSCO
506-10001	INDICATOR, CABIN TEMPERATURE	AHLERS AEROSPACE
507-10001	INDICATOR, OIL TEMPERATURE	AHLERS AEROSPACE
507-40002	INDICATOR, TEMPERATURE	AHLERS AEROSPACE
5080-1002	INDICATOR, INTERTURBINE TEMPERATURE	INSCO
5080-1006	INDICATOR, INTERTURBINE TEMPERATURE	INSCO
5080-3004	INDICATOR, INTERTURBINE TEMPERATURE A/D	INSCO
5080-3005	INDICATOR, INTERTURBINE TEMPERATURE	INSCO
5080-3010	INDICATOR, INTERTURBINE TEMPERATURE	INSCO
508-10757	INDICATOR, DUAL FUEL FLOW	INSCO
5081-3001	INDICATOR, INLET AIR TEMPERATURE A/D	INSCO
510-40001	INDICATOR, TEMPERATURE	AHLERS AEROSPACE
511-10001	INDICATOR, OUTSIDE AIR TEMPERATURE	AHLERS AEROSPACE
511-10002	INDICATOR, OUTSIDE AIR TEMPERATURE	AHLERS AEROSPACE
511-10004	INDICATOR, XMSN OIL TEMP/PRESS	AHLERS AEROSPACE
511-30001	INDICATOR, OUTSIDE AIR TEMPERATURE	AHLERS AEROSPACE
511-30004	INDICATOR, XMSN OIL TEMP/PRESS	AHLERS AEROSPACE
511-40005	INDICATOR, OIL TEMPERATURE	AHLERS AEROSPACE
515-030	STARTER-GENERATOR	THALES/AUXILEC
515-030	STARTER-GENERATOR	THALES/AUXILEC
51509-002	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51509-002A	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51509-002B	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51509-002R	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51509-006	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51509-006B	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51509-006BR	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51509-006C	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51509-006D	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51509-006F	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51530-001	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51530-001A	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51530-001E	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51530-001EI	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51530-006	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51530-006A	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51530-006B	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51530-007	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51530-007A	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51530-007B	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51530-007D	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51530-008	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
51538-001A	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51538-001B	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51538-001C	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51538-001D	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51539-002A	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51539-002B	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51539-002M	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51539-002N	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51539-006B	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51539-006C	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51539-006D	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51539-006E	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51539-006F	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51539-006H	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51539-006J	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
51539-006M	GENERATOR CONTROL UNIT	LSI/TRW/GOODRICH
5160 series	COURSE SELECTOR	AEROSONIC
51-77-77	INDICATOR, DUAL TORQUE	INSCO
522823	INDICATOR, TORQUE PRESSURE	WESTON
522948	INDICATOR, TORQUE PRESSURE	WESTON
524-010	STARTER-GENERATOR	THALES/AUXILEC
524-030	STARTER-GENERATOR	THALES/AUXILEC
524-031	STARTER-GENERATOR	THALES/AUXILEC
524-060	STARTER-GENERATOR	THALES/AUXILEC
524-061	STARTER-GENERATOR	THALES/AUXILEC
524-062	STARTER-GENERATOR	THALES/AUXILEC
526-10001	INDICATOR, INLET AIR TEMPERATURE	AHLERS AEROSPACE
557-10001	INDICATOR, CYLINDER HEAD TEMPERATURE	AHLERS AEROSPACE
561-10001	INDICATOR, EXHAUST GAS TEMPERATURE	AHLERS AEROSPACE
561-10002	INDICATOR, TURBINE GAS TEMPERATURE	AHLERS AEROSPACE
561-10005	INDICATOR, TURBINE GAS TEMPERATURE	AHLERS AEROSPACE
561-10006	INDICATOR, INTER TURBINE TEMPATURE	AHLERS AEROSPACE
561-10010	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
561-10011	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
561-10012	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
561-10013	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
561-10014	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
561-10015	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
561-10020	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
561-10021	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
561-10022	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
561-10023	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
561-10024	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
561-10025	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
561-10027	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
561-10029	INDICATOR, INTER TURBINE TEMPATURE	AHLERS AEROSPACE
561-10033	INDICATOR, EXHAUST GAS TEMPERATURE	AHLERS AEROSPACE
561-10034	INDICATOR, EXHAUST GAS TEMPERATURE	AHLERS AEROSPACE
561-10043	INDICATOR, INTER TURBINE TEMPATURE	AHLERS AEROSPACE
561-10045	INDICATOR, INTER TURBINE TEMPATURE	AHLERS AEROSPACE
561-10046	INDICATOR, EXHAUST GAS TEMPERATURE	AHLERS AEROSPACE
561-10048	INDICATOR, INTER TURBINE TEMPATURE	AHLERS AEROSPACE
561-10050	INDICATOR, INTER TURBINE TEMPATURE	AHLERS AEROSPACE
561-10051	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
561-30038	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
561-30051	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
561-40007	INDICATOR, INTER TURBINE TEMPATURE	AHLERS AEROSPACE
561-40008	INDICATOR, INTER TURBINE TEMPATURE	AHLERS AEROSPACE
561-40009	INDICATOR, INTER TURBINE TEMPATURE	AHLERS AEROSPACE
561-40016	INDICATOR, INTER TURBINE TEMPATURE	AHLERS AEROSPACE
561-40017	INDICATOR, INTER TURBINE TEMPATURE	AHLERS AEROSPACE
561-40018	INDICATOR, INTER TURBINE TEMPATURE	AHLERS AEROSPACE
561-40019	INDICATOR, INTER TURBINE TEMPATURE	AHLERS AEROSPACE
561-40031	INDICATOR, INTER TURBINE TEMPATURE	AHLERS AEROSPACE
561-40032	INDICATOR, INTER TURBINE TEMPATURE	AHLERS AEROSPACE
561-40035	INDICATOR, INTER TURBINE TEMPATURE	AHLERS AEROSPACE
561-40037	INDICATOR, INTER TURBINE TEMPATURE	AHLERS AEROSPACE
561-40038	INDICATOR, INTER TURBINE TEMPATURE	AHLERS AEROSPACE

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
561-40047	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE
561-40049	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE
561-40052	INDICATOR, T-5	AHLERS AEROSPACE
561-40053	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE
561-40054	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE
561-40055	INDICATOR, T-5	AHLERS AEROSPACE
561-40056	INDICATOR, T-5	AHLERS AEROSPACE
561-40057	INDICATOR, T-5	AHLERS AEROSPACE
561-40058	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE
561-40059	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE
561-40060	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE
5633-707-80-12	INDICATOR, NG SPEED & LIMIT DEVIATION	BRION LEROUX
5633-713-20-10	INDICATOR, NG SPEED & LIMIT DEVIATION	BRION LEROUX
563-40001	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE
5702-3002	INDICATOR, FUEL QTY	INSCO
5707-2016	INDICATOR, FUEL QTY	INSCO
5707-3002	INDICATOR, FUEL QTY	INSCO
5707-3007	INDICATOR, FUEL QTY	INSCO
5707-3012	INDICATOR, FUEL QTY	INSCO
5707-3025	INDICATOR, FUEL QTY	INSCO
5707-3027	INDICATOR, FUEL QTY	INSCO
5707-3036	INDICATOR, FUEL QTY	INSCO
5707-3037	INDICATOR, FUEL QTY	INSCO
5707-3038	INDICATOR, FUEL QTY	INSCO
5707-3061	INDICATOR, FUEL QTY	INSCO
5707-3063	INDICATOR, FUEL QTY	INSCO
5709-3017	INDICATOR, FUEL FLOW	INSCO
5711-3008	INDICATOR, FUEL QTY	INSCO
5712-3003	INDICATOR, HYDRAULIC LEVEL	INSCO
5718-2001	INDICATOR, FUEL QTY	INSCO
5719-3003	INDICATOR, CAWI QTY	INSCO
5720-1002	INDICATOR, DUAL FUEL FLOW	INSCO
5720-1021	INDICATOR, FUEL QTY	INSCO
5720-3003	INDICATOR, DUAL FUEL FLOW	INSCO
5720-3004	INDICATOR, DUAL FUEL FLOW	INSCO
5721-1009	INDICATOR, FUEL FLOW	INSCO
5721-3001	INDICATOR, FUEL FLOW	INSCO
5721-3002	INDICATOR, FUEL FLOW	INSCO
5721-3004	INDICATOR, FUEL FLOW	INSCO
5721-3007	INDICATOR, FUEL FLOW	INSCO
5722-3001	INDICATOR, FUEL QTY TOTALIZER	INSCO
5723-1003	INDICATOR, FUEL FLOW/FUEL CONSUMED	INSCO
5723-3002	INDICATOR, FUEL FLOW	INSCO
5724-3001	INDICATOR, FUEL QTY TOTALIZER	INSCO
5724-3002	INDICATOR, FUEL QTY TOTALIZER	INSCO
5724-3003	INDICATOR, FUEL QTY TOTALIZER	INSCO
5725-3002	INDICATOR, FUEL FLOW	INSCO
575-10001	INDICATOR, EXHAUST GAS TEMPERATURE	AHLERS AEROSPACE
576-10002	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE
576-10003	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
576-10005	INDICATOR, TURBINE GAS TEMPERATURE	AHLERS AEROSPACE
576-10006	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
576-10007	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
576-10009	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
576-10010	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
576-10011	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
576-10014	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
576-10016	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
576-10017	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
576-10027	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE
576-10031	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE
576-10032	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
576-10033	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
576-10034	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
576-10035	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
576-10036	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
576-10037	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
576-10038	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
576-10039	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
576-10040	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE
576-10043	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE
576-10047	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE
576-10048	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE
576-10050	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE
576-10051	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
576-10052	INDICATOR, T-4	AHLERS AEROSPACE
576-10053	INDICATOR, EXHAUST GAS TEMPERATURE	AHLERS AEROSPACE
576-10054	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
576-10055	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
576-10056	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
576-20019	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
576-20021	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
576-30001	INDICATOR, TURBINE GAS TEMPERATURE	AHLERS AEROSPACE
576-30002	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE
576-30021	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE
576-30048	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
576-40049	INDICATOR, EXHAUST GAS TEMPERATURE	AHLERS AEROSPACE
5802-1034	INDICATOR, AIRSPEED	INSCO
5802-1049	INDICATOR, AIRSPEED	INSCO
5802-1050	INDICATOR, AIRSPEED	INSCO
5802-1052	INDICATOR, AIRSPEED	INSCO
5802-1065	INDICATOR, AIRSPEED	INSCO
5802-3034	INDICATOR, AIRSPEED	INSCO
5802-3046	INDICATOR, AIRSPEED	INSCO
5802-3048	INDICATOR, AIRSPEED	INSCO
5802-3050	INDICATOR, AIRSPEED	INSCO
5802-3066	INDICATOR, AIRSPEED	INSCO
5802-3068	INDICATOR, AIRSPEED	INSCO
580-8318-1	INDICATOR, DUAL TACHOMETER	INSCO
581-40001	INDICATOR, DUAL EXHAUST GAS TEMPERATURE	AHLERS AEROSPACE
581-40002	INDICATOR, DUAL EXHAUST GAS TEMPERATURE	AHLERS AEROSPACE
581-40003	INDICATOR, DUAL EXHAUST GAS TEMPERATURE	AHLERS AEROSPACE
581-40004	INDICATOR, DUAL EXHAUST GAS TEMPERATURE	AHLERS AEROSPACE
58-380104-3	INDICATOR, CHT/EGT	INSCO
58-380104-5	INDICATOR, CHT/EGT	INSCO
589-10001	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE
590-10002	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
590-10007	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
590-10008	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
590-10010	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
590-10012	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
590-10027	INDICATOR, TURBINE GAS TEMPERATURE	AHLERS AEROSPACE
590-10028	INDICATOR, TURBINE GAS TEMPERATURE	AHLERS AEROSPACE
590-10029	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
590-10030	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE
590-10033	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE
590-10038	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
590-20003	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
590-40001	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
590-40004	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
590-40006	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
590-40009	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
590-40010	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
590-40011	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
590-40012	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
590-40013	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
590-40014	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
590-40016	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
590-40017	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
590-40018	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
590-40019	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
590-40020	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE
590-40021	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE
590-40022	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE
590-40023	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE
590-40026	INDICATOR, INTER TURBINE TEMPERTURE	AHLERS AEROSPACE

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
590-40032	INDICATOR, INTER TURBINE TEMPERATURE	AHLERS AEROSPACE
590-40034	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
590-40035	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
590-40036	INDICATOR, T-5	AHLERS AEROSPACE
590-40037	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
590-40039	INDICATOR, TURBINE OUTLET TEMPERATURE	AHLERS AEROSPACE
600-10002	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
600-10003	INDICATOR, PROP RPM	AHLERS AEROSPACE
600-10004	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
600-10007	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
600-10008	INDICATOR, PROP RPM	AHLERS AEROSPACE
600-10009	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
600-10013	INDICATOR, PROP RPM	AHLERS AEROSPACE
600-10014	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
600-10016	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
600-10017	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
600-10018	INDICATOR, PROP RPM	AHLERS AEROSPACE
600-10020	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
600-20005	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
600-30001	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
600-30002	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
600-30003	INDICATOR, PROP RPM	AHLERS AEROSPACE
600-30021	INDICATOR, N1 TACHOMETER	AHLERS AEROSPACE
600-40006	INDICATOR, NG TACHOMETER	AHLERS AEROSPACE
600-40011	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
600-40012	INDICATOR, N1 TACHOMETER	AHLERS AEROSPACE
600-40014	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
600-40015	INDICATOR, NG TACHOMETER	AHLERS AEROSPACE
600-40019	INDICATOR, NG TACHOMETER	AHLERS AEROSPACE
600-40022	INDICATOR, NG TACHOMETER	AHLERS AEROSPACE
60-1750-3	POWER SUPPLY, STROBE	GRIMES
60-1750-3	POWER SUPPLY, STROBE	GRIMES
602-10001	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
60-2502-1	BATTERY PACK	GRIMES
60-2502-1	BATTERY PACK	GRIMES
60-2502-3	BATTERY PACK	GRIMES
60-2502-3	BATTERY PACK	GRIMES
60-2502-5	BATTERY PACK	GRIMES
60-2502-5	BATTERY PACK	GRIMES
60-2894-1	POWER SUPPLY, STROBE	GRIMES
60-2894-1	POWER SUPPLY, STROBE	GRIMES
60-384070-1	INDICATOR, FUEL FLOW	INSCO
60-384070-3	INDICATOR, FUEL FLOW	INSCO
60-384072-1	INDICATOR, ENGINE	INSCO
60-384072-3	INDICATOR, ENGINE	INSCO
608-10001	INDICATOR, 3" DUAL TACHOMETER	AHLERS AEROSPACE
608-10003	INDICATOR, 3" DUAL TACHOMETER	AHLERS AEROSPACE
608-10009	INDICATOR, TRIPLE TACHOMETER	AHLERS AEROSPACE
608-10010	INDICATOR, 3" DUAL TACHOMETER	AHLERS AEROSPACE
608-10014	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
608-10021	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
608-10022	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
608-10023	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
608-10024	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
608-10024 BLOCK	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
608-20019	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
608-20020	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
608-30003	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
608-40002	INDICATOR, 3" DUAL TACHOMETER	AHLERS AEROSPACE
608-40004	INDICATOR, 3" DUAL TACHOMETER	AHLERS AEROSPACE
608-40005	INDICATOR, 3" DUAL TACHOMETER	AHLERS AEROSPACE
608-40006	INDICATOR, 3" DUAL TACHOMETER	AHLERS AEROSPACE
608-40007	INDICATOR, 3" DUAL TACHOMETER	AHLERS AEROSPACE
608-40011	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
608-40012	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
608-40015	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
608-40016	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
608-40017	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
608-40018	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
608-40021	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
609-10001	INDICATOR, TRIPLE TACHOMETER	AHLERS AEROSPACE
609-10002	INDICATOR, TRIPLE TACHOMETER	AHLERS AEROSPACE
609-10006	INDICATOR, TRIPLE TACHOMETER	AHLERS AEROSPACE
609-10008	INDICATOR, TRIPLE TACHOMETER	AHLERS AEROSPACE
609-10010	INDICATOR, TRIPLE TACHOMETER	AHLERS AEROSPACE
609-40003	INDICATOR, TRIPLE TACHOMETER	AHLERS AEROSPACE
609-40004	INDICATOR, TRIPLE TACHOMETER	AHLERS AEROSPACE
609-40005	INDICATOR, TRIPLE TACHOMETER	AHLERS AEROSPACE
609-40007	INDICATOR, TRIPLE TACHOMETER	AHLERS AEROSPACE
610-10001	INDICATOR, NP TACHOMETER	AHLERS AEROSPACE
6103-1004	INDICATOR, ALTIMETER	INSCO
6103-1014	INDICATOR, ALTIMETER	INSCO
6103-3012	INDICATOR, ALTIMETER	INSCO
6103-3014	INDICATOR, ALTIMETER	INSCO
6105-3003	INDICATOR, COUNTER POINTER ALTIMETER	INSCO
6107-3002	INDICATOR, DRUM POINTER ENCODING ALTIMETER	INSCO
6110-3003	INDICATOR, CABIN ALTIMETER	INSCO
611-10001	INDICATOR, TACHOMETER	AHLERS AEROSPACE
611-10002	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
611-10003	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-10004	INDICATOR, N1 TACHOMETER	AHLERS AEROSPACE
611-10005	INDICATOR, NP TACHOMETER	AHLERS AEROSPACE
611-10006	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
611-10007	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-10008	INDICATOR, PROP TACHOMETER	AHLERS AEROSPACE
611-10019	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-10021	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-10026	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-10032	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
611-10033	INDICATOR, PROP TACHOMETER	AHLERS AEROSPACE
611-10042	INDICATOR, PROP TACHOMETER	AHLERS AEROSPACE
611-10043	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
611-10044	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
611-10047	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-10048	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-10049	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-10050	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-10051	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-10052	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-10060	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-10061	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-10062	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-10066	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-10067	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-10068	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-10069	INDICATOR, PROP TACHOMETER	AHLERS AEROSPACE
61111-14	INDICATOR, PERCENT RPM	LEWIS
61121-04	INDICATOR, PERCENT TORQUE	LEWIS
61121-05	INDICATOR, PERCENT TORQUE	LEWIS
611-30018	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-30045	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-30046	INDICATOR, PROP TACHOMETER	AHLERS AEROSPACE
611-30060	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-40020	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
611-40027	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-40028	INDICATOR, PROP TACHOMETER	AHLERS AEROSPACE
611-40029	INDICATOR, PROP TACHOMETER	AHLERS AEROSPACE
611-40030	INDICATOR, PROP TACHOMETER	AHLERS AEROSPACE
611-40031	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-40032	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
611-40033	INDICATOR, PROP TACHOMETER	AHLERS AEROSPACE
611-40034	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-40035	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-40036	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-40037	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-40038	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
611-40039	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
611-40041	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
611-40053	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
611-40054	INDICATOR, PROP TACHOMETER	AHLERS AEROSPACE
611-40055	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
611-40056	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-40058	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
611-40059	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
611-40063	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
611-40064	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-40065	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
611-40066	INDICATOR, NG TACHOMETER	AHLERS AEROSPACE
611-40070	INDICATOR, NP TACHOMETER	AHLERS AEROSPACE
611-40071	INDICATOR, NP TACHOMETER	AHLERS AEROSPACE
611-40072	INDICATOR, NG TACHOMETER	AHLERS AEROSPACE
614-10001	INDICATOR, TRIPLE TACHOMETER	AHLERS AEROSPACE
615-40001	INDICATOR, 3" TACHOMETER	AHLERS AEROSPACE
617-10001	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-10002	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-10007	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-10021	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-10022	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-10023	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-10024	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-10025	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-10026	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-10027	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-10028	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-10029	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-10030	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-10031	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-10032	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-10033	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-10036	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-10037	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-40008	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-40009	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-40010	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-40011	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-40012	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-40013	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-40014	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-40015	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-40016	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-40017	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-40018	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-40019	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-40020	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-40034	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
617-40035	INDICATOR, DUAL TACHOMETER	AHLERS AEROSPACE
618-10001	INDICATOR, TRIPLE TACHOMETER	AHLERS AEROSPACE
618-10008	INDICATOR, TRIPLE TACHOMETER	AHLERS AEROSPACE
618-10013	INDICATOR, TRIPLE TACHOMETER	AHLERS AEROSPACE
618-10014	INDICATOR, TRIPLE TACHOMETER	AHLERS AEROSPACE
618-10015	INDICATOR, TRIPLE TACHOMETER	AHLERS AEROSPACE
618-20014	INDICATOR, TRIPLE TACHOMETER	AHLERS AEROSPACE
618-30001	INDICATOR, TRIPLE TACHOMETER	AHLERS AEROSPACE
618-40007	INDICATOR, TRIPLE TACHOMETER	AHLERS AEROSPACE
618-40009	INDICATOR, TRIPLE TACHOMETER	AHLERS AEROSPACE
618-40010	INDICATOR, TRIPLE TACHOMETER	AHLERS AEROSPACE
618-40011	INDICATOR, TRIPLE TACHOMETER	AHLERS AEROSPACE
618-40012	INDICATOR, TRIPLE TACHOMETER	AHLERS AEROSPACE
619-10001	INDICATOR, TRIPLE TACHOMETER	AHLERS AEROSPACE
6246-00402	INDICATOR, FUEL QTY	ROCHESTER
6247-00047	CLUSTER, INSTRUMENT	INSCO
625-10001	INDICATOR, % ROTOR SPEED	AHLERS AEROSPACE
626-10004	INDICATOR, TACHOMETER	AHLERS AEROSPACE
626-10006	INDICATOR, TACHOMETER	AHLERS AEROSPACE

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
626-10010	INDICATOR, PROP TACHOMETER	AHLERS AEROSPACE
626-10011	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
626-10020	INDICATOR, PROP TACHOMETER	AHLERS AEROSPACE
626-10022	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
626-10023	INDICATOR, PROP TACHOMETER	AHLERS AEROSPACE
626-10024	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
626-10026	INDICATOR, N1 TACHOMETER	AHLERS AEROSPACE
626-30026	INDICATOR, N1 TACHOMETER	AHLERS AEROSPACE
626-40001	INDICATOR, PROP TACHOMETER	AHLERS AEROSPACE
626-40002	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
626-40003	INDICATOR, PROP TACHOMETER	AHLERS AEROSPACE
626-40005	INDICATOR, PROP TACHOMETER	AHLERS AEROSPACE
626-40007	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
626-40008	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
626-40009	INDICATOR, PROP TACHOMETER	AHLERS AEROSPACE
626-40012	INDICATOR, PROP TACHOMETER	AHLERS AEROSPACE
626-40013	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
626-40014	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
626-40015	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
626-40016	INDICATOR, % RPM TACHOMETER	AHLERS AEROSPACE
626-40025	INDICATOR, GAS PRODUCER TACHOMETER	AHLERS AEROSPACE
626-40027	INDICATOR, PROP TACHOMETER	AHLERS AEROSPACE
627-40001	INDICATOR, TACHOMETER	AHLERS AEROSPACE
627-40002	INDICATOR, TACHOMETER	AHLERS AEROSPACE
627-40003	INDICATOR, TACHOMETER	AHLERS AEROSPACE
64010-029-1	INDICATOR, AIRSPEED	MARCONI
64400-982-1	INDICATOR, ACCELEROMETER	JAEGER
64845-200-1	INDICATOR, TRIPLE PRESSURE	JAEGER
64845-201-1	INDICATOR, TRIPLE PRESSURE	JAEGER
65.421.031.00	INDICATOR, SURFACE POSITION	INSCO
65.421.051.00	INDICATOR, ALTIMETER	INSCO
65.421.068.00	INDICATOR, FLAP/SLAT	INSCO
65.837.022.00	INDICATOR, ALTIMETER	INSCO
65.837.043.00	INDICATOR, AIRSPEED, MACHMETER RANGE	INSCO
65.837.046.00	INDICATOR, HORIZONTAL SITUATION	INSCO
65.837.052.00	INDICATOR, ALTITUDE DIRECTOR	INSCO
65.849.473.00	INDICATOR, DUAL TACHOMETER	INSCO
6501-1010	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	INSCO
6501-1011	INDICATOR, TACHMOMETER, GAS PRODUCER	INSCO
6501-1029	INDICATOR, TACHOMETER PROP RPM	INSCO
6501-1030	INDICATOR, TACHOMETER PERCENT RPM	INSCO
6501-1035	INDICATOR, TACHOMETER PERCENT RPM	INSCO
6501-1039	INDICATOR, TACHOMETER	INSCO
6501-1044	INDICATOR, TACHOMETER PERCENT RPM	INSCO
6501-1051	INDICATOR, TACHOMETER PERCENT RPM	INSCO
6501-1068	INDICATOR, TACHOMETER PERCENT RPM	INSCO
6501-1071	INDICATOR, TACHOMETER PERCENT RPM	INSCO
6501-1075	INDICATOR, TACHOMETER PROP RPM	INSCO
6501-1076	INDICATOR, TACHMOMETER, GAS PRODUCER	INSCO
6501-2004	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	INSCO
6501-2040	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	INSCO
6501-3008	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	INSCO
6501-3009	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	INSCO
6501-3037	INDICATOR, TACHOMETER PERCENT RPM	INSCO
6501-3038	INDICATOR, TACHOMETER PROP RPM	INSCO
6501-3039	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	INSCO
6501-3042	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	INSCO
6501-3046	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	INSCO
6501-3077	INDICATOR, TACHOMETER PROP RPM	INSCO
6501-3078	INDICATOR, TACHOMETER PERCENT RPM	INSCO
6501-3079	INDICATOR, TACHOMETER PERCENT RPM	INSCO
6501-3080	INDICATOR, TACHOMETER PROP RPM	INSCO
65-0136-1	PANEL, MASTER CAUTION	GRIMES
65-0136-21	PANEL, MASTER CAUTION	GRIMES
65-0136-23	PANEL, MASTER CAUTION	GRIMES
65-0136-3	PANEL, MASTER CAUTION	GRIMES
65-0136-5	PANEL, MASTER CAUTION	GRIMES
65-0136-7	PANEL, MASTER CAUTION	GRIMES

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
65-0136-9	PANEL, MASTER CAUTION	GRIMES
6501-8140	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	INSCO
6502-1001	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	INSCO
6502-1014	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	INSCO
6502-1053	INDICATOR, DUAL PROP RPM	INSCO
6502-1054	INDICATOR, DUAL PROP RPM	INSCO
6502-2004	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	INSCO
6502-2039	INDICATOR, TACHOMETER	INSCO
6502-3003	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	INSCO
6502-3010	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	INSCO
6502-3031	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	INSCO
6502-3052	INDICATOR, DUAL TACHOMETER	INSCO
6503-1009	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
6503-1015	INDICATOR, PROP RPM	INSCO
6503-1023	INDICATOR, TACHOMETER	INSCO
6503-1024	INDICATOR, PROP RPM	INSCO
6503-1027	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
6503-2038	INDICATOR, TACHOMETER	INSCO
6503-3029	INDICATOR, PROP RPM	INSCO
6503-3030	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
6503-3031	INDICATOR, TACHOMETER	INSCO
6503-3041	INDICATOR, TACHOMETER	INSCO
6503-3046	IND, LOW PRES ROTOR SPEED TACH, GAS PRODUCER N1	INSCO
6503-3047	IND, LOW PRES ROTOR SPEED TACH, GAS PRODUCER N1	INSCO
6503-3048	IND, HIGH PRES ROTOR SPEED TACH, GAS PRODUCER N2	INSCO
65-0365-1	PANEL, MASTER CAUTION	GRIMES
65-0365-3	PANEL, MASTER CAUTION	GRIMES
65-0365-5	PANEL, MASTER CAUTION	GRIMES
65-0365-7	PANEL, MASTER CAUTION	GRIMES
65-0365-9	PANEL, MASTER CAUTION	GRIMES
6503A-1062	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
6503A-1063	INDICATOR, PROP RPM	INSCO
6503A-1076	INDICATOR, PROP RPM	INSCO
6503A-1077	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
6503A-1093	INDICATOR, SERVOED TACH % RPM	INSCO
6503A-1097	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
6503A-1110	INDICATOR, TACHOMETER	INSCO
6503A-1111	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
6503A-3051	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
6503A-3052	INDICATOR, PROP RPM	INSCO
6503A-3067	INDICATOR, TACHOMETER	INSCO
6503A-3075	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
6503A-3081	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
6503A-3082	INDICATOR, POWER TURBINE TACHOMETER	INSCO
6503A-3088	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
6503A-3099	INDICATOR, PROP RPM	INSCO
6503A-3100	INDICATOR, PROP RPM	INSCO
6503A-3101	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
6503A-3106	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
6503A-3107	INDICATOR, PROP RPM	INSCO
6503A-3108	INDICATOR, POWER TURBINE TACHOMETER	INSCO
6503A-3109	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
6503A-3112	INDICATOR, N1 TACHOMETER % RPM	INSCO
6503A-3113	INDICATOR, N2 TACHOMETER % RPM	INSCO
6503A-3114	INDICATOR, PROP RPM	INSCO
6503A-3115	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
6503A-3116	INDICATOR, PROP RPM	INSCO
6503A-3117	INDICATOR, TACHOMETER PERCENT RPM	INSCO
6503A-3118	INDICATOR, PROP RPM	INSCO
6503A-3119	INDICATOR, TACHOMETER PERCENT RPM	INSCO
6503A-3121	INDICATOR, TACHOMETER PERCENT RPM	INSCO
6503A-3122	INDICATOR, PROP RPM	INSCO
6503A-3125	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
6503A-3126	INDICATOR, PROP RPM	INSCO
6504-2006	INDICATOR, DUAL TACHOMETER	INSCO
6504A-3017	INDICATOR, DUAL TACHOMETER	INSCO
6505-1024	INDICATOR, TRIPLE TACHOMETER	INSCO
6505-3012	INDICATOR, TRIPLE TACHOMETER	INSCO

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
6505-3019	INDICATOR, TRIPLE TACHOMETER	INSCO
6505A-1008	INDICATOR, TRIPLE TACHOMETER	INSCO
6505A-1028	INDICATOR, TRIPLE TACHOMETER	INSCO
6505A-1054	INDICATOR, TRIPLE TACHOMETER	INSCO
6505A-1055	INDICATOR, TRIPLE TACHOMETER	INSCO
6505A-3019	INDICATOR, TRIPLE TACHOMETER	INSCO
6505A-3048	INDICATOR, TRIPLE TACH, ENGINE & ROTOR	INSCO
6505A-3058	INDICATOR, TRIPLE TACHOMETER	INSCO
65-0944-1	PANEL, MASTER CAUTION	GRIMES
6511-1022	INDICATOR, DUAL TACHOMETER	INSCO
6511-3011	INDICATOR, DUAL N1 TACHOMETER	INSCO
6511-3012	INDICATOR, DUAL N2 TACHOMETER	INSCO
6511-3013	INDICATOR, DUAL N1 TACHOMETER	INSCO
6511-3014	INDICATOR, DUAL N2 TACHOMETER	INSCO
6511-3015	INDICATOR, DUAL N1 TACHOMETER	INSCO
6520-3012	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	INSCO
6520-8013	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	INSCO
6522-3001	INDICATOR, TACH, DUAL LOW PRES ROTOR SPEED (NL)	INSCO
6550-1004	INDICATOR, TACHOMETER, % RPM A/D	INSCO
6550-1007	INDICATOR, TACHOMETER, PROP (NP) A/D	INSCO
6550-3005	INDICATOR, PROP RPM (NP)	INSCO
6550-3006	INDICATOR, TURBINE % RPM (NG)	INSCO
6560-1004	INDICATOR, NH TACHOMETER (SERVOED-LED)	INSCO
6560-1005	INDICATOR, NP TACHOMETER (SERVOED-LED)	INSCO
6560-3003	INDICATOR, TACHOMETER GAS TURBINE (NG) % RPM A/D	INSCO
65WE01030-1	PUMP, HYDRAULIC	NEW YORK AIRBRAKE/VICKERS
65WE01030-1	PUMP, HYDRAULIC	NEW YORK AIRBRAKE/VICKERS
65WE01030-2	PUMP, HYDRAULIC	NEW YORK AIRBRAKE/VICKERS
65WE01030-2	PUMP, HYDRAULIC	NEW YORK AIRBRAKE/VICKERS
65WE01030-3	PUMP, HYDRAULIC	NEW YORK AIRBRAKE/VICKERS
65WE01030-3	PUMP, HYDRAULIC	NEW YORK AIRBRAKE/VICKERS
65WE01030-5	PUMP, HYDRAULIC	NEW YORK AIRBRAKE/VICKERS
65WE01030-5	PUMP, HYDRAULIC	NEW YORK AIRBRAKE/VICKERS
65WE01031-1	PUMP, HYDRAULIC	NEW YORK AIRBRAKE/VICKERS
65WE01031-1	PUMP, HYDRAULIC	NEW YORK AIRBRAKE/VICKERS
65WE01031-2	PUMP, HYDRAULIC	NEW YORK AIRBRAKE/VICKERS
65WE01031-2	PUMP, HYDRAULIC	NEW YORK AIRBRAKE/VICKERS
65WE01031-3	PUMP, HYDRAULIC	NEW YORK AIRBRAKE/VICKERS
65WE01031-3	PUMP, HYDRAULIC	NEW YORK AIRBRAKE/VICKERS
6601-1013	INDICATOR, RATE OF CLIMB	INSCO
6601-1014	INDICATOR, VERTICAL SPEED, INSTANTANEOUS	INSCO
6601-3009	INDICATOR, RATE OF CLIMB	INSCO
6601-3012	INDICATOR, RATE OF CLIMB	INSCO
6601-3018	INDICATOR, RATE OF CLIMB	INSCO
66-021-01	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	INSCO
6602-1012	INDICATOR, VERTICAL SPEED	INSCO
66-021-03	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	INSCO
66-021-05	INDICATOR, TACHOMETER, GAS PRODUCER	INSCO
66-021-07	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	INSCO
6602-3002	IND, VERT SPEED RAPID RESPONSE, ACCEL SENSITIVE	INSCO
6602-3010	INDICATOR, VERTICAL SPEED, INSTANTANEOUS	INSCO
6602-3018	INDICATOR, VERTICAL SPEED	INSCO
6602-3019	INDICATOR, VERTICAL SPEED	INSCO
6608211-5	ASSEMBLY, INSTRUMENT	INSCO
6608211-6	CLUSTER, INSTRUMENT	INSCO
6608238-1	INDICATOR, DUAL FUEL FLOW	INSCO
6608300-1	INDICATOR, FAN SPEED	INSCO
6608300-10	INDICATOR	INSCO
6608300-11	INDICATOR, TACHOMETER	INSCO
6608300-14	INDICATOR, INTER TURBINE TEMPURTURE	INSCO
6608300-2	INDICATOR, TURBINE SPEED	INSCO
6608300-3	INDICATOR, INTER TURBINE TEMPURTURE	INSCO
6608303-1	CLUSTER, INSTRUMENT	INSCO
6608303-2	CLUSTER, INSTRUMENT	INSCO
660-8319-1	INDICATOR, ENGINE POWER OUT	AUTRONICS
660-8319-1	UNIT, EPO WARNING	INSCO
660-8333-1	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
660-8333-2	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
660-8333-3	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
6608355-1	CLUSTER, INSTRUMENT	INSCO
6608371-1	INDICATOR, POWER	INSCO
6608802-1	INDICATOR, TORQUE	INSCO
6608803-1	INDICATOR, INTER TURBINE TEMPERATURE	INSCO
6608804-1	INDICATOR, PROP TACHOMETER	INSCO
6608805-1	INDICATOR, TURBINE TACHOMETER	INSCO
6608806-1	INDICATOR, DUAL FUEL FLOW	INSCO
6608807-1	INDICATOR, OIL TEMP/PRESS	INSCO
6608811-1	INDICATOR, LOADMETER/VOLTMETER	INSCO
6610-3005	INDICATOR, ACCELEROMETER	INSCO
6610-3006	INDICATOR, ACCELEROMETER	INSCO
6831-112	INDICATOR, TRIPLE TRIM	INSCO
70-0054-1	CONTROL, DIMMER	GRIMES
70-0075-1	STROBE LIGHT FLASHER	GRIMES
700-1017-001	INDICATOR, XMSN OIL PRESSURE	AHLERS AEROSPACE
700-2760-1	INDICATOR, TORQUE	INSCO
700348-17	DETECTOR, RPM LIMIT	SYMBOLIC DISPLAYS
700-5211-1	INDICATOR, PRESSURE	INSCO
700-5211-3	INDICATOR, TEMPERATURE/PRESSURE	INSCO
700-5211-5	INDICATOR, PRESSURE	INSCO
700-5213-1	INDICATOR, TEMPERATURE	INSCO
700-5213-3	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
700-5219-1	INDICATOR, VOLT/AMMETER	INSCO
700-5221-1	INDICATOR, TEMPERATURE/PRESSURE	INSCO
701-10001	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
701-10002	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
701-10003	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
701-10004	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
701-10005	INDICATOR, XMSN OIL TEMP/PRESS	AHLERS AEROSPACE
701-10006	INDICATOR, XMSN OIL TEMP/PRESS	AHLERS AEROSPACE
701-10007	INDICATOR, XMSN OIL TEMP/PRESS	AHLERS AEROSPACE
701-10012	INDICATOR, XMSN OIL TEMP/PRESS	AHLERS AEROSPACE
701-10013	INDICATOR, XMSN OIL TEMP/PRESS	AHLERS AEROSPACE
701-10014	INDICATOR, XMSN OIL TEMP/PRESS	AHLERS AEROSPACE
701-10015	INDICATOR, XMSN OIL TEMP/PRESS	AHLERS AEROSPACE
701-10016	INDICATOR, XMSN OIL TEMP/PRESS	AHLERS AEROSPACE
701-10017	INDICATOR, XMSN OIL TEMP/PRESS	AHLERS AEROSPACE
701-10020	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
701-10022	INDICATOR, XMSN OIL TEMP/PRESS	AHLERS AEROSPACE
701-10023	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
701-10034	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
701-10035	INDICATOR, XMSN OIL TEMP/PRESS	AHLERS AEROSPACE
701-10036	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
701-40002	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
701-40003	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
701-40008	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
701-40018	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
701-40019	INDICATOR, XMSN OIL TEMP/PRESS	AHLERS AEROSPACE
701-40032	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
701-40033	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-10002	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-10003	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-10005	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-10006	INDICATOR, XMSN OIL TEMP/PRESS	AHLERS AEROSPACE
702-10009	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-10010	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-10012	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-10019	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-10020	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-10022	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-10023	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-10024	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-10025	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-10026	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-10030	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-10031	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-10032	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
702-10033	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-10036	INDICATOR, OIL TEMP/PRESS	AHLERS AEROSPACE
702-20013	INDICATOR, XMSN OIL TEMP/PRESS	AHLERS AEROSPACE
702-20016	INDICATOR, XMSN OIL TEMP/PRESS	AHLERS AEROSPACE
702-20018	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-20028	INDICATOR, XMSN OIL TEMP/PRESS	AHLERS AEROSPACE
702-20029	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-30001	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-30003	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-30007	INDICATOR, HYDRAULIC OIL TEMP/PRESS	AHLERS AEROSPACE
702-30015	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-30030	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-40008	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-40010	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-40011	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-40017	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
702-40034	INDICATOR, ITT TEMP/TORQUE PRESS	AHLERS AEROSPACE
702-40035	INDICATOR, OIL TEMP/PRESS	AHLERS AEROSPACE
702-40037	INDICATOR, ITT TEMP/TORQUE PRESS	AHLERS AEROSPACE
703-10001	INDICATOR, FUEL PRESS/FLOW	AHLERS AEROSPACE
703-10002	INDICATOR, FUEL PRESS/FLOW	AHLERS AEROSPACE
704-10008	INDICATOR, OIL TEMP/PRESS	AHLERS AEROSPACE
704-10009	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
704-10011	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
704-10014	INDICATOR, OIL TEMP/PRESS	AHLERS AEROSPACE
704-10016	INDICATOR, OIL TEMP/PRESS	AHLERS AEROSPACE
704-10035	INDICATOR, OIL TEMP/PRESS	AHLERS AEROSPACE
704-10036	INDICATOR, OIL TEMP/PRESS	AHLERS AEROSPACE
704-10038	INDICATOR, OIL TEMP/PRESS	AHLERS AEROSPACE
704-10039	INDICATOR, OIL TEMP/PRESS	AHLERS AEROSPACE
704-10041	INDICATOR, OIL TEMP/PRESS	AHLERS AEROSPACE
704-10042	INDICATOR, OIL TEMP/PRESS	AHLERS AEROSPACE
704-20003	INDICATOR, OIL TEMP/PRESS	AHLERS AEROSPACE
704-20040	INDICATOR, OIL TEMP/PRESS	AHLERS AEROSPACE
704-30001	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
704-30028	INDICATOR, XMSN OIL TEMP/PRESS	AHLERS AEROSPACE
704-30032	INDICATOR, XMSN C BOX OIL TEMP/PRESS	AHLERS AEROSPACE
704-30043	INDICATOR, OIL TEMP/PRESS	AHLERS AEROSPACE
704-30044	INDICATOR, OIL TEMP/PRESS	AHLERS AEROSPACE
704-40033	INDICATOR, RGBTEMP/PRESS	AHLERS AEROSPACE
704-40034	INDICATOR, OIL TEMP/PRESS	AHLERS AEROSPACE
704A.36.712.006CT	INDICATOR, DC VOLTMETER	INSCO
704A.36.712.010CT	INDICATOR, DC VOLTMETER	INSCO
704A.36.712.012CT	INDICATOR, AC VOLTMETER	INSCO
704A-37-610-035	INDICATOR, DUAL TACHOMETER	INSCO
704A-37-610-036	INDICATOR, DUAL TACHOMETER	INSCO
704A-37-612-008	INDICATOR, TACHOMETER	INSCO
704A-37-612-009	INDICATOR, TACHOMETER	INSCO
704A-37-616-001-1	INDICATOR, TRIPLE TACHOMETER	INSCO
704A-37-616-001-2	INDICATOR, TRIPLE TACHOMETER	INSCO
704A-37-616-001-3	INDICATOR, TRIPLE TACHOMETER	INSCO
704A-37-621-070	INDICATOR, DUAL TORQUE	INSCO
704A-37-634-015	INDICATOR, ENGINE OIL TEMPERATURE	INSCO
704A-37-634-018	INDICATOR, MGB OIL TEMPERATURE	INSCO
704A-37-641-023	INDICATOR, MGB OIL PRESSURE	INSCO
704A-37-642-045	INDICATOR, ENGINE OIL PRESSURE	INSCO
704A-37-643-009	INDICATOR, FUEL PRESSURE	INSCO
704A-47270-036	INSTRUMENT CLUSTER	INSCO
704A-47270-037	INSTRUMENT CLUSTER	INSCO
704A-47-612	INDICATOR, ROTOR RPM	ABG-SEMCA SA
704A-47-612-025	INDICATOR, TACHOMETER	INSCO
704A-47-612-032	INDICATOR, TACHOMETER	INSCO
704A-47-612-042	INDICATOR, TACHOMETER	INSCO
704A-47-612-045	INDICATOR, TACHOMETER	INSCO
704A-47-612-048	INDICATOR, NG % TACHOMETER	INSCO
704A-47-612-063	INDICATOR, DUAL GAS PRODUCER TACHOMETER	INSCO
704A-47-616-012	INDICATOR, TRIPLE TACHOMETER	INSCO
704A-47-616-013	INDICATOR, TRIPLE TACHOMETER	INSCO

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
704A-47-620-016	INDICATOR, STRAIN GAGE	INSCO
704A-47-621-037	INDICATOR, DUAL TORQUE	INSCO
704A-47-621-059	INDICATOR, TORQUE	INSCO
704A-47-621-082	INDICATOR, DUAL TORQUE	INSCO
704A-47-632-020	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
704A-47-632-040	INDICATOR, DUAL T-4 TEMPERATURE	INSCO
704Z-37-611-011	MONOPOLE GENERATOR	INSCO
704Z-37-614-005	SENSOR, MAGNETIC	INSCO
704Z-37-616-000	INDICATOR, TRIPLE TACHOMETER	INSCO
704Z-37-616-009	INDICATOR, TRIPLE TACHOMETER	INSCO
704Z-37-642-050	TRANSDUCER, PRESSURE	INSCO
704Z-47-612-045	INDICATOR, TACHOMETER	INSCO
704Z-47-612-046	INDICATOR, TACHOMETER	INSCO
704Z-47-616-010	INDICATOR, TRIPLE TACHOMETER	INSCO
704Z-47-616-014	INDICATOR, TRIPLE TACHOMETER	INSCO
704Z-47-618-00	INDICATOR, DUAL TACHOMETER	INSCO
704Z-47-621-065	INDICATOR, TORQUE	INSCO
704Z-47-632-020	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
705-10001	INDICATOR, FUEL PRESS/LOADMETER	AHLERS AEROSPACE
705-10002	INDICATOR, FUEL PRESS/LOADMETER	AHLERS AEROSPACE
705-10003	INDICATOR, FUEL PRESS/LOADMETER	AHLERS AEROSPACE
705-10004	INDICATOR, FUEL PRESS/LOADMETER	AHLERS AEROSPACE
705-10008	INDICATOR, FUEL PRESS/LOADMETER	AHLERS AEROSPACE
705-10009	INDICATOR, FUEL PRESS/LOADMETER	AHLERS AEROSPACE
705-10010	INDICATOR, FUEL PRESS/LOADMETER	AHLERS AEROSPACE
705-10016	INDICATOR, FUEL PRESS/LOADMETER	AHLERS AEROSPACE
705-10017	INDICATOR, FUEL PRESS/LOADMETER	AHLERS AEROSPACE
705-10018	INDICATOR, FUEL PRESS/LOADMETER	AHLERS AEROSPACE
705-10019	INDICATOR, FUEL PRESS/LOADMETER	AHLERS AEROSPACE
705-10020	INDICATOR, FUEL PRESS/LOADMETER	AHLERS AEROSPACE
705-10021	INDICATOR, FUEL PRESS/LOADMETER	AHLERS AEROSPACE
705-10022	INDICATOR, FUEL PRESS/LOADMETER	AHLERS AEROSPACE
705-10023	INDICATOR, FUEL PRESS/LOADMETER	AHLERS AEROSPACE
705-10024	INDICATOR, FUEL PRESS/LOADMETER	AHLERS AEROSPACE
705-2C4-771-008	INDICATOR, DUAL TORQUE	INSCO
705-2C4-771-010	INDICATOR, DUAL N1 TACHOMETER	INSCO
705-2C4-771-011	INDICATOR, TRIPLE TACHOMETER	INSCO
705-2C4-772-003	INDICATOR, TURBINE OUTLET TEMPERTURE	INSCO
705-2C4-793-004	INDICATOR, ENGINE OIL TEMP/PRESS	INSCO
705-2M4-246-003	INDICATOR, DUAL VOLTMETER	INSCO
705-2M4-246-004	INDICATOR, DUAL AMMETER	INSCO
705-2M4-293-003	INDICATOR, DUAL HYDRAULIC PRESSURE	INSCO
705-2M4-634-003	INDICATOR, OIL TEMP/PRESS	INSCO
705-2M4-771-008	INDICATOR, DUAL TORQUE	INSCO
705-2M4-771-009	INDICATOR, DUAL N1 TACHOMETER	INSCO
705-2M4-771-011	INDICATOR, TRIPLE TACHOMETER	INSCO
705-2M4-772-003	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
706-1017-1	INDICATOR, XMSN OIL PRESSURE	INSCO
707-40001	INDICATOR, ENGINE	AHLERS AEROSPACE
708-40001	INDICATOR, ENGINE	AHLERS AEROSPACE
711-10001	INDICATOR, VOLT/AMMETER	AHLERS AEROSPACE
711-10003	INDICATOR, VOLT/AMMETER	AHLERS AEROSPACE
711-10007	INDICATOR, DUAL VOLTMETER	AHLERS AEROSPACE
711-10012	INDICATOR, DUAL AMMETER	AHLERS AEROSPACE
711-10015	INDICATOR, DUAL AMMETER	AHLERS AEROSPACE
711-10018	INDICATOR, VOLT/AMMETER	AHLERS AEROSPACE
711-10020	INDICATOR, VOLT/AMMETER	AHLERS AEROSPACE
711-10021	INDICATOR, DUAL VOLTMETER	AHLERS AEROSPACE
711-10022	INDICATOR, VOLT/AMMETER	AHLERS AEROSPACE
711-10023	INDICATOR, DUAL AMMETER	AHLERS AEROSPACE
711-10024	INDICATOR, VOLT/AMMETER	AHLERS AEROSPACE
711-10025	INDICATOR, VOLT/AMMETER	AHLERS AEROSPACE
711-10026	INDICATOR, VOLT/AMMETER	AHLERS AEROSPACE
711-10029	INDICATOR, VOLT/AMMETER	AHLERS AEROSPACE
711-10032	INDICATOR, VOLT/AMMETER	AHLERS AEROSPACE
711-30010	INDICATOR, DUAL VOLTMETER	AHLERS AEROSPACE
711-30017	INDICATOR, DUAL AMMETER	AHLERS AEROSPACE
711-30025	INDICATOR, VOLT/AMMETER	AHLERS AEROSPACE

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
711-30028	INDICATOR, VOLT/AMMETER	AHLERS AEROSPACE
711-40002	INDICATOR, VOLT/AMMETER	AHLERS AEROSPACE
711-40018	INDICATOR, VOLT/AMMETER	AHLERS AEROSPACE
711-40019	INDICATOR, VOLT/AMMETER	AHLERS AEROSPACE
711-40030	INDICATOR, DUAL VOLTMETER	AHLERS AEROSPACE
711-40031	INDICATOR, DUAL AMMETER	AHLERS AEROSPACE
712-10001	INDICATOR, OIL TEMP/PRESS	AHLERS AEROSPACE
71-301-145	INDICATOR, ENGINE OIL TEMP/PRESS	INSCO
71-311-148	INDICATOR, MEASURED GAS TEMPERATURE	INSCO
71-321-154	INDICATOR, DUAL XMSN PRESSURE	INSCO
71-331-157	INDICATOR, DUAL FUEL PRESSURE	INSCO
71-341-159	INDICATOR, DUAL HYDRAULIC PRESSURE	INSCO
71-352-162	INDICATOR, TRIPLE TACHOMETER	INSCO
71-361-163	INDICATOR, GAS PRODUCER TACHOMETER	INSCO
71-371-165	INDICATOR, TRIPLE TACHOMETER	INSCO
71-381-166	INDICATOR, DUAL TORQUE	INSCO
71-394-189	INDICATOR, TRIPLE FUEL QTY	INSCO
71-403-122	INDICATOR, XMSN OIL TEMPERATURE	INSCO
71-411-211	INDICATOR, DUAL DC AMMETER	INSCO
715-40001	INDICATOR, VOLT/AMMETER	AHLERS AEROSPACE
723-10001	INDICATOR, FUEL TEMPERATURE	AHLERS AEROSPACE
730-10001	INDICATOR CLUSTER, VOLT/AMMETER	AHLERS AEROSPACE
730-10002	INDICATOR CLUSTER, VOLT/AMMETER	AHLERS AEROSPACE
730-10003	INDICATOR CLUSTER, VOLT/AMMETER	AHLERS AEROSPACE
730-10004	INDICATOR CLUSTER, VOLT/AMMETER	AHLERS AEROSPACE
730-10005	INDICATOR CLUSTER, VOLT/AMMETER	AHLERS AEROSPACE
730-10006	INDICATOR CLUSTER, VOLT/AMMETER	AHLERS AEROSPACE
730-30001	INDICATOR CLUSTER, VOLT/AMMETER	AHLERS AEROSPACE
73-101-1	TRANSMITTER, FUEL, QTY	Ragen Data
73-21-00	VALVE, N2 OVERSPEED SOLENOID	GENERAL MOTORS
732-10001	INDICATOR, CLUSTER	AHLERS AEROSPACE
749-40001	INDICATOR, FLAP POSITION	AHLERS AEROSPACE
75-0152-1	PANEL, MASTER CAUTION	GRIMES
75-0152-3	PANEL, MASTER CAUTION	GRIMES
75-0152-5	PANEL, MASTER CAUTION	GRIMES
750-30001	INDICATOR, HOVER	AHLERS AEROSPACE
75-0326-1	PANEL, MASTER CAUTION	GRIMES
75-0326-3	PANEL, MASTER CAUTION	GRIMES
75-0326-5	PANEL, MASTER CAUTION	GRIMES
7582-175-00-12	INDICATOR, NG DUAL	BRION LEROUX
76450	INDICATOR, ENGINE OIL TEMP/PRESS	INSCO
76450-00801-1101	INDICATOR, AIRSPEED	INSCO
76450-00901-104	INDICATOR, AIRSPEED	INSCO
76450-00907	INDICATOR, TACHOMETER	INSCO
76450-01058-1008	INDICATOR, OIL TEMP/PRESS	INSCO
76450-01058-101	INDICATOR, TACHOMETER	INSCO
76450-01058-102	INDICATOR, TURBINE INLET TEMPERATURE	INSCO
76450-01058-103	INDICATOR, OIL TEMP/PRESS	INSCO
76450-01058-104	INDICATOR, FUEL PRESSURE	INSCO
76450-01058-105	INDICATOR, DUAL FUEL QTY	INSCO
76450-01058-106	INDICATOR, FUEL QTY	INSCO
76450-01058-107	INDICATOR, FUEL QTY	INSCO
76450-01058-110	INDICATOR, TRIPLE TACHOMETER	INSCO
76450-01058-111	INDICATOR, DUAL TORQUE	INSCO
76450-01076-101	INDICATOR, NG TACHOMETER	INSCO
76450-01076-103	INDICATOR, TRIPLE TACHOMETER	INSCO
76450-01076-105	INDICATOR, T-5 TEMPERATURE	INSCO
76450-01076-106	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
76450-01076-107	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
76450-01078-118	TRANSMITTER, OIL PRESSURE	INSCO
76450-01087-106	INDICATOR, DUAL TORQUE	INSCO
771-5211-001	INDICATOR, TORQUE	AHLERS AEROSPACE
771-5211-011	INDICATOR, TORQUE	AHLERS AEROSPACE
771-5211-1	INDICATOR, TORQUE	INSCO
771-5211-3	INDICATOR, TORQUE	INSCO
771-5213-3	INDICATOR, TURBINE OUTLET TEMPERATURE	INSCO
771-5221-001	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE
771-5221-011	INDICATOR, ENGINE OIL TEMP/PRESS	AHLERS AEROSPACE

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
782000000-01	INDICATOR, TRIPLE TORQUE	CLIFTON PRECISION
782000000-02	INDICATOR, TRIPLE TORQUE	CLIFTON PRECISION
782000000-03	INDICATOR, TRIPLE TACHOMETER	CLIFTON PRECISION
783000000-03	INDICATOR, TRIPLE TORQUE	CLIFTON PRECISION
783000000-04	INDICATOR, TRIPLE TORQUE	CLIFTON PRECISION
7SC0241	INDICATOR, RUDDER TRIM POSITION	INSCO
7SC-0242	INDICATOR, NOSEWHEEL POSITION	INSCO
8000 SERIES	INDICATOR, AIRSPEED	UNITED INST.
800-0001	UNIT, FUEL CONTROL	AHLERS AEROSPACE
80-0070-1	PANEL, MASTER CAUTION	GRIMES
80-0070-11	PANEL, MASTER CAUTION	GRIMES
80-0070-9	PANEL, MASTER CAUTION	GRIMES
8001-1016	INDICATOR, AILERON TRIM POSITION	INSCO
8001-3005	INDICATOR, HORIZONTAL STABILIZING TRIM POSITION	INSCO
8001-3006	INDICATOR, FLAP POSITION	INSCO
8001-3017	INDICATOR, FLAP POSITION	INSCO
8001-3018	INDICATOR, RUDDER TRIM	INSCO
8001-3019	INDICATOR, FLAP POSITION	INSCO
8001-3020	INDICATOR, AILERON TRIM POSITION	INSCO
80-0199-1	PANEL, MASTER CAUTION	GRIMES
80-0199-1 thru -41	MASTER CAUTION PANEL	GRIMES
80-0199-11	PANEL, MASTER CAUTION	GRIMES
80-0199-13	PANEL, MASTER CAUTION	GRIMES
80-0199-15	PANEL, MASTER CAUTION	GRIMES
80-0199-17	PANEL, MASTER CAUTION	GRIMES
80-0199-19	PANEL, MASTER CAUTION	GRIMES
80-0199-21	PANEL, MASTER CAUTION	GRIMES
80-0199-23	PANEL, MASTER CAUTION	GRIMES
80-0199-25	PANEL, MASTER CAUTION	GRIMES
80-0199-27	PANEL, MASTER CAUTION	GRIMES
80-0199-29	PANEL, MASTER CAUTION	GRIMES
80-0199-3	PANEL, MASTER CAUTION	GRIMES
80-0199-31	PANEL, MASTER CAUTION	GRIMES
80-0199-33	PANEL, MASTER CAUTION	GRIMES
80-0199-39	PANEL, MASTER CAUTION	GRIMES
80-0199-5	PANEL, MASTER CAUTION	GRIMES
80-0199-7	PANEL, MASTER CAUTION	GRIMES
80-0199-9	PANEL, MASTER CAUTION	GRIMES
8003-3002	INDICATOR, FLAP POSITION	INSCO
8003-3003	INDICATOR, PITCH TRIM	INSCO
800-40002	SWITCH, FUEL PRESS DIFF	AHLERS AEROSPACE
8009-3003	INDICATOR, FLAP POSITION/TRIM	INSCO
801-40001	UNIT, RPM WARNING	AHLERS AEROSPACE
801-40002	UNIT, ROTOR WARNING	AHLERS AEROSPACE
801-40003	UNIT, RPM WARNING	AHLERS AEROSPACE
801-40004	UNIT, RPM WARNING	AHLERS AEROSPACE
801-40005-10	SENSOR, LOW ROTOR RPM WARNING	AHLERS AEROSPACE
801-40009	SENSOR, RPM WARNING	AHLERS AEROSPACE
801-40011	SENSOR, RPM WARNING	AHLERS AEROSPACE
801-40015	SENSOR, RPM WARNING	AHLERS AEROSPACE
801-40016	FREQUENCY CONVERTER	AHLERS AEROSPACE
801-40017	ENGINE POWER OUT	AHLERS AEROSPACE
801-40018	ENGINE POWER OUT	AHLERS AEROSPACE
801-40019	ENGINE POWER OUT	AHLERS AEROSPACE
802-40001	WARNING UNIT, BEARING TEMPERATURE	AHLERS AEROSPACE
802-40002	DETECTOR, FUEL TEMPERATURE	AHLERS AEROSPACE
802-40003	WARNING UNIT, BEARING TEMPERATURE	AHLERS AEROSPACE
8025 SERIES	INDICATOR, AIRSPEED	UNITED INST.
8030 SERIES	INDICATOR, AIRSPEED	UNITED INST.
803-10001	EMERGENCY POWER CONTROL	AHLERS AEROSPACE
803-40001	EMERGENCY POWER SUPPLY	AHLERS AEROSPACE
8040 SERIES	INDICATOR, AIRSPEED	UNITED INST.
804-10002	PANEL, SYSTEM WARNING	AHLERS AEROSPACE
804-40001	PANEL, DOOR AJAR	AHLERS AEROSPACE
805-40001	CONTROL, ELECTRICAL, PRIMARY	AHLERS AEROSPACE
805-40002	CONTROL, ELECTRICAL, BACKUP	AHLERS AEROSPACE
806-10001	SWITCH, VOLTAGE SELECTOR	AHLERS AEROSPACE
806-30001	SWITCH, VOLTAGE SELECTOR	AHLERS AEROSPACE

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
807-10001	PANEL, DC POWER MONITOR,	AHLERS AEROSPACE
807-10003	PANEL, DC POWER MONITOR,	AHLERS AEROSPACE
808-30001	ASSEMBLY, NVIS INSTRUMENT EYEBROW	AHLERS AEROSPACE
808-30002	ASSEMBLY, NVIS INSTRUMENT EYEBROW	AHLERS AEROSPACE
808-30003	ASSEMBLY, NVIS INSTRUMENT EYEBROW	AHLERS AEROSPACE
808-30004	ASSEMBLY, NVIS INSTRUMENT EYEBROW	AHLERS AEROSPACE
808-30005	ASSEMBLY, NVIS INSTRUMENT EYEBROW	AHLERS AEROSPACE
808-30006	ASSEMBLY, NVIS INSTRUMENT EYEBROW	AHLERS AEROSPACE
808-30052	ASSEMBLY, INSTRUMENT EYEBROW	AHLERS AEROSPACE
808-30056	UTILITY LIGHT, NVIS GREEN A	AHLERS AEROSPACE
808-30057	UTILITY LIGHT, NVIS GREEN A	AHLERS AEROSPACE
808-30058	POST LIGHT ASSEMBLY	AHLERS AEROSPACE
808-30066	UTILITY LIGHT, FLEXIBLE ARM	AHLERS AEROSPACE
808-40016	FREQUENCY CONVERTER	AHLERS AEROSPACE
809-40001	SIGNAL CONDITIONER	AHLERS AEROSPACE
809-40002	SIGNAL CONDITIONER	AHLERS AEROSPACE
809-40003	SIGNAL CONDITIONER	AHLERS AEROSPACE
809-40004	SIGNAL CONDITIONER	AHLERS AEROSPACE
80K208208-401	E105 FREON CONTROL UNIT	PIAGGIO AERO INSDUSTRIES
810-10001	ANNUNCIATOR, PANEL	AHLERS AEROSPACE
810-10002	ANNUNCIATOR	AHLERS AEROSPACE
810-30003	GPS ANNUNCIATOR	AHLERS AEROSPACE
811-40001	LOGIC CONTROL BOX	AHLERS AEROSPACE
812-40001	SPEAKER BOX	AHLERS AEROSPACE
813-40001	TONE GENERATOR	AHLERS AEROSPACE
83-104-1	INDICATOR, FUEL QTY	Ragen Data
83900099	SENSOR, RPM	APPLIED ELEC. TECH
839-00099	SENSOR, RPM	SCIENTIFIC TECHNOLOGY
839-00150	SENSOR, RPM	APPLIED ELEC. TECH
839-00150	SENSOR, RPM	SCIENTIFIC TECHNOLOGY
839-00154	SENSOR, RPM	APPLIED ELEC. TECH
839-00154	SENSOR, RPM	SCIENTIFIC TECHNOLOGY
839-00155	SENSOR, RPM	APPLIED ELEC. TECH
839-00155	SENSOR, RPM	SCIENTIFIC TECHNOLOGY
839-00157	SENSOR, RPM	APPLIED ELEC. TECH
839-00170	SENSOR, RPM	APPLIED ELEC. TECH
839-00170	SENSOR, RPM	SCIENTIFIC TECHNOLOGY
850083-507	INDICATOR, DUAL TACHOMETER	INSCO
850083-509	INDICATOR, DUAL TACHOMETER	INSCO
850275-507	INDICATOR, % RPM TACHOMETER	INSCO
850275-509	INDICATOR, % RPM TACHOMETER	INSCO
850493-1	INDICATOR, ENGINE TEMP/PRESS	INSCO
850493-505	INDICATOR, ENGINE TEMP/PRESS	INSCO
850493-511	INDICATOR, ENGINE TEMP/PRESS	INSCO
850493-517	INDICATOR, ENGINE TEMP/PRESS	INSCO
850493-519	INDICATOR, ENGINE TEMP/PRESS	INSCO
850493-5B	INDICATOR, ENGINE TEMP/PRESS	INSCO
850568	INDICATOR, INTER TURBINE TEMPERTURE	INSCO
850568-1	INDICATOR, INTER TURBINE TEMPERTURE	INSCO
850568-503	INDICATOR, INTER TURBINE TEMPERTURE	INSCO
850591-1	INDICATOR, DUAL TRIM TAB POSITION	INSCO
850591-501	INDICATOR, DUAL TRIM TAB POSITION	INSCO
850591-503	INDICATOR, DUAL TRIM TAB POSITION	INSCO
850629	INDICATOR, DUAL OIL PRESSURE	INSCO
850630-1	INDICATOR, DUAL FUEL PRESSURE	INSCO
850630-501	INDICATOR, DUAL FUEL PRESSURE	INSCO
850631-1	INDICATOR, DUAL TEMPERATURE	INSCO
850631-501	INDICATOR, DUAL TEMPERATURE	INSCO
850634-501	INDICATOR, EXHAUST GAS TEMPERATURE	INSCO
850637-1	INDICATOR, TORQUE	INSCO
850637-501	INDICATOR, % TORQUE	INSCO
850662-501	INDICATOR, TACHOMETER	INSCO
8DJ100AAA1	INDICATOR, SERVO TEMP	GENERAL ELECTRIC
8DJ100AAF1	INDICATOR, SERVO TEMP	GENERAL ELECTRIC
8DJ100AAK1	INDICATOR, SERVO TEMP	GENERAL ELECTRIC
8DJ100AAS4	INDICATOR, SERVO TEMP	GENERAL ELECTRIC
8DJ100LAB1	INDICATOR, SERVO TEMP	GENERAL ELECTRIC
8DJ100LAC1	INDICATOR, SERVO TEMP	GENERAL ELECTRIC

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
8DJ100LAE1	INDICATOR, SERVO TEMP	GENERAL ELECTRIC
8DJ100LAF1	INDICATOR, SERVO TEMP	GENERAL ELECTRIC
8DJ100LAK1	INDICATOR, SERVO TEMP	GENERAL ELECTRIC
8DJ100LAR1	INDICATOR, SERVO TEMP	GENERAL ELECTRIC
8DJ100LAT1	INDICATOR, SERVO TEMP	GENERAL ELECTRIC
8DJ100LAV1	INDICATOR, SERVO TEMP	GENERAL ELECTRIC
8DJ100LAW1	INDICATOR, SERVO TEMP	GENERAL ELECTRIC
8DJ100LAY1	INDICATOR, SERVO TEMP	GENERAL ELECTRIC
8DJ100LBA1	INDICATOR, SERVO TEMP	GENERAL ELECTRIC
8DJ100WAE4	INDICATOR, SERVO TEMP	GENERAL ELECTRIC
8DJ100WAG2	INDICATOR, SERVO TEMP	GENERAL ELECTRIC
8DJ100WAH4	INDICATOR, SERVO TEMP	GENERAL ELECTRIC
8DJ100WAM4	INDICATOR, SERVO TEMP	GENERAL ELECTRIC
8DJ100WAS2	INDICATOR, SERVO TEMP	GENERAL ELECTRIC
8DJ11PEZ/8TJ9PEL	POSITION IND./TRANSMITTER	GENERAL ELECTRIC
8DJ11PKA/8TJ9PFF	POSITION IND./TRANSMITTER	GENERAL ELECTRIC
8DJ120WAA	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	GENERAL ELECTRIC
8DJ131AAJ	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	GENERAL ELECTRIC
8DJ131AAJ1	INDICATOR, TRIPLE TACHOMETER	GENERAL ELECTRIC
8DJ131AAT2	INDICATOR, TRIPLE TACHOMETER	GENERAL ELECTRIC
8DJ131LAE1	INDICATOR, TRIPLE TACHOMETER	GENERAL ELECTRIC
8DJ131LAN1	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	GENERAL ELECTRIC
8DJ131LAV	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	GENERAL ELECTRIC
8DJ131LAV1	INDICATOR, TRIPLE TACHOMETER	GENERAL ELECTRIC
8DJ131LAW	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	GENERAL ELECTRIC
8DJ131LAW1	INDICATOR, TRIPLE TACHOMETER	GENERAL ELECTRIC
8DJ131LAZ1	INDICATOR, TRIPLE TACHOMETER	GENERAL ELECTRIC
8DJ131LBA	INDICATOR, TRIPLE TACHOMETER, MAGNETIC DRAG	GENERAL ELECTRIC
8DJ131LBA1	INDICATOR, TRIPLE TACHOMETER	GENERAL ELECTRIC
8DJ163LXK4	INDICATOR, TEMPERATURE	GENERAL ELECTRIC
8DJ163LXM4	INDICATOR, TEMPERATURE	GENERAL ELECTRIC
8DJ163LXY4	INDICATOR, TEMPERATURE	GENERAL ELECTRIC
8DJ163LYM4	INDICATOR, TEMPERATURE	GENERAL ELECTRIC
8DJ43AAF14	INDICATOR, TACHOMETER	GENERAL ELECTRIC
8DJ43AAL14	INDICATOR, TACHOMETER	GENERAL ELECTRIC
8DJ43AAM14	INDICATOR, TACHOMETER	GENERAL ELECTRIC
8DJ43BAE14	INDICATOR, TACHOMETER	GENERAL ELECTRIC
8DJ43BAH14	INDICATOR, TACHOMETER	GENERAL ELECTRIC
8DJ48AAD/8TJ9PFF	POSITION IND./TRANSMITTER	GENERAL ELECTRIC
8DJ48CAB1/8TJ9PFF	POSITION IND./TRANSMITTER	GENERAL ELECTRIC
8DJ48CAD/8TJ9PFF	POSITION IND./TRANSMITTER	GENERAL ELECTRIC
8DJ48FAH/8TJ9PFF	POSITION IND./TRANSMITTER	GENERAL ELECTRIC
8DJ67FRC	INDICATOR, DUAL TACHOMETER, MAGNETIC DRAG	GENERAL ELECTRIC
8DJ81CAA1	INDICATOR, TACHOMETER	GENERAL ELECTRIC
8DJ81CAA2	INDICATOR, TACHOMETER	GENERAL ELECTRIC
8DJ81LAA1	INDICATOR, TACHOMETER	GENERAL ELECTRIC
8DJ81LAA2	INDICATOR, TACHOMETER	GENERAL ELECTRIC
8DJ81LCA2	INDICATOR, TACHOMETER	GENERAL ELECTRIC
8DJ81LWA1	INDICATOR, TACHOMETER	GENERAL ELECTRIC
8DJ81LWA2	INDICATOR, TACHOMETER	GENERAL ELECTRIC
8DJ81LWA3	INDICATOR, TACHOMETER	GENERAL ELECTRIC
8DJ81LZA2	INDICATOR, TACHOMETER	GENERAL ELECTRIC
8DJ81WBS4	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	GENERAL ELECTRIC
8DJ81WDG4	INDICATOR, SINGLE TACHOMETER, MAGNETIC DRAG	GENERAL ELECTRIC
8SC0065	INDICATOR, FLAP POSITION	INSCO
8SC0070	INDICATOR, DUAL HYDRAULIC PRESSURE	INSCO
8SC0072	INDICATOR, AC POWER MONITOR	INSCO
8SC0079	INDICATOR, TEMPERATURE	INSCO
8SC0085	INDICATOR, HYDRAULIC BRAKE PRESSURE	INSCO
8SC0118	INDICATOR, DUAL DE-ICE PRESSURE	INSCO
8SC0152	INDICATOR, RUDDER TRIM POSITION	INSCO
8SC0158	INDICATOR, AILERON TRIM POSITION	INSCO
8SC0160	INDICATOR, DUAL TACHOMETER	INSCO
8SC0202	INDICATOR, ENGINE OIL TEMP/PRESS	INSCO
8SC0249	INDICATOR, DUAL FUEL TEMPERATURE	INSCO
900-10002	INDICATOR, AIRSPEED	AHLERS AEROSPACE
900-10003	INDICATOR, AIRSPEED	AHLERS AEROSPACE
9002-3001	CLUSTER, INSTRUMENT	INSCO

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
9003-1001	CLUSTER, INSTRUMENT	INSCO
9003-1101	CLUSTER, INSTRUMENT	INSCO
900-40001	SWITCH, AIRSPEED	AHLERS AEROSPACE
900-40002	INDICATOR, AIRSPEED	AHLERS AEROSPACE
90044-01 thru -58	ANTI-COLISION LIGHT	WHELEN
9006-3002	CLUSTER, INSTRUMENT	INSCO
9009-1014	INDICATOR, ENGINE OIL TEMP/PRESS	INSCO
9009-1026	INDICATOR, TEMP/PRESS	INSCO
9009-3003	INDICATOR, TEMP/PRESS	INSCO
9009-3004	INDICATOR, TEMP/PRESS	INSCO
9009-3009	INDICATOR, TEMP/PRESS	INSCO
9009-3010	INDICATOR, TEMP/PRESS	INSCO
9009-3013	INDICATOR, TEMP/PRESS	INSCO
9009-3028	INDICATOR, ENGINE OIL TEMP/PRESS	INSCO
9009-3029	INDICATOR, XMSN OIL TEMP/PRESS	INSCO
9009-3033	INDICATOR, ENGINE OIL TEMP/PRESS	INSCO
9009-3034	INDICATOR, XMSN OIL TEMP/PRESS	INSCO
901-10001	INDICATOR, ENVELOPE PRESSURE	AHLERS AEROSPACE
9016-3001	INDICATOR, LOAD/FUEL PRESS	INSCO
9016-3002	INDICATOR, LOAD/FUEL PRESS	INSCO
9016-3003	INDICATOR, LOAD/FUEL PRESS	INSCO
9016-3018	INDICATOR, LOAD/FUEL PRESS	INSCO
9016-3019	INDICATOR, LOAD/FUEL PRESS	INSCO
9016-3021	INDICATOR, LOAD/FUEL PRESS	INSCO
9016-3023	INDICATOR, LOAD/FUEL PRESS	INSCO
9016-3024	INDICATOR, LOAD/FUEL PRESS	INSCO
9016-3025	INDICATOR, LOAD/FUEL PRESS	INSCO
9016-3029	INDICATOR, LOAD/FUEL PRESS	INSCO
9017-3010	INDICATOR, ENGINE	INSCO
9018-1002	INDICATOR, OIL TEMPERATURE	INSCO
9018-1003	INDICATOR, OIL TEMPERATURE	INSCO
9018-1006	INDICATOR, OIL TEMPERATURE	INSCO
9018-1008	INDICATOR, OIL TEMPERATURE	INSCO
9019-1014	INDICATOR, OIL TEMP/PRESSURE	INSCO
9019-1015	INDICATOR, OIL TEMP/PRESSURE	INSCO
9019-1016	INDICATOR, OIL TEMP/PRESSURE	INSCO
9019-1029	INDICATOR, OIL TEMP/PRESSURE	INSCO
9019-1043	INDICATOR, OIL TEMP/PRESSURE	INSCO
9019-2020	INDICATOR, TEMP/PRESS	INSCO
9019-2045	INDICATOR, TEMP/PRESS	INSCO
9019-3003	INDICATOR, TEMP/PRESS	INSCO
9019-3040	INDICATOR, XMSN OIL TEMP/PRESS	INSCO
9019-3048	INDICATOR, TEMP/PRESS	INSCO
9019-8021	INDICATOR, TEMP/PRESS	INSCO
9019-8050	INDICATOR, TEMP/PRESS	INSCO
9019-8051	INDICATOR, TEMP/PRESS	INSCO
9019-8054	INDICATOR, TEMP/PRESS	INSCO
9020-1041	INDICATOR, VOLT/AMMETER	INSCO
9020-3014	INDICATOR, DC VOLTMETER	INSCO
9020-3021	INDICATOR, DUAL AMMETER	INSCO
9020-3031	INDICATOR, DUAL AMMETER	INSCO
9020-8048	INDICATOR, DUAL AMMETER	INSCO
9020-8049	INDICATOR, VOLT/AMMETER	INSCO
9021-1012	INDICATOR, VOLT/AMMETER	INSCO
9021-1022	INDICATOR, VOLT/AMMETER	INSCO
9021-2008	INDICATOR, VOLT/AMMETER	INSCO
9021-3008	INDICATOR, VOLT/AMMETER	INSCO
9021-3014	INDICATOR, VOLT/AMMETER	INSCO
9021-3015	INDICATOR, VOLT/AMMETER	INSCO
9021-3016	INDICATOR, VOLT/AMMETER	INSCO
9021-3017	INDICATOR, VOLT/AMMETER	INSCO
9021-3018	INDICATOR, TRANSFORMER/RETIFIER	INSCO
9021-3019	INDICATOR, DUAL AC GENERATOR	INSCO
9021-3020	INDICATOR, VOLT/AMMETER	INSCO
9021-3024	INDICATOR, VOLT/AMMETER	INSCO
9030-1001	INDICATOR, DUAL OIL TEMP	INSCO
9030-1002	INDICATOR, DUAL FUEL PRESSURE	INSCO
9030-1003	INDICATOR, DUAL FUEL PRESSURE	INSCO

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
9030-1017	INDICATOR, DUAL FUEL PRESSURE	INSCO
9030-1024	INDICATOR, DUAL OIL PRESSURE	INSCO
9030-3033	INDICATOR, DUAL FUEL PRESSURE	INSCO
9030-3035	INDICATOR, DUAL DE-ICE PRESSURE	INSCO
9030-3036	INDICATOR, PARK BRAKE HYDRAULIC PRESSURE	INSCO
9030-3037	INDICATOR, DUAL FUEL TEMPERATURE	INSCO
9030-3038	INDICATOR, DUAL FUEL PRESSURE	INSCO
9030-3039	INDICATOR, DUAL OIL PRESSURE	INSCO
9031-1007	INDICATOR, DUAL OIL TEMP	INSCO
9031-3009	INDICATOR, DUAL OIL TEMP	INSCO
9031-3010	INDICATOR, DUAL OIL TEMP	INSCO
9031-3018	INDICATOR, DUAL OIL TEMP	INSCO
9032-1003	INDICATOR, DUAL FUEL QTY	INSCO
9032-1018	INDICATOR, DUAL FUEL QTY	INSCO
9032-1022	INDICATOR, DUAL FUEL QTY	INSCO
9032-3008	INDICATOR, DUAL FUEL QTY	INSCO
9032-3013	INDICATOR, DUAL FUEL QTY	INSCO
9032-3017	INDICATOR, DUAL FUEL QTY	INSCO
9032-3023	INDICATOR, DUAL FUEL QTY	INSCO
9032-3024	INDICATOR, AUX TANK FUEL QTY	INSCO
9032-3026	INDICATOR, DUAL FUEL QTY	INSCO
9032-3028	INDICATOR, AUX TANK FUEL QTY	INSCO
9034-1002	INDICATOR, OIL PRESSURE	INSCO
9036-1009	INDICATOR, OIL TEMP/PRESSURE	INSCO
9036-1025	INDICATOR, OIL TEMP/PRESSURE	INSCO
9036-1039	INDICATOR, OIL TEMP/PRESSURE	INSCO
9036-1044	INDICATOR, OIL TEMP/PRESSURE	INSCO
9036-1051	INDICATOR, OIL TEMP/PRESSURE	INSCO
9036-1053	INDICATOR, OIL TEMP/PRESSURE	INSCO
9036-2007	INDICATOR, TEMP/PRESS	INSCO
9036-2012	INDICATOR, OIL TEMP/PRESSURE	INSCO
9036-2132	INDICATOR, TEMP/PRESS	INSCO
9036-2133	INDICATOR, TEMP/PRESS	INSCO
9036-3005	INDICATOR, OIL TEMP/PRESSURE	INSCO
9036-3011	CLUSTER, VOLT/AMMETER	INSCO
9036-3012	INDICATOR, OIL TEMP/PRESSURE	INSCO
9036-3014	INDICATOR, OIL TEMP/PRESSURE	INSCO
9036-3026	INDICATOR, OIL TEMP/PRESSURE	INSCO
9036-3034	INDICATOR, OIL TEMP/PRESSURE	INSCO
9036-3036	INDICATOR, OIL TEMP/PRESSURE	INSCO
9036-3042	INDICATOR, OIL TEMP/PRESSURE	INSCO
9036-3043	INDICATOR, OIL TEMP/PRESSURE	INSCO
9036-3048	INDICATOR, OIL TEMP/PRESSURE	INSCO
9036-3050	INDICATOR, OIL TEMP/PRESSURE	INSCO
9036-3052	INDICATOR, OIL TEMP/PRESSURE	INSCO
9036-3055	INDICATOR, OIL TEMP/PRESSURE	INSCO
9036-3056	INDICATOR, OIL TEMP/PRESSURE	INSCO
9036-3057	INDICATOR, OIL TEMP/PRESSURE	INSCO
9036-3058	INDICATOR, OIL TEMP/PRESSURE	INSCO
9036-3059	INDICATOR, OIL TEMP/PRESSURE	INSCO
9036-3060	INDICATOR, OIL TEMP/PRESSURE	INSCO
9036-3061	INDICATOR, OIL TEMP/PRESSURE	INSCO
9036-3062	INDICATOR, TRANSMISSION OIL TEMP/PRESSURE	INSCO
9036-8153	INDICATOR, TEMP/PRESS	INSCO
90-384023-1	INDICATOR, VOLT/AMMETER	INSCO
90-384028-1	INDICATOR, PROP TACHOMETER	INSCO
90-384028-3	INDICATOR, PROP TACHOMETER	INSCO
9041-1004	INDICATOR, DUAL FUEL PRESSURE	INSCO
9041-1005	INDICATOR, FUEL/OIL PRESSURE	INSCO
9041-1007	INDICATOR, FUEL/OIL PRESSURE	INSCO
9041-1014	INDICATOR, DUAL FUEL PRESSURE	INSCO
9041-1015	INDICATOR, DUAL OIL PRESSURE	INSCO
9041-1019	INDICATOR, DUAL FUEL PRESSURE	INSCO
9041-3008	INDICATOR, DUAL FUEL PRESSURE	INSCO
9041-3016	INDICATOR, DUAL OIL PRESSURE	INSCO
9041-3017	INDICATOR, DUAL OIL PRESSURE	INSCO
9041-3020	INDICATOR, DUAL OIL PRESSURE	INSCO
9049-1001	INDICATOR, FUEL QTY	INSCO

Ahlers Aerospace, Inc.
Repair Station Capability Listing

MFG P/N	DESCRIPTION	MFG.
9050-2001	INDICATOR, OIL TEMP/PRESSURE	INSCO
9053-1002	CLUSTER, INSTRUMENT	INSCO